

Merging Beamlet Experiment Review

May 10, 2004

Injector Group:

Joe Kwan (experiment)

Glen Westenskow (experiment)

Dave Grote (theory)


Irv Haber (theory)

Erni Halaxa (designer)

Gary Freeze (Mech. Tech)

Bob Hall (Elec. Tech)

Ion Beams for Heavy Ion Inertial Fusion



Power amplification to the required 10^{14} - 10^{15} W is achieved by beam combining, acceleration and longitudinal bunching.

- Heavy ion beams have significant space-charge effects
- Multiple beams provide better target illumination symmetry and a better match to the beam transport limits.



HIF Drivers require Injectors of Bright Beams

Ion mass	> 100 amu for driver, 39 amu for HCX
Total charge delivered	~ 1 mC
Beam current per beam	~ 0.5 ampere (transport limit)
Delta I/ I	± 0.2 %
Total beam current	≥ 50 ampere
Number of beams	≈ 100
Injector voltage	~ 1.5 - 2.0 MV
(Delta V)/ V	± 0.1%
Line charge density per beam	≥ 0.2 μC/m
Pulse length	≈ 10 - 20 μs
Rise time	< 1 μs
Current density uniformity	± 10%
Emittance (each 0.5 A beam)	< 1 π-mm-mrad (adequate, but smaller is better)
Life time	~ 5 Hz x 3.15x10 ⁷ sec/yr = 1.6x10 ⁸ pulses

Achieved parameters
are in red fonts

Traditional HIF Injectors use large surface sources

- Surface ionization source diameter ≥ 10 cm, solid emitter boundary.
- Current density < 10 mA/cm² of K⁺.
- 750 kV pre-accelerator before ESQ.



Specifications:

1.8 MV


0.6 A K⁺

1 π -mm-mrad


Good agreement between experimental results and simulation predictions

Warp simulations


Experimental results



10-cm diameter K+ Alumino-silicate source




Step 1199, T = 2.1556e-6 s, Zbeam = 0.0000 m
 STS500: 6161518
 J.-L. Vay warp r2 sr22



A 84-beam array injector is very large (and costly)


Present surface ionization sources operates at low current density



Is there a better way for HIF injector system?

Beam Extraction Scaling Law

$$J_{CL} = \chi \frac{V^{\frac{3}{2}}}{d^2} \quad I_{CL} = \pi \chi \left(\frac{a}{d}\right)^2 V^{\frac{3}{2}}$$



- **Space-charge-limited flow in the extraction diode is governed by Child-Langmuir equation.**

where $\chi = (4\epsilon_0/9)(2q/M)^{1/2}$

with q and M being the charge and mass of the ions respectively, a is the aperture radius, d the diode length, and V is the extraction voltage.

- **V is limited by breakdown**

$$V \sim d \quad \text{for } d < 1 \text{ cm}$$

$$V \sim d^{0.5} \quad \text{for } d > 1 \text{ cm}$$


so large ion diode needs high V but produces low J .

- **Spherical aberration depends on the aspect ratio a/d (typically < 0.5) thus $I_{\max} \sim V^{3/2}$**


- **Conclusion: high current needs large V and d but results in low J , so the brightness is limited.**

High Current Density Option

- For effective LEBT, high brightness miniature beamlets (≈ 5 mA ea) can be accelerated to ≈ 1.2 MeV before they are merged into a single beam (≈ 1 ampere).
- Beamlets can be aimed and steered to rapidly match into an ESQ channel.
- Beamlet merging will introduce emittance growth, thus the miniature beamlets must be very bright.



The mini-beamlet approach can drastically reduce the size of a multiple beam injector



- The merging beamlet approach requires a high current density ion source. It can tolerate a higher intrinsic ion temperature, so there are more ion source options.
- Merging beamlets produces emittance growth.


The purpose of the Merging Beamlets Experiment was to develop a prototype injector for IRE

- **With the recent improvements in alumino-silicate sources, the single aperture source is probably still the optimum choice for single beam experiments**
- **Merging beamlets type injector is preferred for drivers with multiple beams**
- **We want to demonstrate that we have solutions to all the critical issues—high J, high gradient, tolerance etc.**
- **Study the physics of emittance growth from merging beamlets**
- **Benchmarking the simulation code will enable us to control beam profiles and halos.**

The Merging Beamlets Experimental Plan

- Built an RF-driven argon plasma source that can deliver the current density over a large extraction area
- Built a high voltage test stand—a 500 kV column is just about the maximum voltage that can run in air. Higher voltage will require a compressed-air enclosure and cost more.
- Develop and test high gradient insulators and vacuum gaps: aim at 35 kV/cm and 100 kV/cm respectively.
- Do the experiment in three phases—(1) test the source, extraction and Einzel lens on STS-100, (2) experiment with full gradient beamlets up to the first 400 kV of a full size injector, (3) experiment with a $\frac{1}{4}$ scaled voltage (but full size) merging beamlets at 400 kV.

Testing a multi-beamlet Ar⁺ RF-plasma source



RF-driven multi-cusp source inside ceramic insulator




500 μ s, 20kW, ~ 10 MHz Compact RF oscillator



Schematic Diagram of the RF-Source Experiment on STS-100



- Faraday cup to measure total beam current
- 2nd Faraday cup to measure Time of Flight (TOF)
- Double-slit scanner to measure projectional emittance
- Dipole plates to measure energy dispersion



Argon plasma source has produced beamlets near the required current density


- Current peaks when a beam fills the exit aperture.
- Optimum optics at perveance = $5.3 \text{ mA} / 80 \text{ kV}^{(3/2)}$

Obtained 3.9 mA from $d=0.25 \text{ cm}$ aperture
 $\Rightarrow 80 \text{ mA/cm}^2$.
(compare to 8.3 mA/cm^2 for hot-plate source)




Charge states measurements

Time of flight data for charge states identification




RF Plasma Source Charge State Fractions




020924Zi.xls

Emittance measurements


- Measured emittance showed $T_{\text{eff}} \approx 2$ eV, which is adequate for use in merging beamlets.
- Possible emittance reduction by improving beam optics.



matched optics





Overdense optics



8/19/02


Energy dispersion can result from charge exchange loss during acceleration

- Use an energy analyser to measure the beam energy spread
- Compare results as a function of gas pressure in the source chamber




4ms on gas valve ~ 2 mTorr chamber pressure

Charge Exchange Loss



CX effect was proportional to gas pressure

Gas density profile in the extraction gap, calculated using known CX cross-section. Compares to $1/R^2$ model.




Recent Results from Argon RF Plasma Source

Single Beamlet:

<u>Parameters</u>	<u>Results</u>	<u>Status</u>
Current density	100 mA/cm ² (5 mA)	met goal
Emittance	T _{eff} < 2 eV	met goal
Charge states	> 90% in Ar ⁺	met goal
Energy spread	< a few % beam suffers CX	met goal?

RF Source:



Multiple Beamlet:






Image on Kapton:




Results of the Einzel lens multi-beamlet experiment

Image on Kapton film


Einzel lens using flat electrodes
HGI held 35kV/cm



Grid parameters: 61 beamlets,
Pierce aperture diam. 2.21 mm
lens aperture diam. 4.0 mm
Spacing is 6.0 mm



45 kV, 5.5 kV RF
-20 kV Einzel lens




Kapton data:

**Measured radius =
2.25 mm at 10 mm
downstream.**







**Actual Einzel lens
voltage: $10 < V < 20$
due to lens drawing
current from the
power supply**

See 031117 presentation

Beamlet profile measured from a slit scanner




PBGUNs simulation was consistent with data




The Merging Beamlet Experiment has a conservative extractor design

Designed operating point for the merging beamlet experiment is ~ 58 mA



The Full-Gradient test will be installed this month

To demonstrate a full current density array, the vacuum gap voltage gradient (> 100 kV/cm) and check for interaction between beamlets.



We will use Faraday cup, and take images of the beamlets

The Final Phase will merge beamlets into an ESQ Channel

