

XE1201EVK Evaluation kit User's Guide

For further information please contact

XEMICS SA

Web: http://www.xemics.com/
E-mail: info@xemics.com/



Table of contents

TABLE OF CONTENTS	2
INTRODUCTION	3
KIT CONTENTS	3
SOFTWARE INSTALLATION	3
HARDWARE SETUP	
CONNECTION OF THE RF BOARD AND PC-XE1201 INTERFACE BOARD:	4
HOW TO USE THE PROGRAM FOR THE CONFIGURATION OF THE XE1201:	4
PARALLEL PORT ADDRESS SELECTION:	10
0378 HEX	
CHOICE OF THE 3-WIRE BUS CONNECTOR ON THE PC-XE1201 INTERFACE	:10
ANNEXES: HARDWARE DESCRIPTIONS:	11
A1: LAYOUT OF XE1201 EVALUATION BOARD V2.0:	



Introduction

Firstly, many thanks for using XEMICS products. The XE1201 Evaluation kit is a flexible support tool that allows you to extract and evaluate the XE1201 electrical performances with your application environment parameters. Influences and interactions between components and system conditions can be easily evaluated thanks to the tuning elements that have been especially inserted in the RF board (final applications can be built without any tuning component). All the XE1201 modes and functions behaviors are controlled via user-friendly-menu-driven software installed on a WINDOWS based PC. Configuration data and results are entered and read directly via the keyboard/mouse and the PC screen.

For customers who wish to start application designs based on this evaluation kit, detailed descriptions on PCB, components characteristics and layout implementation are also given.

In a typical utilization of the XE1201 Evaluation kit, minimum measurement tools are recommended as follows:

WINDOWS based PC (to program the XE1201 behaviors)

Spectrum analyzer (if one needs to visualize RF signals spectrum i.e. LO, RFOUT,..)

Oscilloscope to visualize the demodulated data and synchronized clock

RF generator

Pattern generator

Kit Contents

RF board with XE1201 circuit soldered with components and connectors; the XE1201 EVAL board.

Interface board; the PC-XE1201 INTERFACE board

Inter-board connector

XEMICS CD ROM including Application Example and CoolRIDE development tools

This user guide

Software installation

The application **XE1201_V3** is an executable program. It has been created with the software Labview, which works under Windows 3.x. It enables the configuration of the main characteristics for the XE1201 Low-Power UHF transceiver, via the 3-wire bus.

Click on Setup.exe and then follow the installation instructions on the screen.

Note: it is necessary to have PC screen set with 1024*768 pixels minimum and with small characters, in order to get the software working properly. In addition, <xel201v2.exe> needs the file <lvdevice.dll>; this file is automatically copied during the unzip operations.



Hardware Setup

Connection of the RF board and PC-XE1201 interface board:

The interface board is connected to the parallel port of the PC. The cable (not included in the kit) used for connection between the interface and the PC is a 25 pin RS-232-C, as described in the schematic. The 2 boards are interconnected via the 10 flat wires cable; one can either choose the K1 or K2 connection on the RF side.

The 2 boards (RF board and the PC-XE1201 interface board) must be both power-supplied by a VCC between 2.4 and 3.6 volts (same values for both boards). Power connections are made via pins (VDD_in, VSS in on the RF board and D VDD, D GND on the interface board).

How to use the program for the configuration of the XE1201:


Once the program is executed, the main screen shows five different menus that user has then to select. These are :

Bits Direct Programming menu Features Programming menu Frames sequence menu Parallel Port Configuration menu Parallel Port Control

The 5 menus are shown and described on the following page




Bits Direct Programming menu:



Here, one can program all the different bits of the three registers, via the data line SD. Click on the corresponding small circular buttons to select the desired option (activation at value 1; visible through a red dot). Once all the choices are validated, click on the Save button to store these settings. To activate the operations, the « Transmit Frame » button must be « pushed ».



Features Programming menu:




Here, one can program all the different characteristics of the transceiver, as described in the XE1201 data sheet.

The user enters the desired features; when all the data have been entered, selections are validated by a click on the Save button. Again, operations are executed after having pressed the « Transmit Frame » button.



Frames Sequence menu:



One can send four Lift sequences to the transceiver one after the other. The duration between sequences can be changed and set by the user. The figure shows the possible set-up of one of the Frame Configurations. Use the small circular buttons to activate the Clock Control, Chip Enable, Transmit/Receive Mode, Data inversion bit, Transmitter output amplifier enable and the Transfer data bit. On this screen, one can also set the EN (pin 1) and RXTX (pin 15). The output power is set using the sliding buttons.

Also enter the receiver data rate and the modulator frequency deviation here.


When all these fields have been filled in, click on the SAVE button. This will save all data for Frame 1.

To load a previously saved configuration, click on the load button and select the desired settings.

Now click on the Frame Sequence Menu button to return and set up the other Frames.




Parallel Port Configuration menu:



One can choose the parallel port of the PC, send data LPT1 or LPT2, or define own Port Address (in HEX). Click on the Validate button to activate the new address.



Parallel Port Control Menu:



One can control the static levels of the 3-wire bus, as well as the lines EN and RXTX. Click on the radio buttons to activate the following parameters:

- Bus data Input
- Bus Clock
- Bus Data Enable for K1 Connector
- Bus Data Enable for K2 Connector
- Chip enable
- Receiver / Transmitter Enable

Note: The screen refresh is performed when one clicks on the "enter" button (localized on the upper left corner of the screen), or when you send the data.



Parallel port address selection:

Every parallel port has an address identified in the PC. Correct address selection is required prior to sending data on the right parallel port. This address must be known in advance; it can be found in the PC documentation or through the BIOS program during any PC initialization phase.

Once known, the parallel port address can be entered from the Labview program via the menu

< Parallel Port Configuration >.

There are three different practical cases (linked to the user PC hardware):

1. The PC has only one parallel port named LPT1 and is addressed by :

0378 Hex

and the control port is defined by:

037A Hex. ("default mode" in the program)

2. The PC has two parallel ports and LPT1 is already used (usually a printer). One can use the second parallel port named LPT2 and it is addressed by:

0278 Hex

and its control port is defined by:

027A Hex

3. The PC has a special address for its parallel port. In this case, enter just its corresponding address in the program.

Choice of the 3-wire bus connector on the PC-XE1201 interface

The PC-XE1201 interface allows you to program two XE1201 evaluation RF boards via their connectors K1 and K2. The only thing to note is that you must program the different modes on one board with the CONTROL MODE BIT (A13) set to 1. This is because you can address only one of the two connectors via the pin 15 (RXTX) and pin 1 (EN).

More detailed description of the configuration bits and pins can be found in the XEMICS XE1201 Datasheet ref D88-011on pages 5 to 7.



Annexes: hardware descriptions:

A1: Layout of XE1201 Evaluation board V2.0:




Figure 1 : Top view of XE1201 evaluation board




Figure 2: bottom view of XE1201 evaluation board

Board adjustment:

Measurements on this board are performed with the Local frequency set to 433.92 MHz with the C10 trimmer capacitor (see figure 2). The Local Oscillator frequency can be seen in the RFOUT port, with a spectrum analyser or a high frequency meter.


Then the C5 trimmer capacitor (see figure 2) is set to obtain the maximum power level on RFOUT port (Typically with a new board Pout=-12 dBm). This adjustment is very important, because it has an influence on receiver and transmitter functionary mode.

In transmitter mode, the C16 trimmer capacitor (see figure 1) is set to obtain the maximum power performance (Typically –4 dBm) and a 50 . output load.


In receiver mode, the C12 trimmer capacitor (see figure 1) is adjusted to obtain the maximum voltage amplitude on IO and QO ports (Typically 1.5Vpp).



A2 : Layout of PC-XE1201 Interface board V2.0 :



PC-XE1201 Interface board – Top view



PC-XE1201 Interface board – Bottom view



User's Guide XE1201evk Evaluation Kit

ģ ဖ က N တ ဖ N 4 **Huber&Shuhner** Huber&Shuhner 3M, Arting or eq Coilcraft ou eq Coilcraft ou eq Coilcraft ou eq Coilcraft or eq Murata or eq Murata or eq Murata or eq Philips or eq Any one Xemics Origin Sarnix RFIM SMD 0805 SMD 0805 **SMD 0805 SMD 1206 SMD 0805** SMD 0805 SMD 0805 SMD 0805 **SMD 0805** TQFP32 SM-2 SMD SMD SMD SMD Form 433.92 MHz 70 mm x 50 1.4 to 3 pF 1.4 to 3 pF 1.4 to 3 pF 4.00 MHz 2 to 6 pF 12.5 mm 1 Mohm 1.5 pF 0.1 inch 20.5 mm 2.2 pF 100 uF 100 nF 2.2 pF 12 nH 18 nH 56 nH 22 nH 10 nF value NAP 0805 NPO Ni, +/-0.25pF, 50 v 0805 NPO Ni, +/-0.25pF, 50 v 0805 NPO Ni, +/-0.25pF, 50 v 0805 X7R Ni +/-10%, 50v DIN 41651 dipole female 0805 CS-120-X JBC 5% 0805 CS-180-X JBC 5% 0805 CS-560-XJBC 5% 0805 CS-220-XJBC 5% BOM - XEMICS Evaluation kit XE1201 : "XE1201 EVAL" SUBD barette double Any one (not critical) Any one (not critical) Any one (not critical) 21 SMA-50-3-15/111 85 SMC-50-0-1/111 TZC03Z030A110 TZC03Z060A110 TZC03Z030A110 TZC03Z030A110 References RO-2101A S0409745 E2 141 XE1201 E2 141 Semi-rigid coax cable for SMA connection Semi-rigid coax cable for SMA connection Connector 10 pins male double sides Decoupling capacitor VDD chemical Adjustment tank LNA trim-capacitor Adjustment tank PA trim-capacitor Adjustment tank LO trim-capacitor Adaptation matching RF-out cap Adjustment matching RF-out cap Pull-down resistors digital inputs Connector 10 pins dipole female Adaptation matching RF-in cap SAW resonator tuning inductor Decoupling capacitor ceramic SMC connectors (digital data) Components Matching RF-out inductor Coupling RF-in capacitor Matching RF-in inductor Decoupling capacitors Interboards flat cable RF SMA connectors Inductors for tanks Transceiver circuit SAW resonator Double sides XTAL Quartz VDD-in, VSS-in, IO, QO Test pins R3,R4,R5,R6,R7,R8 L1,L2,L3,L4,L5,L6 C3,C4,C6,C7,C11 TXD, RXD, CLKD KCC - DEC 98 RF in, RF out PCB board Conn 10p RF board SAW1 C10 C14 C16 C12 C17 5 ∞

14



User's Guide XE1201evk Evaluation Kit

Interface board						
U1, U2, U3	Opto-coupler	HP2731	ı	DIP8	윺	က
U4	Schmitt trigger inverter and buffers	MM74HC14N	ı	DIP14	Motorola	_
R1,R3,R5,R,R9,R11	Serial port interface resistors	Not critical	2.2 kOhms	1206	Philips or eq	9
R2,R4,R6,R8,R10,R12 Pull-up resistors	Pull-up resistors	Not critical	1 kOhms	1206	Philips or eq	9
C1, C3	Decoupling capacitor supplies, chemical	-	10 uF	Ref+10k	Philips on ed	7
C2,C4	Decoupling capacitor supplies, ceramic	1206 X7R 10	100 nF	K5K	Philips on ed	7
K1, K2	Connector 10 pins male double sides	SUBD barette double	0.1 inch		3M, Arting or eq	7
PCB board	Double sides		uu 02 x uug2			

©XEMICS, 2001

All rights reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner. The information presented in this document does not form part of any quotation or contract, nor is believed to be accurate and reliable and may be changed without notice. The publisher for any consequence of its use will accept no liability. Publication thereof does not convey nor imply any license under patent or other industrial or intellectual property