



Fire Protection Products

Droplet Characterization Using Direct Imaging Techniques

March 8, 2012

Suppression Detection Conference

Melissa Avila, Tyco Fire Protection Products

Co-authors and acknowledgements

- Zachary Magnone, Tyco Fire Protection Products
- Cooperation with Shanghai Jiao Tong University (SJTU) and Worcester Polytechnic Institute (WPI)
 - Hao “Jonathan” Bohan, SJTU, mechanical engineering
 - Chu “Stella” Yueshan, SJTU, mechanical engineering
 - Nicholas Fast, WPI, mechanical engineering
 - Rachel Winsten, WPI, civil engineering
 - Professor Nick Dembsey, WPI, fire protection engineering
- Chad Goyette, Tyco Fire Protection Products
- Dr. Patricia Beaulieu

Background

- Sprinkler Design

- Can streamline development with more in-depth knowledge of sprays

- Approval Agencies

- Similar testing is starting to be used for sprinkler approvals

- Work by others in the field


- Marshall, Sheppard, Drysdale, Brenton, Grant, etc.

- Fire Modeling

- Fire models are only as accurate as the information you provide them
- Characterization means more precise models in FDS

Background – Research Need

- How do sprinkler sprays really work?



- Need critical spray characteristics (relate to CFD inputs)
 - Spray geometry: 3D spatial distribution of water droplets
 - Energy transfer: droplet size, velocity, temperature, total flow rate, etc.

Our research questions


- How is sprinkler spray droplet size affected by:

- K-factor?
- Pressure?
- Spray angle?
- Measurement location in spray?



- What implications do our results have on how specific spray patterns are:


- Developed?
- Studied?
- Simulated?





Setup – Imaging System

Backlight diffuser

High-speed camera in waterproof housing with microscope lens




Calibration reticle mounting location



Calibration reticle used for image scaling

Setup – Translation Stage, Nozzle Rotation



- Nozzle mounted in automatic rotational indexer
- Can set rotation angle within 1° accuracy




- Camera assembly mounted on 3-axis linear translation stage
- Can set measurement coordinate to 1 mm accuracy within 1 m³ space

Setup – software and processing

- Raw shadow image


- Backlight causes bright background
- Droplets show up as dark shadows



Setup – software and processing

• Step 1: Apply smoothing filter


- Only inconsistencies in background brightness remain
- “Small” in-focus objects washed out



Setup – software and processing

• Step 2: Even out image intensity

- Subtract smooth image from original to normalize
 - Brightest = 100%
 - Darkest = 0%
- Droplets now show up as bright spots





Setup – software and processing

• Step 3: Find possible droplets

- Scan for areas brighter than a certain “global” threshold


- e.g. brighter than 40% total intensity range



Setup – software and processing

- **Step 4:** Filter out of focus droplets, measure size

- Review droplets using brightness thresholds (low 30%; high 70%)
- Compare relative areas
 - low area < 200%
 - high area = in focus
- Avg intensity = diameter



Testing – nozzle parameters

- Tyco D3 nozzle
- 132 tests in total
 - Every sensible combination of given parameters tested
 - Some repeated multiple times




- K-factor
 - 1.2K (K17.3)
 - 3.0K (K43.2)
- Spray angle
 - 65°
 - 180°



Testing – location parameters

- Nozzle rotation

- 0° (tine)
- 45° (slot)
- 90° (frame arms)




- Location in spray

- Under
- Middle
- Edge


- Distance from nozzle

- 1 ft (0.3m)
- 3 ft (0.9m)





Analysis – statistics definition

- **D10**: Mean diameter
- **D32**: Sauter Mean Diameter
 - Droplet with same surface area to volume ratio as total distribution
 - Useful when interested in evaporative cooling processes
- **D_v XX** (e.g. D_v 10, **D_v 50**, D_v 90): Volumetric Mean Diameter
 - The diameter below which the distribution contains XX percentage of the total flow
 - D_v 50 commonly used in CFD




Analysis – D_VXX sensitivity

- The cumulative volume distribution is very sensitive to droplet size.
 - Droplet volume \sim diameter³
 - One big droplet in image set can greatly skew D_VXX results



Analysis - statistical confidence


Accuracy of mean droplet diameter as a function of sample size





- Sample size is related to several parameters
 - Number of images
 - Density of measurable droplets per image
- In areas where the spray is disperse, more images are needed for proper statistical confidence

Results – Tine *(3.0K, 65° nozzle)*

20 PSI (1.4 Bar)



100 PSI (6.9 Bar)





1 ft (30.5 cm) radius



3 ft (91.5 cm) radius

Results – Tine (3.0K, 65° nozzle)

20 PSI (1.4 Bar)



100 PSI (6.9 Bar)





1 ft (30.5 cm) radius



3 ft (91.5 cm) radius

Results – Slot *(3.0K, 65° nozzle)*

20 PSI (1.4 Bar)



100 PSI (6.9 Bar)





1 ft (30.5 cm) radius



3 ft (91.5 cm) radius

Results – Slot (3.0K, 65° nozzle)

20 PSI (1.4 Bar)



100 PSI (6.9 Bar)




1 ft (30.5 cm) radius


3 ft (91.5 cm) radius

Results – orifice and spray angle *(20 psi, tine, 1 ft)*

65° Spray



180° Spray





$K = 1.2 \text{ gpm/psi}^{0.5}$



$K = 3.0 \text{ gpm/psi}^{0.5}$

Results – orifice and spray angle (20 psi, tine, 1 ft)

65° Spray



180° Spray



$K = 1.2 \text{ gpm/psi}^{0.5}$

$K = 3.0 \text{ gpm/psi}^{0.5}$

Conclusions

- Interactions with the frame arms cause relatively unpredictable results
 - Frame arm shadow at 90° spray angle
 - Directly underneath the nozzle
- Big drops tend to maintain trajectory, small droplets fill in gaps
 - Leads to full conical spray pattern of D3
- An increase in orifice size causes an increase in droplet size
 - Exception: frame shadow region
 - On the “edge” of the pattern (subjective definition)

Conclusions

- A wider spray angle produces smaller droplets
 - Thinner water sheet or more turbulence in spray? Or combination?
- There is a significant reduction in droplet size with an increase in pressure
 - Most significant reduction on tines
- Trends tend to match what is generally expected for variations in the chosen parameters
- Research is first step in continuation of spray characterization
 - Leads to streamlined development and better modeling capabilities

tyco

Fire Protection Products

Thank You