

Valence Technology, Inc.

Saphion[®] “Safety – Built In”

Alastair Johnston
EMEA Sales Director

Version: 15th November 2005

Valence Confidential

Corporate Overview

1989: Founded as a R&D company focused on Lithium-ion polymer technology
>600 issued and pending patents worldwide

2002: New management team from Dell, emphasis on Sales and Marketing

2003: Launched Saphion® Lithium-ion technology: First phosphate based battery chemistry on the market

2003: Launched first N-Charge™ Power System: Consumer product showcasing Saphion technology

2004: Launching K-Charge™ & U-Charge™ Power System: Large format energy storage system.

2004: Move into the cell pack markets with the IFR 18650 and P545 cells.

2004: Set up Valence owned powder plant and pack assembly factory in China


2004: Set up EMEA Sales Office, in Mallusk, N.Ireland

2006: Q1 Launch of U Charge high volume production

Valence Locations & Partners



Saphion Technology & Safety







In LiCoO₂: Co-O :
1.91Å
In Saphion P-O :
1.63 Å

Coordination and
location determine
bond distance and
strength



Tightly bound Oxygen
= safety






Raman Spectroscopy
stretching bands:


P-O : 1100 cm⁻¹

Co-O (LCO): 540 cm⁻¹

The P-O bond is stronger than the Co-O bond.




LiCoO₂ only




Whole cell

JES 146(9) Maleki et al. (Motorola): commercial LiCoO₂/graphite cell charged to 4.2V




LiCoO₂: large exotherm onset at 147°C results in cell safety problem

LiFePO₄ exotherm smaller and onset at much higher temperature




JES 148(3) Yamada et al.



Theoretical basis for safety advantages of phosphates

Phosphate Safety Comparison Video



<http://www.valence.com/SafetyVideo.asp>

Phosphate remains thermally stable under extreme abuse

Valence Confidential

Abuse Test

Abuse Requirements

UL1642 Third Edition (april 26, 1995), latest ammendment Jun 24, 1999

Test	Description	Saphion	LCO
Electrical Tests			
section 10 short curcuit test			
at room temp	connect terminals with wire <0.1mOhm	Pass	Pass
at 60C	connect terminals with wire <0.1mOhm	Pass	Pass
section 11a Abnormal Charge ^a	3 times recommended charge rate for 48hr minimum	Pass	Pass
Mechanical Tests			
section 12 crush	applied load of 13kN between flat plates	Pass	Pass
section 13 impact	drop 20lbs from 2 ft onto 5/8in diameter bar	Pass	Pass
section 14 shock	75G initial, 125-175G peak	Pass	Pass
section 15 vibration	ramp 10-55-10Hz in 90 minutes, 1.6mm excursion	Pass	Pass
Environmental Tests			
section 18a heating (hot box)	ramp to 150C, hold for 10 minutes	Pass	Pass
section 18b temperature cycling	ramp temp between -40 and 70C, 10X	Pass	Pass
section 18c altitude simulation	6hrs at 11.6kPa	Pass	Pass


Abuse Characterization

Test	Description	Saphion	LCO
Nail Penetration	JSBA standard	Pass	Fail
Round Bar Crush	slow crush to deform cell to induce short	Pass	Fail
Series/Parallel testing	simulate proposed battery design		
3 parallel Nail penetration	do safety devices in cell stop propagation	Pass	Fail
4 series NP on during charge	do safety devices in cell stop propagation	Pass	Fail
Hot Box (extended)	UL hot box with 150C hold	Pass	Fail
additional failsafe testing	application test to fail		

Round Bar Crush Test


Round Bar Crush Test - Oxide18650

S/N 162153 - Temperature vs. Voltage




Round Bar Crush Test - Phosphate18650

S/N 341387 - Temperature vs. Voltage




Overcharge Test

Overcharge Test - Oxide 18650
(2 Cells in Parallel supply set to 3.6A, 5.0V)



Overcharge Test - Phosphate 18650
(2 Cells in parallel supply set to 3.6A, 5.0V)




Excess Lithium in cobalt cells causes cell to continue to charge until “safety” device is activated. Despite this activation, the cell goes into thermal runaway 15 minutes later, reaching 760C.

Saphion® cells have NO excess lithium. After fully charging, the cell quickly reaches the 5V setpoint and the current tapers. The temperature reaches only 50C.

Nail Penetration Test


Nail Pen Test - Oxide 18650's

S/N 204040 - Temp. vs. Voltage, Current



Nail Pen Test - Phosphate 18650's

S/N 341488 - Temp. vs. Voltage, Current



Valence Products

Backup Power KWh - MWh




Motive Power 500 – 85000 Wh



Portable Power 50 – 300 Wh



OEMs and Pack Builders



Watt Hours

15

N-Charge™ Power System Family

A family of power sources to facilitate complete mobility

Sleek polymer models for thin and light notebooks

Modular and scaleable models for DTR and mainstream notebooks

Lightweight and compact for ultimate portability

Uses notebook PC adapter for recharging

Provides fast recharge and long cycle life



A lightweight, high-energy alternative to conventional lead acid batteries designed for wheelchairs, scooters, ebikes and more...

High performance, intelligent, reliable batteries

Safe, environmentally friendly, Saphion® Lithium-ion technology

Low maintenance, long cycle life = Lower lifetime costs!

Twice the runtime and 1/3 less weight compared to Lead Acid

Fits easily into established 12V and 24V platforms



***Kilowatt to megawatts of energy storage for the utility,
network and vehicular markets***

High performance, intelligent, reliable batteries

The safest Lithium-ion technology available

Flexible form factor

Less volume and lower weight

Fast recharge time, excellent cycle life



Valence Technology & Segway





Max Dimensions (l x w x h) mm	360 x 150 x 82
Weight	5.5 kgs
Cell Used	Valence Saphion IFR 18650e
Number of cells per pack	92
Pack Capacity	400 Wh
Continuous Current	16 Amps *
Peak Current	30 amps

* Rated value, however 30A continuous has been tested with no ill effects.