



Application of Master Sintering Curve Theory To Predict And Control Nano-Crystalline Ceramic Sintering

Kevin G. Ewsuk, Christopher B. DiAntonio,
Donald T. Ellerby, and Denise N. Bencoe
Sandia National Laboratories
Albuquerque, NM 87185-1340

Sintering 2003

3rd Intl Conf on the Science, Technology, & Applications of Sintering
September 14-17, 2003
University Park, PA

*Sandia National Laboratories is a multi-program laboratory operated
by Sandia Corporation, a Lockheed Martin Company for the US
Department of Energy under contract No. DE-AC04-94AL8500*



A Science-Based Approach Can Be Used To Improve Process Control

The Problem: Processing defects impact manufacturing cost, and component performance and reliability


Technical Solution:

Apply fundamental scientific understanding to design reproducible processes to manufacture high performance and reliability ceramics

- characterization
- predictive modeling

Science-Based Processing

Form → Sinter





Form → Sinter → Grind (\$\$'s)

Traditional Processing

Characterization & Modeling Are Advancing Sintering Science


Bilayer Sintering Experiment



Characterization

- Shrinkage (non-contact video)
- Shape Deformation (in-situ)
- Constitutive behavior
- Pore Characteristics (NMRI)

Bilayer Sintering Simulation




Modeling


- Master Sintering Curve Theory
- 3D FE Modeling
- Microstructure Modeling

Validation Sintering Model Validation

	Experiment	Model	Δ
L 8.049 mm	6.7 mm	6.431	4.0%
H_u 1.323 mm	2.15 mm	1.001	1.2%
H_l 1.308 mm		1.123	
W 4.790 mm	3.89	3.888	0.1%



Densification Can Be Predicted And Controlled With The MSC




The MSC Offers Processing, Microstructure, & Property Control

Sintering Time
And Temperature


$$\int_0^t \frac{1}{T} \exp\left(-\frac{Q}{RT}\right) dt \equiv \rho \equiv \frac{k}{\gamma\Omega D_0} \int_{\rho_0}^{\rho} \frac{(G(\rho))^n}{3\rho\Gamma(\rho)} d\rho$$

Microstructure &
Materials Properties




Two Different ZnO Ceramic Powders Were Examined

Nano-Crystalline ZnO



48 nm average particle size
30 m²/g specific surface area

Micro-Crystalline ZnO



790 nm average particle size
3.2 m²/g specific surface area



The ZnO Powders Were Granulated, Pressed, And Sintered

Nano-Crystalline ZnO

Pan Granulated

3 Wt% 50:50 PVA:PEG

Ground and Sieved

<150 μm

Dry Pressed (6 x 6mm dia pellets)

140 MPa uniaxial
210 MPa Isostatic

Binder Burned out

RT - 600°C in Air

Sintered

5, 10, 20, or 30°C/min to 1550°C
Netzsch Dilatometer 402ED

Micro-Crystalline ZnO

Spray Granulated (CBM)

3 Wt% 50:50 PVA:PEG

Sieved

>45 μm to <150 μm

Dry Pressed (5 x 6 x 50 mm bars)

18 MPa uniaxial
210 MPa Isostatic

Binder Burned out

RT - 600°C in Air

Sintered (4 x 5 x 10 mm bars)

5, 10, 20, or 30°C/min to 1550°C
Netzsch Dilatometer 402



62% TD ZnO Powder Compacts Sintered To Greater Than 91% TD

Nano-Crystalline ZnO

Compact Density (w/o binder)

62.6 ± 0.0% TD

Sintered Density

99.2 ± 0.2% TD

Micro-Crystalline ZnO

Compact Density (w/o binder)

62.2 ± 0.0% TD


Sintered Density

91.3 ± 0.3% TD


Sintered Density Was Determined From Measured Linear Shrinkage

Nano-Crystalline ZnO

$$\frac{dL}{Ldt} = \frac{d\rho}{3\rho dt}$$



Nano-Crystalline ZnO Sinters Faster Than Micro-Crystalline ZnO



A Consistent Activation Energy (Q) Was Determined For ZnO Sintering

*Nano-Crystalline ZnO


Micro-Crystalline ZnO

Q for Densification (65-90%TD)

Q for Densification (65-90%TD)

268 ± 25 kJ/mole


296 ± 21 kJ/mole




$Q = \text{slope} * R$

$Q = 276 \pm 13$ kJ/mole Gupta & Coble - J Am Ceram Soc 1968

A Master Sintering Curve Was Constructed For Micro-Crystalline ZnO




A Master Sintering Curve Was Constructed For Nano-Crystalline ZnO




Master Sintering Curve Predictions Were Tested & Validated

Nano-Crystalline ZnO Sintering



A Slower Heating Rate May Alter Sintering And The MSC



- A-16 Al_2O_3 Sshows seviation from the MSC at $1^\circ\text{C}/\text{min}$.

- **Surface diffusion** results in coarsening at the expense of densification.

MSC Theory Was Applied To Nano-Crystalline ZnO Sintering

Nano-Crystalline ZnO Sintering

48 nm average particle size

30 m²/g specific surface area

62.6% TD compacts sintered to 99.2% TD

$Q = 268 \pm 25$ kJ/mole

A master sintering curve (MSC) was constructed

