Field-induced Characteristics of nanoparticles with Applications to Thin Film Displays

Weijia Wen

Department of Physics and Institute of Nano Science and Technology The Hong Kong University of Science and Technology HONG KONG





Outline:

Introduction to Electrorheological effect

Display from electrorheological suspension

Paperlike thermochromic display



Electrorheological effect

What is ER suspension ?





ER fluid is a kind of colloid consisting of dielectric particles suspended in a nonconducting liquid. It can change from liquid state to solid state abruptly.

Dielectric particles





Electrorheological forces





Attraction



Structural evolution of ER suspension under an external electric field











Display from electrorheological suspension

Display principle





Nanoparticles used for display





Illustration of the mechanism for the storage mode display







Top-views of field-induced patterns formed by nanoparticles





НКИЗТ

Pattern formation with different electrode configurations



Electric field is applied across the top and bottom electrodes



Electric field formed by the planar electrodes



Optical transmission characteristics of nanoparticle-based suspension at different field strengths





Images viewed through the display panel Viewed through **HKUST** the display panel а Grad obje proj C: sepa bring high **Display panel** with Without electric field b Original color panel With electric field С



Display panels formed with different backgrounds





The drawback of nanoparticle-based ER display presented above is the classic tendency of particles to agglomerate together irreversibly, the flocculation effect.



Results: particle shapes by TEM





Dyed particles





Gold shell

Dispersion in oil 2As 2C







Paperlike thermochromic display

Polydimethylsioxane (PDMS)-based conducting composite





SEM pictures of the cured conductive composite and powders: (a) Ag+PDMS (84wt%); (b) C+PDMS 28wt%

Electrode fabricated with PDMS/Carbon conducting composite





Process flow chart illustrating the patterning of conductive PDMS by soft lithography. (a) Micro-patterning of the conductive PDMS, (b) –(d) SEM pictures showing the various fabricated conductive patterns.

Electrode fabricated with PDMS/Silver conducting composite





Micro-heater from PDMS conducting composite





Schematic illustration of the micro-heater. The three-dimensional helicalpatterned structure is made from silver micro-particles-PDMS composite. Inset: a SEM picture of the micro-heater whose line width is 25 Temperature of the micro-heater's central heating part plotted as a function of the input voltage.





The two insets are IR pictures showing the thermal distributions at specific applied voltages. The bright spot on the right panel is a high temperature region with a temperature of ~250 $^{\circ}$ C



Time dependent temperature variations of the micro-heater





The right inset tabulates the temperature rise and decay times, defined at points where the temperature is 80% of the stabilized value.







(b) shows the infrared images of the digits are displayed, demonstrating the ease and flexibility of operations.

Fabrication of thermochromic composite





liquid-like composite

Fabrication processing for paperlike thermochromic display





Structure of thermochromic thin film display









Display panel with flexible character

Image appears when power turns on

The display is wrapped on a column





- (a) shows the display film when no input signal is applied,
- (b) shows the logo image to be correctly displayed when a voltage heating pulse train is applied

Display degree plotted as a function of applied voltage





The five curves on the left correspond to a step function voltage of various height, while the one on the right corresponds to what happens after the voltage is turned off. The insets show the logo images at various display degrees. The image in inset C is blurred due to overheating

Power consumption of the display under different *t*/*T* ratios of the heating pulse train.





The duty cycle is fixed at 50Hz. The table gives the best voltage values (for achieving an accurate image) associated with the various values of t/T ratio.



