




BASIC MICRO

TECHNOLOGY AT WORK

**B0262 - BasicATOM Lab Board
Data Sheet**

Feature Overview:

- Includes 16x2 LCD Display
- Solderless Prototyping Board
- 2.1mm Power Connector
- USB Connector Using FTDI
- All ATOM Module Compatible
- Basic Stamp Compatible
- Power Status LED
- 4 LED Indicator Lights
- 4 Tactile Switches
- 1 User Potentiometer
- Built-In Speaker
- 16 Servo or I/O Connectors

**Basic Description**

The BasicATOM Lab Board is designed to be a full experimentation center for BasicATOM, BasicATOM Pro or Basic Stamp modules. The 16x2 LCD allows users to easily integrate display technology with their BASIC code. The Lab Board includes a solderless breadboard area for the construction of auxiliary circuitry, as well as built-in tactile buttons, LED indicators, Potentiometer and a bank of headers capable of controlling up to 16 servos.


USB and RS232

Programming the installed module can be done by using the on board USB connection or DB9 RS232 connector.

Compatible

The BasicATOM Lab Board is compatible with all BasicATOM, BasicATOM Pro and Basic Stamp 2 modules.

Hardware Overview:



A: 2.1mm Power Jack Center Positive, 6 to 9VDC

B: DB9 RS232 connector. RS232 and USB connected to module SIN and SOUT pins. (Remove jumpers at JP7 to use RS232 (DB9)).

C: USB connector. (FTDI) USB chip. RS232 and USB connected to module SIN and SOUT pins.

D: 14, 24, 28, 40 Pin BasicATOM or BasicATOM Pro module socket.

E: 16x2 Character LCD display. HD44780 based.

F: LCD contrast control potentiometer and master RESET button for BasicATOM or BasicATOM Pro.

G: 4 LEDs, 4 Tactile Switches, 1 Potentiometer. User accessible though header shown in I.

H: Solderless Breadboard.

I: Peripherals header to access LED 1-4, Tactile Switches 1-4, Potentiometer and Piezo Speaker.

J: Servo or I/O male headers. Male headers can be connected directly to a Servo motor or used for GPIO (General Purpose I/O). **Note:** Power to headers can be set to regulated 5vdc or VIN by Servo Pwr header (VIN is direct power in from 2.1mm connector). Headers are connected to P0 - P15 from top of board to bottom.

K: Piezo speaker.


L: FTDI. JP7 jumpers can be removed to disconnect the FTDI from circuit. Or can be used to access the FTDI for your own configuration using jumper wires.

NOTE:

Remove jumpers at JP7 to use RS232 (DB9).

JP6 Jumpers

The jumpers on JP6 should be installed if using USB to program the ATOM module in the on board socket. To program the ATOM modules using RS232 (DB9) the JP7 jumpers should be removed. You must remove any cables connected to the DB9 connector when using USB to program the ATOM.



USB Access


The on board USB can be used in your circuit if using the RS232 (DB9) connector to program the ATOM module. TXD, RXD and RTS are available on JP7. Using male to female jumpers, which are included in most Basic Micro development kits JP7 USB side pins 1,3 and 5 can be jumpered to the solderless bread board area.

RS232

The on board RS232 (DB9) connector is hard wired to the ATOM modules SIN, SOUT and ATN pins. You must remove any cables connected to the DB9 connector when using the USB to program the ATOM module.

Lab Board Demo

The LCD is pre-wired for easy setup. Control lines (RS, E and R/W) are tied to P0 - P2. The LCD is setup in 4bit mode. Data lines (DB4 - DB7) are tied to P4 - P7. The demo program will print "Hello World" to the LCD screen. You can adjust the potentiometer at R14 and the analog value will display on the screen. Pressing the tactile switch will illuminate a LED. Wire the Lab Board as shown below.



BasicATOM 40 Demo

Coding for each module is slightly different and demo programs are provided for each module with comments. Wire the Lab Board as shown with a BasicATOM 40 installed. You can download code from download section of the Basicmicro.com website.

```
; %CONFIG% BASICATOM40 $1312d00 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0 $0
; Atom28 P16:P19 are on LabBoard AX0:AX3

; Wiring
; AX3 to POT
; AX0 to led1
; P15 to led2
; P14 to led3
; P13 to led4
; p12 to button 1
; p11 to button 2
; p10 to buzzer/speaker
; p9 to button3
; p8 to button4

; Setup LCD
lcdinit p0\p1\p2,outb
lcdwrite p0\p1\p2,outb,[CLEARLCD,HOMELCD,SCR,TWOLINE,"Hello World"]

; Set pins to known state
low AX0
low p15
low p14
low p13
high p3

; Setup 32 bit variable
temp var long
cnt var long
cnt=0

; Start program main loop
main
    ; Read analog pin and display value to LCD
    cnt=cnt+1
    adin AX3,temp
    lcdwrite p0\p1\p2,outb,[SCRRAM+40,dec4 temp\4]

    ; Send analog reading to terminal window set to 9600 baud
    serout S_OUT,i9600,[dec temp,13]

    ; Copy state of button to LED on/off
    out28=in12    ; P28 is AX0
    out15=in11
    out14=in9
    out13=in8

    ; If button 4 is pressed make sound with buzzer
    out3=in8
    if(in8)then
        low p10
    else
        high p10
    endif

    ; Return to main loop
    goto main
```

BasicATOM Pro 28 Demo

The following code is setup to run with the BasicATOM Pro 28-M. You can download this code from the Basicmicro.com website.

```
;AtomPro28: P16:P19 are on AX0:AX3 of the Lab Board

;Wiring
;P19/AX3 to POT
;P16/AX0 to LED1
;P15 to LED2
;P14 to LED3
;P13 to LED4
;P12 to Button1
;P11 to Button2
;P10 to Buzzer/Speaker
;P9 to Button3
;P8 to Button4

;Setup LCD
lcdinit p0\p1\p7\p6\p5\p4,p2
lcdwrite p0\p1\p7\p6\p5\p4,p2,[LCDCLEAR,LCDHOME,SCR,TWOLINE,"Hello World"]

;Set pins to known state
low p16
low p15
low p14
low p13
high p3

;Setup 32 bit variable
temp var long
cnt var long
cnt=0

;Start main program loop
main
    ;Read analog pin and display value to LCD
    cnt=cnt+1
    adin p19,temp
    lcdwrite p0\p1\p7\p6\p5\p4,p2,[SCRRAM+40,dec4 temp\4]

    ;Send analog reading to terminal window set to 9600 baud
    serout S_OUT,i9600,[dec temp,13]

    ;Copy state of button to LED on/off
    out16=in12
    out15=in11
    out14=in9
    out13=in8

    ; If button 4 is pressed stop speaker sound
    ;hpwm command adjust speaker frequency based on
    ;value of POT
    out3=in8
    if(in8)then
        hpwm p10,temp*8,temp*4
    else
        hpwm p10,10000,0

    endif



















    ; Return to main loop
    goto main
```

Driver Installation

You can download the FTDI customized driver from <http://www.basicmicro.com>. During installation you will be installing 2 parts. One is the device and the second is the port its self. You are required to click "Continue Anyway" during both installations.

Electrical Characteristics

Characteristic	Rating	Min	Max
VCC Input	VDC	6	12
Current Draw	mA	30	1000
I/O Voltages	VDC	0	5
Tempature Range	C	-40	+125



Title			
BasicATOM Lab Board Rev B (c) 2009			
Size	Number	Revision	
B	B		
Date:	1/29/2009	Sheet of	
File: E:\PCB\Designs\ATOM\lab board Rev D Sch 0209m Bv			

Warranty

Basic Micro warrants its products against defects in material and workmanship for a period of 90 days. If a defect is discovered, Basic Micro will, at our discretion repair, replace, or refund the purchase price of the product in question. Contact us at support@basicmicro.com. No returns will be accepted without the proper authorization.

Copyrights and Trademarks

Copyright© 2009 by Basic Micro, Inc. All rights reserved. PICmicro® is a trademark of Microchip Technology, Inc. The Basic Atom and Basic Micro are registered trademarks of Basic Micro Inc. Other trademarks mentioned are registered trademarks of their respective holders.

Disclaimer

Basic Micro cannot be held responsible for any incidental, or consequential damages resulting from use of products manufactured or sold by Basic Micro or its distributors. No products from Basic Micro should be used in any medical devices and/or medical situations. No product should be used in a life support situation.

Contacts

Email: sales@basicmicro.com
Tech support: support@basicmicro.com
Web: <http://www.basicmicro.com>

Discussion List

A web based discussion board is maintained at <http://www.basicmicro.com>.

Technical Support

Technical support is made available by sending an email to support@basicmicro.com. All email will be answered within 48 hours. All general syntax and programming questions, unless deemed to be a software issue, will be referred to the on-line discussion forums.