

# Dissolvine® chelates The versatile solution to metal ion control

Metal ions have a powerful influence on chemical processes as well as on the performance of many products. A wide range of problems associated with metal ions can be solved using Dissolvine® chelates from improving the efficiency of pulp bleaching to cleaning dairies, from increasing crop quality and yields to preserving food quality.













For more info and up to date addresses please check our websites:

www.dissolvine.com www.dissolvinegl.com www.akzonobel.com/micronutrients www.ferrazone.com



## How do Dissolvine® chelates work?

Dissolvine® is the AkzoNobel brand name for products known as chelates, chemicals that control the reactivity of metal ions.

As the word 'chele' implies (it's Greek for crab's claw), chelates seize a metal ion and control it, making it very difficult for another substance to liberate it. Dissolvine® chelates form strong, water-soluble complexes that prevent undesirable precipitation, dissolve scale deposits and optimize oxidation processes. Our Dissolvine® chelate product range includes chelating agents that bind and control metal ions, as well as metal chelates

that introduce the right form of metal ions into a product or process.

For example, metal cations like calcium, magnesium and barium can form low watersoluble salts with carbonates, sulfates and phosphates that precipitate out of aqueous systems. These precipitates form scales that are extremely difficult to remove and reduce the efficiency of boilers and chemical processing equipment. When Dissolvine® chelating agents are added to these systems, they complex the metal ions into a water-soluble form and dissolve the scale deposit so that it is removed in the cleaning process.













# Where can Dissolvine® chelates make a difference?

In virtually any industrial process which uses water, Dissolvine® chelates can add or remove metals in a controlled way.

### Removing unwanted metal ions

In many applications chelates are used to remove or alter the properties of metals that are detrimental to the process, for instance, reducing water hardness or removing scales. Examples include:

### Preventing precipitation, removing scale, or dissolving metals

- agricultural applications
- mining processes
- oil and gas production and processing

### Controlling metal catalyzed reactions

- building applications
- food and feed products
- personal care products
- polymer production
- pulp and paper production

### Reducing the toxic effects of metals

- fish hatchery processes
- pharmaceutical products

### Preventing precipitation and controlling metal catalyzed reactions

- cleaners and detergents
- electronics
- industrial cleaning
- metal plating
- photography
- textile processing

### Introducing metal ions

At other times you may want to introduce metal ions into an application in just the right 'form'. For instance:

### Oxidizing or reduction agent

- H<sub>2</sub>S gas sweetening
- photography
- NOx removal

### Transforming trace metals into water soluble complexes

- agriculture
- food fortification

Wherever you use a Dissolvine® chelate, it can significantly improve the efficiency and cost effectiveness of your process.



Dissolvine® chelates
For every application

The Dissolvine® chelates product line is the most extensive there is, with chelates available for many industrial processes. The primary applications are described below, but please contact our representatives for more information related to your specific needs.

#### **Agriculture**

Every crop needs several kinds of nutrients. Dissolvine® metal chelates act as carriers for micronutrients, ensuring that plants get the trace elements they need, regardless of environmental conditions. Products can be applied on or in the soil or can be sprayed onto plants. High-purity metal chelates are available to meet the rigorous demands of soil-less culture (hydroponics). Chelates can be used to soften water in order to prevent or dissolve scale in drip irrigation. They can also be applied in combination with pesticides. A special brochure on AkzoNobel micronutrients is available from our representatives. See also www.akzonobel.com/micronutrients

#### **Building & Construction**

Rapid setting of Portland cement and gypsum can be a problem. For example, in modern gypsum board mills the proper balance of multiple admixtures is essential for optimal operation. Dissolvine® chelates are applied as synthetic retarding agents, giving more flexibility to the production process.

### Cleaning and detergents

Dissolvine® chelating agents deactivate the unwanted heavy metal ions that are often introduced through raw materials in the manufacture of soap and of detergents that contain peroxides like hydrogenperoxide, percarbonates and perborates. Chelates boost the effectiveness of biocides and can be used efficiently to soften the water and act as (co-)builder in detergents.

### Industrial Cleaning

Metal salts can cause scaling problems in boilers, heat exchangers and other water circulation systems found in the power, brewing, sugar and dairy industries. Dissolvine® chelating agents form stable, water-soluble metal complexes with all potentially harmful metal ions, dissolving existing scale formations and preventing new scales from forming.

### Feed additives

Trace metal elements are important for the health and growth of animals. According to US law, disodium EDTA (Dissolvine® NA2-P) can be used to solubilize trace minerals in aqueous solutions, which are then added to animal feeds (US: 21CFR, sec 573.360).

Dissolvine® chelates are also used as preservatives in animal feed.















### Food fortification

Iron is an essential element for good health. Ferrazone® (food-grade sodium iron EDTA), is a highly effective iron source in food fortification to combat iron deficiency anemia and is produced in compliance with HACCP and FSSC 22000 regulations. Sodium iron EDTA is recommended by the World Health Organization as the preferred iron fortificant for wheat and maize flour. Furthermore Ferrazone® can be used in drinks fully free of any metallic taste and has been accepted for food use in nearly all countries worldwide. Please contact us for the current regulatory status of Ferrazone®. For more information, see: www.ferrazone.com

#### Food preservation

Heavy metal ions can catalyze the degradation of vegetable oils and fats that can make food and beverages rancid. Dissolvine® chelates (E-CA-10 and NA2-P) deactivate these undesirable metal ions, preserving the quality of the food and increasing shelf life. Both Dissolvine® products are produced in compliance with HACCP regulations. Please ask for our special food application brochure.

#### Gas sweetening

In commercially available processes, ferric ions oxidize H<sub>2</sub>S to elemental sulfur. Dissolvine® chelating agents activate the ferric ions and prevent them from precipitating. In DeNOx processes Dissolvine® metal chelates enable nitrous oxide to dissolve in water, making it available for chemical and bacterial reduction to nitrogen.

### Metal plating and electronics

Solutions containing copper ions are used in the production of printed circuit boards. Copper and nickel are used in plating of automotive parts. Dissolvine® chelates fulfill several functions: as a metal carrier, as a stabilizer of process baths and for neutralizing trace impurities.

#### Oil industry

Dissolvine® chelating agents are widely used in various oilfield applications like stimulation, completion, cementing and enhanced oil recovery to re-dissolve scales such as SrSO<sub>4</sub>, BaSO<sub>4</sub> and CaCO<sub>3</sub>. Furthermore, they can prevent iron precipitation during acidizing and fracturing processes.

#### Personal care

Heavy metal ions can catalyze the degradation of ingredients used in personal care products. Dissolvine® chelating agents deactivate the undesirable metal ions, maintaining quality and improving shelf life.

#### Pharma

Some of our products are qualified for use in the production of pharmaceuticals. Please check with our representatives for specific details.

#### Photography

Chelated ferric ions are used to oxidize metallic silver into soluble silver ions, which can then be washed from films. Dissolvine® chelating agents act as carriers of these ferric ions and play an essential role in accelerating and fine-tuning the reactivity of these ferric ions with metallic silver.

### Polymer production

Ferric (Fe³+) and ferrous (Fe²+) ions play a key role in initiating emulsion polymerization processes to produce SBR and ABS. Dissolvine® chelating agents act as carriers of ferric ions. They also conserve natural rubber lattices by deactivating metal ion impurities that can catalyze decomposition.

### **Printing ink**

Metal ions can cause the formation of insoluble resin soaps in water thinned inks. For example, in offset printing, the formation of polyvalent metal soaps may cause unwanted discoloration. Dissolvine® chelating agents are used to overcome these problems, resulting in clear and color-stable inks.

#### Pulp and paper

Metal ions catalyze the decomposition of bleaching agents (e.g. peroxide, ozone and hydrosulfite) and can lead to brightness reversion of pulp and paper. Dissolvine® chelating agents are used to remove and deactivate metal ions.

### Textiles

During the scouring and bleaching of textile fibers, Dissolvine® chelating agents remove and deactivate metal ions that would otherwise catalyze the decomposition of the peroxide bleaching agent. They also improve the performance of dye baths, where metal ions like Ca and Mg inhibit dye penetrating the fiber.







### Dissolvine® chelates The right chemistry

Dissolvine® chelating agents combine amine and carboxylic acid chemistry in one molecule. This powerful chemical combination yields aminopolycarboxylates (APCs), which form more stable complexes with metal ions compared to other chelating agents.

In fact, they are the most commonly used chelates, because of their cost effectiveness and versatility. Compared to other less effective chelating agents, the Dissolvine® chelates are stable over a wider range of temperatures and pH values, have a stronger affinity for metals and are significantly more efficient. They also have good water solubility and are inert to most chemicals. Moreover, several products in the Dissolvine® chelate range are readily biodegradable as measured using the Closed Bottle Test (OECD 301D).

Dissolvine® chelates have been designed and fine-tuned to meet the needs of our customers. Our product range is extensive, including chelating agents and metal chelates, in various salt forms, in different purities and in both liquid and solid forms. What is more, we continuously develop new products to better meet requirements in specific application areas. Thanks to our concerted research and development efforts, product quality and consistency are ensured.



### The world of Dissolvine® chelates

We supply the following Dissolvine® chelates: EDTA, GLDA, DTPA, HEDTA, NTA, PDTA, EDG and Glucoheptonate. EDTA is generally the preferred choice, but specific applications may require other chelating agents. Common specific properties of these molecules:

**EDTA** 

The most widely used, strong, cost effective and general purpose chelating agent.

**GLDA** 

The latest, strong and green chelate in our product range. A safe and readily biodegradable chelating agent, that can be used as alternative for NTA, EDTA, phosphates and phosphonates, especially in cleaning applications. It has a high solubility over a wide pH range. The major part of the molecule originates from a natural sustainable source.

**DTPA** 

Recommended when a stronger chelating agent is needed, such as during peroxide bleaching of pulp. It remains more effective under oxidizing conditions. It is also especially suitable for descaling in oilfield applications.

**HEDTA** 

A chelating agent with similar efficacy to EDTA. Particularly useful when high solubility is needed at low pH and for stabilizing iron ions at high pH.

A readily biodegradable chelating agent that is not as strong as EDTA but used widely in cleaning processes and detergent applications. It has a higher temperature stability.

**EDG** 

A readily biodegradable chelating agent, effective when a relatively weak chelating agent can be used.

**PDTA** 

A chelating agent especially developed for the photo-finishing process. It is very effective in the bleaching of photographic films and paper, due to the favorable redox-potentials it imparts to iron.

Glucoheptonate

A biodegradable chelating agent based on a carbohydrate. It is generally weaker than the aminopolycarboxylates (APCs) mentioned above. However, it exhibits an exceptional chelating ability for iron and other transition metal ions at high pH. As with GLDA, the major part of the molecule originates from a natural sustainable source.

### **Choosing the right** Dissolvine® chelate

Dissolvine® chelates can be used directly in chemical processes or formulated as water-soluble products. We can discuss your process to establish which product should be used. The type and quantity of metal ions as well as the anions involved in the process need to be considered. An important factor is the strength of the complex formed between the metal ion and the chelating agent. This determines whether the complex will be formed in the presence of competing anions. The stability or equilibrium constant (K), expressed as log K, has been determined for many metals and chelating agents. The higher the log K values, the more tightly the metal ion will be bound to the chelating agent and the more likely that the complex will be formed.


#### Stability constants (log K values)1

Metal ion	EDTA	GLDA	DTPA	HEDTA	NTA	EDG	PDTA
Al³+	16.4	12.2*	18.6	14.4	11.4	7.7	16.3
Ba <sup>2+</sup>	7.9	3.5	8.7	6.2	4.8	3.4	3.9
Ca <sup>2+</sup>	10.7	5.9	10.8	8.1	6.4	4.7	7.2
Cd <sup>2+</sup>	16.5	9.1*	19.0	13.7	9.8	7.4	13.8
Co <sup>2+</sup>	16.5	10.0*	18.8	14.5	10.4	8.0	15.5
Cu <sup>2+</sup>	18.8	13.1	21.2	17.4	13.0	11.8	18.8
Fe <sup>2+</sup>	14.3	8.7*	16.2	12.2	8.9	6.8	13.4
Fe³+	25.1	11.7*	28.0	19.7	15.9	11.6	21.6
Hg²+	21.5	14.3	26.4	20.1	14.3	5.5	19.8
Mg <sup>2+</sup>	8.8	5.2	9.3	7.0	5.5	3.4	6.2
Mn <sup>2+</sup>	13.9	7.6*	15.2	11.1	7.5	5.5	10.0
Ni <sup>2+</sup>	18.4	10.9*	20.1	17.1	11.5	9.3	18.2
Pb <sup>2+</sup>	18.0	10.5*	18.8	15.6	11.5	9.4	13.6
Sr <sup>2+</sup>	8.7	4.1	9.8	6.8	5.0	3.8	5.2
Zn²+	16.5	10.0*	18.2	14.6	10.7	8.4	15.2

<sup>1</sup>A.E. Martell, R.M. Smith, NIST Critically selected stability constants of metal complexes (NIST standard reference database 46, Version 7.0, 2003)

### **Active pH range**

The pH of the system and the oxidizing nature of the environment can affect the stability and effectiveness of the chelating system. For each metal complex there is an optimum pH and an active pH range in which the metal complex is stable.



Calculated for a hydroxide environment in demineralized water at 0.1 mol / l. Lower pH limit: the conditional stability constant  $\log K' \ge 3$ . Upper pH limit is based on the precipitation

At upper pH limit; fraction chelated ≥ 95%. For the Fe chelates deviations are possible in the calculation of the upper pH limit.

\*= determined by measurement

The quantity of chelating agent needed depends on the concentration of metal ion to be chelated and the type of chelating agent used. Dissolvine® chelating agents form a complex with a metal ion generally on an equimolecular basis (which means the higher the molecular weight of the chelating agent, the higher the quantity of chelating agent required to chelate the metal ion). See chelation equivalents in the product overview table.

<sup>\*</sup> As determined by AkzoNobel Stability Constants: as determined at an ionic strength of 0.1M and at a temperature of 25°C, or if not available at 20°C.

### **EDTA** chelating agents

More products are available. Please contact your local sales office.

 $^1$  poured bulk density for solids, note: 1000 kg / m³ = 8.35 lb / gal [for liquids] and 62.43 lb / ft³ [for solids]  $^2$  as 1% solution or saturated solution if solubility is < 1%

Metals to control	High acidity	n acidity Low acidity Low alkali		High alkalinity			
Divalent metals		EDTA, GLDA,	DTPA, HEDTA				
Water hardness	No chelating agent applicable	GLDA, HEDTA	EDTA, GLDA, DTPA	, NTA, EDG, HEDTA			
Iron control	EDTA, GLDA,	TA, GLDA, DTPA, PDTA HEDTA Glucohepto					

STRUCTURE AND CHEMICAL NAME	DIS-	CHEMICAL	CAS REGISTRY	PHYSICAL	MOLECULAR	DENSITY	(approx.)	TYPICAL pH		Calculated w	FION EQUIVA Weight of proweight part	duct needed	i	SPECIFIC PROPERTIES
	SOLVINE®	FORMULA	NUMBER	FORM	MASS	kg/m³	lb/gallon lb/ft³	VALUE <sup>2</sup>	Ca	Cu	Fe	Mg	Mn	
	E-39			Liquid (39%)		1300	10.9		24	15	18	40	18	Most widely used liquid chelating agent
	100-S	EDTA-Na <sub>4</sub>		Liquid (38%)	380.2	1270	10.6	11.5	25	16	18	41	18	High purity (NTA free)
	NA		64-02-8	Micro-granular	-	600	37		11	7.0	7.9	18	8.0	Most widely used solid chelating agent
	NA-X	EDTA-Na,		Crystalline	452.2	900	56	11.5	12	7.2	8.2	19	8.3	High purity (Low NTA)
	220-S	Tetrahydrate		Crystattine	452.2	750	47	11.5	12	7.2	0.2	17	0.3	High purity (NTA free)
H00C N C00H	NA3-36	EDTA-Na <sub>3</sub> H	150-38-9	Liquid (36%)	358.2	1240	10.4	9.5	25	16	18	41	18	High purity (NTA free) Lower pH without inorganic salt
	NA2					600	37							Slightly acidic without inorganic salt
HOOC N N COOH	NA2-S	EDTA-Na <sub>2</sub> H <sub>2</sub> Dihydrate		Crystalline	372.2			4.5	9.4	5.9	6.7	16	6.8	High purity (NTA free)
ноос	NA2-P	Í				550	34							Food / Pharma quality (USP/FCC/EP/JP/ACS)
Ethylenediaminetetraacetic acid EDTA-H <sub>4</sub>	E-CA-10	EDTA-Na <sub>2</sub> Ca Dihydrate	23411-34-9 Anhydrous: 62-33-9	Micro-granular	410.3	700	44	7	-	6.5	7.4	-	7.5	High purity (NTA free) High purity: Food (E385) and Pharma quality (USP/FCC/EP/96-77-EC)
	AM4-50	EDTA-(NH <sub>4</sub> ) <sub>4</sub>	22473-78-5	Liquid (50%)	360.4	1180	9.9	9	18	11	13	30	13	
	AM3-40	EDTA-(NH <sub>4</sub> ) <sub>3</sub> H	15934-01-7	Liquid (40%)	343.3	1150	9.6	7	21	14	15	35	16	Sodium free
	AM2-45	EDTA-(NH <sub>4</sub> ) <sub>2</sub> H <sub>2</sub>	20824-56-0	Liquid (45%)	326.3	1200	10.0	5	18	11	13	30	13	Sodiumnee
	K4-50	EDTA-K,	5964-35-2	Liquid (50%)	444.6	1300	10.9	11.5	22	14	16	37	16	
	K4-100-S	LDIA-N <sub>4</sub>	0704-00-Z	Liquid (45%)	444.0	1270	10.6	11.5	25	16	18	41	18	Sodium free
ļ.	K3-123-S	EDTA-K₃H	17572-97-3	Liquid (50%)	406.5	1310	10.9	8	20	13	15	33	15	High purity
	Z	EDTA-H,	60-00-4	Crystalline	292.2	700	44	2.5	7.4	4.6	5.3	12	5.4	High purity
	Z-S	4		,	_ : <b></b>	- 50								High purity (NTA free)

### Other chelating agents

More products are available. Please contact your local sales office.

Metals to control	High acidity	Low acidity	Low alkalinity	High alkalinity
Divalent metals		EDTA, GLDA,	DTPA, HEDTA	
Water hardness	No chelating agent applicable	GLDA, HEDTA	EDTA, GLDA, DTPA	, NTA, EDG, HEDTA
Iron control	EDTA, GLDA,	DTPA, PDTA	HEDTA	Glucoheptonate

STRUCTURE AND CHEMICAL NAME	DIS- SOLVINE®	CHEMICAL FORMULA	CAS REGISTRY	PHYSICAL FORM	MOLECULAR MASS	DENSITY	¹ (approx.)	TYPICAL pH	Calculate	CHELA d weight of p	TION EQUIVA Product need of metal		veight part	SPECIFIC PROPERTIES
	SULVINE	FURMULA	NUMBER	FURM	MASS	kg/m³	lb/gallon lb/ft³	VALUE <sup>2</sup>	Ca	Cu	Fe	Mg	Mn	
соон	GL-38	CLDA Na		Liquid (38%)	351.1	1360	11.4	11.5	23	15	17	38	17	Readily biodegradable & highly
ноос \ \ \ \ \ \ \ \ \ \ \ \ \ Соон	GL-47-S	GLDA-Na <sub>4</sub>	F4004 04 /	Liquid (47%)		1400	11.7	11.5	19	12	13	31	14	soluble. Main part originates from natural sustainable source
СООН	GL-NA-40-S	GLDA-Na <sub>4</sub> GLDA-H4	51981-21-6	Liquid (40%)		1260	10.5	3-4	18	11	13	29	13	GL-47-S, GL-NA-40-S and GL-PD-S are high purity products. GL-47-S and GL-NA-40-S
Glutamic acid, N,N-diacetic acid GLDA-H <sub>4</sub>	GL-PD-S	GLDA-Na <sub>4</sub>		Micro-granular		400	25	11.5	11	6.9	7.9	18	8.0	are NTA free.
COOH	D-40			Liquid (40%)		1280	10.7		31	20	23	52	23	
HOOC N COOH	D-50	DTPA-Na <sub>5</sub>	140-01-2	Liquid (50%)	503.3	1370	11.4	11.5	25	16	18	41	18	Regular DTPA
	D-88			Micro-granular		700	44		14	9.0	10	24	10	
lines J	D-K5-40	DTPA-K <sub>5</sub>	7216-95-7	Liquid (40%)	583.3	1280	10.6		36	23	26	60	27	Sodium free. High purity
Diethylenetriaminepentaacetic acid	DZ	DTPA-H <sub>5</sub>	67-43-6	Crystalline	393.4	600	37	2	10	6.3	7.2	17	7.3	High purity Also available in version meeting the USP test requirements.
COOH	H-40	HEDTA-Na <sub>3</sub>	139-89-9	Liquid (43%)	344.2	1280	10.7	11.5	20	13	15	33	15	
HOOC N COOH	H-50-GS	HEDTA-Na <sub>3</sub> / HEDTA-H3	-	Liquid (50%)	-	1320	11.0	5-9	17	11	13	28	13	Chelating agent for iron at low alkalinity
HOUC / Hydroxyethylethylenediaminetriacetic acid HEDTA-H <sub>3</sub>	H-88-X	HEDTA-Na <sub>3</sub> 2.5 hydrate	Anhydrous: 139-89-9	Crystalline	389.2	600	37	11.5	9.8	6.2	7.0	16	7.2	
HOOC N COOH  COOH  Nitrilotriacetic acid  NTA-H <sub>3</sub>	A-150-S	NTA-Na <sub>3</sub>	5064-31-3	Liquid (40%)	257.1	1300	10.9	11.5	16	10	12	27	12	Readily biodegradable High temperature stable

 $<sup>^1</sup>$  poured bulk density for solids, note: 1000 kg / m³ = 8.35 lb / gal (for liquids) and 62.43 lb / ft³ (for solids)  $^2$  as 1% solution or saturated solution if solubility is < 1%

More products are available. Please contact your local sales office.

Metals to control	High acidity	Low acidity	Low alkalinity	High alkalinity					
Divalent metals		EDTA, GLDA, DTPA, HEDTA							
Water hardness	No chelating agent applicable	GLDA, HEDTA	EDTA, GLDA, DTPA	, NTA, EDG, HEDTA					
Iron control	EDTA, GLDA,	DTPA, PDTA	DTA HEDTA Glucohepto						

STRUCTURE AND CHEMICAL NAME	DIS- SOLVINE®	CHEMICAL FORMULA	CAS REGISTRY	PHYSICAL Form	MOLECULAR MASS	pH   sit one weight part of metal		d	SPECIFIC PROPERTIES					
	JOLVINE	FORMULA	NUMBER	FORM	МАЗЭ	kg/m³	lb/gallon lb/ft³	VALUE <sup>2</sup>	Ca	Cu	Fe	Mg	Mn	
HO N COOH COOH Ethanoldiglycinic acid; EDG-H <sub>2</sub>	EDG	EDG-Na <sub>2</sub>	135-37-5	Liquid (27.5%)	221.1	1180	9.9	11.5	20	13	14	33	15	Readily biodegradable Also referred to as HEIDA
HOOC N COOH HOOC COOH  1,3-Propylenediaminetetraacetic acid; PDTA-H <sub>4</sub>	PDZ	PDTA-H₄	1939-36-2	Crystalline	306.3	700	44	2	7.8	4.9	5.6	13	5.7	High purity chelate for photo bleaching Imparts favorable redox- potential to iron
OH OH OH HO OH OH OH OH Glucoheptonic acid	CSA	Sodium glucoheptonate	31138-65-5 Also 13007-85-7	Liquid (30%)	248.2	1180	9.9	8.5	More metals can be chelated by one molecule of this chelating agent, depending on the pH		Readily biodegradable chelating agent for application at high alkalinity Main part originates from natural sustainable source			

 $<sup>^1</sup>$  poured bulk density for solids, note: 1000 kg / m³ = 8.35 lb / gal (for liquids) and 62.43 lb / ft³ (for solids)  $^2$  as 1% solution or saturated solution if solubility is < 1%

### **Metal Chelates**

More products are available. Please contact your local sales office.

Metals to control	High acidity	Low acidity	Low alkalinity	High alkalinity				
Divalent metals		EDTA, GLDA,	DTPA, HEDTA					
Water hardness	No chelating agent applicable	GLDA, HEDTA	EDTA, GLDA, DTPA	, NTA, EDG, HEDTA				
Iron control	EDTA, GLDA,	DTPA, PDTA	HEDTA Glucoheptor					

DISCOLVINE®	OUENION FORMULA	OLG DEGISTRY NUMBER	DUVISION FORM	MOLEOULAR MASS	DENSIT	Y¹ (approx.)	APPLICATION
DISSOLVINE®	CHEMICAL FORMULA	CAS REGISTRY NUMBER	PHYSICAL FORM	MOLECULAR MASS	kg/m³	lb/gallon lb/ft³	(other than agriculture)
E-CA-3	[EDTA.Ca] Na <sub>2</sub>	Anhydrous: 62-33-9	Liquid	374.3	1190	9.9	Peroxide bleaching
E-CA-10	[EDTA.Ca] Na <sub>2</sub> .2H <sub>2</sub> 0	+2 aq: 23411-34-9	Micro-granular	410.3	700	44	Food & Pharma
E-CU-8	[EDTA C] (NIII.)	/7000 00 0	1:	207.0	1250	10.4	[]t -ti
E-CU-9	[EDTA.Cu] (NH <sub>4</sub> ) <sub>2</sub>	67989-88-2	Liquid	387.8	1330	11.1	Electroplating
E-CU-15	[EDTA.Cu] Na <sub>2</sub>	14025-15-1	Micro-granular	397.7	700	44	Cosmetics, Electroplating
E-MG-3	[EDTA M. ] M.	47700 00 4	Liquid	050.5	1240	10.4	D
E-MG-6	[EDTA.Mg] Na <sub>2</sub>	14402-88-1	Micro-granular	358.5	700	44	Peroxide bleaching
E-MN-6	[EDTA.Mn] K <sub>2</sub>	68015-77-0	Liquid	421.4	1330	11.1	-
E-MN-13	[EDTA.Mn] Na <sub>2</sub>	15375-84-5	Micro-granular	389.1	700	44	-
E-FE-6	[EDTA.Fe] K	54959-35-2	Liquid	383.2	1350	11.3	DeNOx, Gas sweetening
E-FE-13	[EDTA.Fe] Na.3H <sub>2</sub> 0	15708-41-5	Crystalline	421.1	900	56	Polymer processing, Gas sweetening
E-ZN-9	[EDTA.Zn] (NH <sub>4</sub> ) <sub>2</sub>	67859-51-2	Liquid	389.7	1320	11.0	-
E-ZN-15	[EDTA.Zn] Na <sub>2</sub>	14025-21-9	Micro-granular	399.6	800	50	-
AMFE-50					1300	10.9	
AMFE-52	[EDTA.Fe] NH <sub>x</sub> .NH <sub>x</sub> OH	68413-60-5	Liquid	397.2	1300	10.7	Photography
AMFE-54	[EDTA.Fe] NH <sub>4</sub> .NH <sub>4</sub> OH	00413-00-3	Liquid	377.2	1320	11.0	Gas sweetening
AMFE-34					1320	11.0	
D-FE-3	[DTPA.Fe] Na <sub>2</sub>	100208-96-6 19529-38-5	Liquid	490.2	1280	10.7	-
D-FE-6	[DTPA.Fe] (NH <sub>4</sub> ) <sub>2</sub>	85959-68-8		480.2	1300	10.9	-
D-FE-11	[DTPA.Fe] H Na	12389-75-2	Crystalline	468.2	700	44	-
H-FE-4.5					1280	10.7	
H-FE-5.5-GS	[HEDTA.Fe]	17084-02-5	Liquid	331.1	1360	11.4	Gas sweetening
	[nedia.re]	17004-02-3	Miana gazzadza	331.1			das sweeteiling
H-FE-13			Micro-granular		500	31	
MP	[PDTA.Fe] K	124268-99-1	Liquid	397.2	1210	10.1	Photography

 $<sup>^1</sup>$  poured bulk density for solids, note: 1000 kg / m³ = 8.35 lb / gal (for liquids) and 62.43 lb / ft³ (for solids)  $^2$  as 1% solution or saturated solution if solubility is < 1%

## Recommendation for product use

### Chelating agent product range and applications

\* = also available in version meeting the USP test requirements.

Dissolvine®	Building & Construction	Cleaning & Detergents	Industrial cleaning	Feed additives	Food & Pharma	Gas sweetening	Metal plating & Electronics	Oil industry	Personal care	Photography	Polymer production	Printing ink	Pulp & Paper	Textiles
E-39											0		•	
100-S									0		0		0	
NA									0		0		-	
NA-X									0					
220-S									0					
NA3-36									0					
NA2									0					
NA2-S									0					
NA2-P				0	0				0					
E-CA-10					0									
AM4-50														
AM3-40														
AM2-45														
K4-50														
K4-100-S														
K3-123-S														
Z									0					
Z-S									0					
GL-38									0		0		•	
GL-47-S									0		0			
GL-NA-40-S									0		0		•	
GL-PD-S	_								0		0		0	
D-40									•		0		•	
D-50									0		0		0	
D-88									0		0		•	
D-K5-40														
DZ					*	_	_		0		_	_		
H-40									0		0		•	
H-50-GS														
H-88-X									0		_			
A-150-S											0			
EDG														
PDZ														
CSA														


### Metal chelate product range and applications


### **Functions**

- Stopping undesirable precipitation or removing scale / re-dissolving salts
- Controlling metal catalyzed reactions
- A combination of preventing precipitation and controlling metal catalyzed reactions
- Intermediate for metal chelate

Dissolvine®	Agriculture	Food & Pharma	Gas sweetening	Metal plating & Electronics	Personal care	Peroxide bleaching	Photography	Polymer production
E-CA-3								
E-CA-10		•			•			
E-CU-8								
E-CU-9								
E-CU-15								
E-MG-3						0		
E-MG-6						0		
E-MN-6								
E-MN-13								
E-FE-6							•	
E-FE-13							•	-
E-ZN-9								
E-ZN-15								
AMFE-50								
AMFE-52								
AMFE-54							-	
D-FE-3								
D-FE-6								
D-FE-0								
D-LE-11								
H-FE-4.5								
H-FE-5.5-GS								
H-FE-13								
MP								

2





### **Contact us**

If you would like further details, please get in touch with us at one of our regional offices

### **Asia Pacific**

Akzo Nobel Functional Chemicals Pte Ltd. 41 Science Park Road #03-04 The Gemini Singapore Science Park II Singapore 117610 Singapore

T: +65 6773 8488 E: AP@Dissolvine.com

#### China

Akzo Nobel Chemicals ( Ningbo) Co., Ltd. 5F, The Exchange No. 299 Tong Ren Road Shanghai 200040 China

T: +86 21 2216 3600 E: AP@Dissolvine.com

### **Europe & Rest of the World**

Akzo Nobel Functional Chemicals BV Stationsstraat 77 P.O. Box 247 3800 AE Amersfoort The Netherlands T: +31 33 4676341

E: EUR@Dissolvine.com

### North and South America

Akzo Nobel Functional Chemicals LLC 525 W. van Buren Street Chicago, Illinois 60607 U.S.A.

Inside U.S.A. Tel: +1 800 906 7979 Outside U.S.A. Tel: +1 312 544 7000 E-mail: NAM@Dissolvine.com

Please also visit our website: www.dissolvine.com

### Dissolvine® master the elements

The information presented herein is true and accurate to the best of our knowledge, but without any guarantee unless explicitly given. Since the conditions of use are beyond our control, we disclaim any liability, including patent infringement, incurred in connection with the use of these product data or suggestions.

© AkzoNobel

® Dissolvine and the AkzoNobel device are trademarks of the AkzoNobel group of companies Issue: September 2010