AS-2009-000036 Rev.1 PSN-2009-0563

TOSHIBA Leading Innovation >>>

4S Reactor <u>Super-Safe</u>, <u>Small and Simple</u>

June 2009

Kazuo Arie Toshiba Corporation Tony Grenci Westinghouse Electric Company





4S Presentation

- Introduction Marvin Yoder
- 4S Overview Kazuo Arie, Toshiba
- 4S Design Tony Grenci, Westinghouse
- Licensing Status Tony Grenci, Westinghouse
- Questions



Overview

Goals

- Provide safe, clean, reliable, grid-appropriate power
- Minimize security and proliferation risks
- Minimize infrastructure, operation & maintenance requirements

Sodium cooled fast reactor


- Co-developer: CRIEPI
- Developing Partners: ANL, Westinghouse

30 MWt (10MWe)

(Initial Configuration)

Main features


- Passive safety
- No onsite refueling for 30 years
- Low maintenance requirements
- High inherent security







Plant Description




- Seismic isolation is provided for the reactor building.
- Reactor building is below grade.



4S Advantages - Economy

- Diesel fuel prices are high and unpredictable.
- Long refueling interval (10-30 years) front-loads the fuel costs.








4S Advantages - Operations

- Small operations and security force
 - Simplified operations, load changes accomplished using turbine bypass
 - Automatic burnup compensation
 - Passive safety systems
 - Small plant footprint



4S Advantages- High Inherent Security

- Below-grade siting to protect from missile or airplane impact.
- No onsite fuel storage (10 MWe).
- Sealed Reactor Vessel.
- Heavy Lifting and Fuel Handling Equipment removed from site.
- Fuel enrichment below proliferation grade.









4S Advantages - Maintenance

- Passive systems
- Materials compatibility
- Minimal moving parts
 - EM Pumps










4S Versions

- Two versions being designed simultaneously.
 - 10 MWe version
 - 50 MWe Version
- Rx Vessel, Rx Building identical for both versions.



4S System Configuration




TOSHIBA Leading Innovation >>>

Copyright 2009, Toshiba Corporation

Westinghouse

4S Versions

- Steam Generator, IHX, Air Cooler sizing
- IRACS operation





Westinghouse

Plant Design Parameters

Reactor Core


Core Height	2.50 m	(8.2 ft)
Equivalent Core Diameter	0.95 m	(3.1 ft)
Fuel / Clad Material	U-10%Zr / HT-9 s	teel
235U Enrichment (inner / outer)	17 / 19 %	
Average Burn-up	34,000 MWd/t	
Reactor Vessel		
Design Pressure	0.3 MPa	(44 psi)
Design Temperature	550 deg.C	(1022 deg.F)
Inner Diameter / Thickness	3.5 m / 25 mm	(12 ft / 1.0 inch)

Design Pressure	0.3 MPa	(44 psi)	
Design Temperature	550 deg.C	(1022 deg.F)	
Inner Diameter / Thickness	3.5 m / 25 mm	(12 ft / 1.0 inch)	
Total Height	24 m	(79 ft)	
Material	Type 304 stainles	Type 304 stainless steel	





Core Design








Reactivity Control System


Reflector		
Number	6	
Reflector stroke	2.7m (8.8ft)	
Scram	gravity	
Shutdown rod		Shutdown rod
Number	1	Cavity
Rod stroke	2.5m (8.2ft)	
Absorber material	B4C	
Scram	gravity Insertic	on Reflector
Fixed absorber		
Number	6	
Absorber stroke	2.7m (8.8ft)	
Absorber material	Hf	
		14/24






Reactivity Control







Available Systems	Reflector	Shutdown Rod	Fixed Absorber
Start up & normal shutdown	0	0	-
Burn-up compensation	0	_	0
Scram	Δ^*	Δ	-

Shutdown Rod

O - Needed


 Δ – Redundant and diverse

* - Provides one reflector stuck margin





Primary EM pumps








Passive Decay Heat Removal

Heat removal by natural circulation & natural air draft

- Redundant and diverse residual heat removal
- RVACS: Natural air draft outside the guard vessel
 - Sufficient cooling capacity by only RVACS
- IRACS: Natural circulation of sodium and air draft of air cooler






Westinghouse

Steam Generator

Double wall tube steam generator Minimizes potential for sodium-water reaction 31.8mm Tube Gap filled with wire mesh Outer Tube Water/Steam Inner Tube Sodium







Containment

Guard vessel


- 2 1/4Cr-1Mo - Material:
- **Diameter:** _

Top dome

- Material: 2
- **Diameter:** _
- 2 1/4Cr-1Mo

3.65m

- **8**m
- Passive heat removal system







Safety Features of 4S

Source term reduction

- Low power results in low fission product inventory
- Sodium affinity for fission products minimizes release
- No significant release to containment due to absence of energetic and pressurization events

Radioactive release reduction

- Sealed reactor vessel and containment
- Minimize penetrations and isolation valves
- Threat to containment integrity is minimal due to absence of damaging phenomena (direct containment heating, steam explosion, hydrogen burning or detonation, missiles)






Safety Analysis Results

 Large margin to acceptance criteria for site suitability and emergency planning

Distance (m)	50
EAB (rem)	0.004
LPZ (rem)	0.2
Acceptance dose criteria (rem)	25

- TEDE: Total equivalent dose
- EAB: Exclusion area boundary
- LPZ: Low population zone








Test Facility for Further Tests


• TOSHIBA Sodium Component Test Facility

- Facility completed December 2008.
- Functional testing begun January 2009.
- Planned tests
 - Demonstration of large-scale EM pump.
 - Verification of leak detection system for a steam generator outer tube failure.










Westinghouse

Current Licensing Schedule

• Submit Design Approval application on October, 2010

- Phase 1: Complete a series of meetings with NRC to identify issues to be addressed before Design Approval application
- Phase 2: Submit technical reports and obtain NRC feedback to address the issues identified in Phase 1
- Phase 3: Submit Design Approval application and obtain SER



The licensing activity is been conducted in cooperation with CRIEPI, ANL and WEC.





Conclusions

- 4S is a mature technology that is ready for regulatory review and commercialization.
 - Preliminary systems design complete and detailed design in progress
 - Significant body of test data to support key components
 - Proven and tested fuel experience to support the 30-year core lifetime

• 4S U.S. licensing process has begun.

- Pre-application review meetings & technical reports
- Target for FDA 2013





TOSHIBA Leading Innovation >>>