


## Heat Flux Sensors

### Insulation measurement of a refrigerator

#### Case description

An industrial freezer is designed to operate at an internal air temperature of  $-20^{\circ}\text{C}$ , when the external air temperature is  $25^{\circ}\text{C}$ . The internal and external heat transfer coefficient are  $k_1 = 11\text{ W/m}^2$  and  $k_2 = 7\text{ W/m}^2$ . The walls of the freezer are comprising of a layer of plastic with  $\lambda_1 = 1\text{ W/mK}$  and thickness  $d_1 = 3\text{ mm}$ , insulation material with  $\lambda_2 = 0.06\text{ W/mK}$  and thickness of  $d_2 = 200\text{ mm}$  and an outer layer of stainless steel with  $\lambda_3 = 16\text{ W/mK}$  and thickness of  $d_3 = 1.5\text{ mm}$ . Below we describe the calculation and the measurement approach to derive the heat flux ( $\Phi$ ) to the inside of the refrigerator wall and the overall U-Value (U).



#### Calculation

Known parameters:

$$d_1 = 0.003\text{ m}$$

$$\lambda_1 = 1 \frac{\text{W}}{\text{mK}}$$

$$d_2 = 0.2\text{ m}$$

$$\lambda_2 = 0.06 \frac{\text{W}}{\text{mK}}$$

$$d_3 = 0.0015\text{ m}$$

$$\lambda_3 = 16 \frac{\text{W}}{\text{mK}}$$

$$k_1 = 11 \frac{\text{W}}{\text{m}^2}$$

$$k_2 = 7 \frac{\text{W}}{\text{m}^2}$$

$$T_{in} = -20^{\circ}\text{C}$$

$$T_{out} = 25^{\circ}\text{C}$$

#### Measurement with gSKIN<sup>®</sup> U-Value KIT


Background knowledge for measurement approach:

*No assumptions needed*

*No need for any known values beforehand (thickness, material, etc.)*

*No additional calculation needed*

1. Mount the heat flux sensor and one temperature sensor on the outside of the refrigerator.



## Heat Flux Sensors

### Unknown:

Heat loss per m<sup>2</sup> of fridge surface:

$$\Phi = ? \left[ \frac{\text{W}}{\text{m}^2} \right]$$

Heat transfer coefficient via the wall:

$$U = ? \left[ \frac{\text{W}}{\text{m}^2 \text{oK}} \right]$$

### Assumptions needed for calculation:

- 1) Steady state conditions
- 2) One-dimensional conduction through the wall
- 3) Constant thermal conductivity

### Formulas:

$$\Phi = U * (T_{\text{in}} - T_{\text{out}})$$

$$U = \frac{1}{\frac{1}{hk_1} + \frac{d_1}{\lambda_1} + \frac{d_2}{\lambda_2} + \frac{d_3}{\lambda_3} + \frac{1}{k_2}}$$

### Results:


$$U = \frac{1}{\frac{1}{11} + \frac{0.003}{1} + \frac{0.2}{0.06} + \frac{0.0015}{16} + \frac{1}{7}} = 0.28 \frac{\text{W}}{\text{m}^2\text{K}}$$

$$\Phi = 0.28 * (25 - (-20)) = 12.6 \frac{\text{W}}{\text{m}^2}$$

Mount the second temperature sensor inside the refrigerator:



2. Connect all the sensors to the logging unit, start the measurement, evaluate the heat flux through the wall and the U-Value according to ISO 9869 and monitor it during the whole measurement time



### Summary

Advantages of using gSKIN<sup>®</sup> U-Value KIT over calculation:

- 1) No need for additional parameters (i.e. heat transfer coefficients)
- 2) Real-time measurement
- 3) The measurement takes into account real conditions
- 4) gSKIN<sup>®</sup> Heat Flux Sensor detects all types of heat transfer

For more information go to: <http://u-value.greenteg.com>