



## PREPARATION TECHNIQUES APPLIED TO A STEGOSAURIAN DINOSAUR FROM PORTUGAL

Ricardo Araújo<sup>1,2</sup>, Octávio Mateus<sup>1,2</sup>, Aart Walen<sup>3</sup> and Nicolai Christiansen<sup>1</sup>

1- Museu da Lourinhã, Rua João Luís de Moura, 2530-157 Lourinhã.

2- CICEGe, Faculdade de Ciências e Tecnologia, Universidade Nova de Lisboa, , 2829-516 Caparica, Portugal.

3- Creatures and Features, Rijndijk 17, NL-6686 MN, Doornenburg, Netherlands.

### ABSTRACT

General vertebrate paleontological techniques that have been used in the Museum of Lourinhã (Portugal) are presented here, in particular those applied to a stegosaurian dinosaur skeleton. A monolith jacket technique using polyurethane foam and plaster is presented. Mechanical preparation techniques combining the use of an electric grinder and airscribes proved effective during the initial phases of preparation on well-preserved bone embedded in hard matrix. We also present a technique to mould monoliths in the early stages of preparation, creating a thin silicone rubber mould in several contiguous parts. To mould and cast monoliths before removing individual bones has proven valuable for the preservation of taphonomic data and for display purposes. Polyurethane resin combined with plaster is useful for small casts, while polyester resin applied in four layers is the preferred technique for larger casts. The four layers are composed of: a first thin layer of polyester resin with bone colour; followed by another layer of polyester resin of sediment colour and containing hollowfill to make it thicker. The third layer is composed of fibre glass chopped strands, and the fourth is composed of fibre glass mats embedded in plain polyester resin. 3D scanning and digitization techniques were tested for the storage of osteological information of individual bones and proved very promising.

### RESUMO [in Portuguese]

As técnicas gerais de paleontologia de vertebrados que foram usadas no Museu da Lourinhã (Portugal) são apresentadas aqui, em particular as aplicadas num dinossauro estegossauo. É apresentada uma técnica de revestimento de monólitos usando a espuma de poliuretano. Uma técnica de preparação mecânica que combina o potencial de uma rebarbadora eléctrica e de uma caneta percursora durante as fases iniciais da preparação do osso, quando envolvido em matriz dura, revelou-se eficaz. Foi aplicado um procedimento geral para moldar e replicar que, combina gesso e resina de poliuretano: útil para moldes pequenos. É indicada uma técnica usando quatro camadas para a elaboração de réplicas de grandes dimensões. A primeira camada é composta por resina de poliéster colorida; a segunda adiciona *hollowfill* e diferentes tonalidades à composição da primeira camada; a terceira é composta por fibras de vidro; e, a quarta por mantas de fibra de vidro embebidas em poliéster. A moldagem de monólitos revelou-se uma solução efectiva, preservando informação tafonómica e, ao mesmo tempo, útil para propósitos de exposição. O digitalizador 3D mostrou ser útil para o armazenamento de informação osteológica.

How to cite this article: Araújo, R., Mateus, O., Walen, A. and Christiansen, N., 2008. Preparation techniques applied to a stegosaurian Dinosaur from Portugal, Journal of Paleontological Techniques, 5: 1-24.

## INTRODUCTION

This paper describes the excavation, preparation, moulding, casting, and 3D scanning of a Late Jurassic dinosaur from Lourinhã, Portugal. This area is rich in dinosaurs and other vertebrates (see Antunes and Mateus 2003, Mateus 2006, and references therein). Fossil collecting and preparation in Museum of Lourinhã commenced in 1984 when the first specimens of crocodiles and dinosaurs were collected. Initially, the equipment was rudimentary little more than chisel and hammer was used. Out of curiosity, the first electric [air]scribe was acquired in 1998. The increasing number of fossils collected also brought awareness of the vital importance of preparation in the paleontological collections.

The first full time preparator – Dennis Roessler – was then hired in 2001. The subsequent work was then developed by Nicolai Christiansen, Ricardo Araújo, Rui Lino and Alexandra Tomás, in consultation with Aart Walen and Museum research scientists.

Currently, Museum of Lourinhã has a modern laboratory making use of techniques designed on the basis of other preparation laboratories and adapted to our own conditions (fig. 1). The preparation techniques applied in the Museum of Lourinhã are represented here using, as an example, the entire process of preparation of the stegosaurian dinosaur specimen ML433 [for a formal description of the specimen see Mateus et al. (in press)].



Fig. 1 – Aspect of the paleontological preparation laboratory at Museu da Lourinhã.

## FOSSIL MATERIAL

The specimen ML433, belonging to a stegosaur dinosaur, is composed of an early complete anterior half of a skeleton with partial skull (right premaxilla, left nasal, right postorbital,

right and left angulars and a partial left maxilla), fifteen cervical vertebrae, two dorsal vertebrae, left coracoid, left scapula, partial right fused scapulacoracoid, both humeri, radius and ulnae, one metacarpal, three phalanges, twelve ribs, one chevron, one dermal spine and

thirteen dermal plates. This specimen was discovered in 2001 by Rui Soares, who initially

discovered an exposed osteoderm (fig. 2).




Fig. 2 – Preserved material from the stegosaur dinosaur ML433 (illustration by Simão Mateus).

## MATERIALS AND TOOLS

The most important tools used during the process are listed below. Some of the casting and moulding products can be obtained from the same suppliers as those of fiber glass boat industries, ceramics industry, and art stores. A more complete list can be found in May *et al.* (1994).

### Field:

- Hitachi® DH40FA jackhammer or hammer drill (230V; power input: 950W; 6,7kg); obtainable at any hardware shop;
- Hammer, chisel, and pickaxe (for each, four different sorts and weights, at least); obtainable at any hardware shop;
- Plexigum® 742 – 33% impregnator (base ethylmethacrylate, at 33% solids in ethanol:methoxypropanol 7:1; thermoplastic acrylic resin; medium hard polymer; soluble in acetone, alcohols, esters, aromatics – acetone has been used preferably, due to its quick volatilization); obtainable at <http://kremer-pigmente.de>;

- DeWalt® DW476 angle grinder; obtainable at any hardware shop;

### Jacketing:

- Polyurethane foam (2-component: isocyanate and polyol); obtainable in chemical shops;
- Plaster-of-Paris; obtainable at any art store;
- Gauze (regular gauze used for medical purposes)
- Burlap and canvas; obtainable at any fabric shop;
- Cardboard;
- Metal structure (for the monolith base).

### Laboratorial mechanical preparation (fig. 3):

- Ciata® T-300/P air compressor (capacity: 284dm<sup>3</sup>, pressure: 9,8bar); obtainable at hardware shops;
- Paleotools® airscribes obtainable at <http://www.paleotools.com/>:
  - Paleo-ARO™ airscribe: long bushing; solid tungsten carbide pointed stylus with 0,094inch diameter; 3,5inches long;
  - Micro-Jack®-6 airscribe: solid tungsten carbide stylus 0,063 inch diameter, 1,5inches long, 0,5inch beyond bushing;

- Mighty-Jack™ airscribe: chisel stylus 1/4 inch diameter;
- 3M® Series 6000 respirator; obtainable at any hardware shop;
- DeWalt® DW817 electric grinder (230V; 10A; power input: 720W; 1,7kg, wheel diameter: 115mm, frequency: 10.000min<sup>-1</sup>) and DeWalt® DW476 (same characteristics but different wheel diameter: 180mm); obtainable at any hardware shop;
- Renfert® basic MOBIL No. 2914 sandblaster; obtainable at <http://www.krantz-online.de/de/1.html>;
- Bench grinder; obtainable at any hardware shop;




Fig. 3 – Main equipments used for mechanical preparation: A- airscribe Paleotools® Mighty-Jack™; B- airscribe Paleotools® Paleo-ARO™; C- airscribe Paleotools® Micro-Jack®-6; D - electric grinder DeWalt® DW817; E - sandblaster Renfert® basic MOBIL No. 2914; F- respirator 3M® Series 6000; G- jackhammer Hitachi® DH40FA; H- air compressor Ciata® T-300/P.

#### Chemicals:

- Polymer acrylic resins of the brands Paraloid (Acryloid) B72, Plexigum PM381 or equivalent, dissolvable in acetone. Plexigum is a 2-Methylpropyl 2-methyl-2-propenoate homopolymer.
- Epoxy glues: Crys® or Araldite®, two-component epoxy;
- Paleobond® PB002 penetrant/stabilizer; obtainable at <http://www.paleobond.com/>;
- Paleobond® bonding adhesives; obtainable at <http://www.paleobond.com/>;
- Paleobond® PB303 activator non-aerosol; obtainable at <http://www.paleobond.com/>;
- Paleobond® PB400 debonder solvent; obtainable at <http://www.paleobond.com/>;
- Carbowax® 4000 C005 (polyethylene glycol, storage temperature: 20°C); obtainable at <http://www.dow.com/polyglycols/carbowax/>;
- Starbond® Thin EM-02; obtainable at <http://www.starbond.com/>;
- Starbond® accelerator; obtainable at <http://www.starbond.com/>;

- Polyester putty (11-18%w/w styrene; takes about 20min to dry; hardener paste: benzoylperoxide or dibenzoyl 50 %w/w; aluminium powder/silica spheres. Calcium carbonate powder can be added in different proportions); obtainable at most chemical stores;
- Formic acid (HCOOH); obtainable at chemical store.

#### Moulding:

- Rhodorsil® RTV 863 N silicone; obtainable at <http://secure.silmid.com/>;
- Catalyst 863 N catalyst; obtainable at <http://secure.silmid.com/>;
- Rhodorsil® A DITIVO PC 12 (0,5 to 2,0% w/w) thixotropic additive; <http://secure.silmid.com/>
- Colour pigment powder; obtainable at Cristalcer-Cerâmica, Produtos e Serviços Lda.
- Ladies stocking material or anti-weed tissue;
- Metal brush;
- Paint thinner; obtainable at any chemical store;

#### Casting:

- Polyurethane resin SG 130/PUR11 (stiffening time: 20-40min; recommended temperature of usage: 18-25°C; aluminium powder and pigments can be added); obtainable at any chemical store;
- Polyester resin (11-18% styrene; takes about 20min to dry; hardener: benzoylperoxide or methylethylketone peroxide); obtainable at most chemical stores;
- Fibreglass chopped strands; obtainable at most chemical stores;
- Hollowfill or spherulites; obtainable at any chemical store;
- Grey clay; obtainable at any art store;
- Polyurethane UV- protection coat; obtainable at any chemical store;
- Polyurethane and water based acrylic (e.g. Galeria®, Rembrandt®); obtainable at any artist store;
- Peroxide hardener;
- Polyurethane foam; obtainable at any chemical store;
- Screws, wooden and metal pieces;
- Stanley-knife;
- Aluminium powder; obtainable at any chemical store;
- Silica spheres; obtainable at any chemical store;
- Fibreglass mats (300g/m<sup>2</sup>) and strands; obtainable at any chemical store;

- Calcium carbonate powder; obtainable at any chemical store;
- Colour pigment powder; obtainable at any chemical store;
- Metal brush;
- Paint thinner; obtainable at any chemical store;
- Plastic wrapper film;
- Brushes; obtainable at art shops.

**Security and health:**

- First aid kit;
- Protections for eyes (goggles) and ears;
- Respiratory protection;
- Field boots;
- Latex gloves;
- Lab coat.





Fig. 4 – Geographical location of Lourinhã and Miragaia after Carta Militar nº349.

**FIELD EXCAVATION AND POLYURETHANE JACKETING**

ML433 was collected from the Miragaia Unit of the Lourinhã Formation. The stegosaurian dinosaur remains were found (fig. 4) along a secondary road linking the villages of Miragaia and Sobral. The construction of this road was the cause of destruction of the posterior part of the specimen.

The excavation and collecting of ML433 was conducted by the Museum of Lourinhã during two digging seasons (in August 1999 and another in August 2001) coordinated by one of us. During the first season, the quarry was opened (towards the west) with the assistance of nine volunteers. Isolated bones were collected and one main block containing several bone elements (limb bones, ribs, pectoral girdle and cervical vertebrae) was isolated. (fig. 5).



Fig. 5 – Field techniques: A – site where the specimen was collected before excavation; B – first season of excavations; C – isolating the main block; D – jacketing technique: applying the metal frame, the block was already protected with polyester and plaster; E – applying polyurethane on the metal frame, once it hardens it attaches to the main block; F – aspect of the quarry once the main block was removed; G – transporting the main block to the museum.

The bone-bed is composed of compact calcareous sandstone overlain by more than 45cm of the sandstone with lignite lamina and carbonate nodules. The layer is subsequently overlain by 50 to 130 cm layers of mudstone, some being fossiliferous ( fig. 6 ). The fossiliferous layer was hard to quarry, since the

matrix was very dense and the preserved bone was generally more fragile than the surrounding rock. In the other hand, the cleavage between rock and fossil was perfect, enhanced by its brittle characteristics.




Fig. 6 – Schematic stratigraphic log of the excavated area.

During the second season, the block (then with approximate dimensions: 1,5m×1,5m × 1m) that had been isolated during the first season was recovered from the field using a jacketing technique with expanded polyurethane (see fig.5 D , E ; 7) . Mateus and Araújo ( 2008) describe techniques for removing large blocks in paleontological excavations, however the technique was not used in the excavation here reported. This technique has been used systematically in subsequent digs with success. Initially, a layer of acrylic impregnator was applied to the bones, followed by aluminium foil or wet paper. This impregnator layer, applied with a small brush (0,5cm diameter), not only prevents the surface of the freshly exposed fossil to be effaced under mechanical preparation, but also impregnates and consolidates the interior of the fossil bone. Special care should be taken when the solvent is evaporating (normally 2-3minutes), since it weakens the bone while it did not evaporate completely. The solvent used is acetone. Subsequently, plaster-of-Paris with gauze was applied on the foil, although burlap has revealed to be more resistant and cheaper. Wood boards and a metal frame were placed on top of the block, increasing rigidity and at the same time making the block easier to handle. After this, regular cardboard was placed all the way around on the lateral parts of the block, serving as retaining walls to control the liquid polyurethane. As the liquid grows and solidifies into foam, the wood structure gets embedded within the polyurethane and firmly attaches to the block. Once the cardboard is removed, the mushroom-like monolith can be flipped over securely, after the base is totally excavated. The expansion of polyurethane liquid into foam takes a few minutes and grows to between twenty to thirty times its original volume. Attention must be paid when using polyurethane: the air temperature and the proportions of the two different components used will lead to different reaction time and polyurethane foam properties. Hot air temperatures induce a faster reaction and distinct proportion of the two components will provide a more flexible, or more brittle foam. The adhesion to the adjacent surfaces also

changes with the proportions. Presence of water will enhance the expansion effect.

This polyurethane jacketing technique is particularly effective in comparison with plaster-of-Paris-only jackets when the blocks are heavy or have irregular shapes. The foam structure absorbs physical shock and gives a strong cohesion to the block. In sum, the advantages of combining polyurethane jacketing with regular plaster-of-Paris jacketing are: 1) lighter weight (especially relevant in big monoliths), 2) the foam adapts perfectly to the block shape and fills open gaps, 3) the flexible foam absorbs shocks and gives cohesion, 4) the original liquid net volume is smaller when compared to the expanded foam, thus easier to transport and storage and 5) polyurethane foam can be reused as packing material, for example.

The large quantities of polyurethane bits that the opening of the field jacket will produce can be recycled. They can be used either as packing material or as filling for casts. By pouring freshly mixed polyurethane foam over and in between the bits will lock the two halves of a cast firmly and will dramatically decrease the amount of new polyurethane used to foam out a cast.

As disadvantages, the polyurethane is 1) more expensive, 2) less available, 3) toxic after setting if the reaction is not complete (the dust is irritating to the skin and eyes), 4) it is combustible in its solid form, and 5) it is less controllable and manageable than plaster-of-Paris (the liquid is harder to control than a putty consistency).

Jacketing techniques are seldom reported; Leiggi *et al.* (1994), Schulp *et al.* (2001), Watabe *et al.* (2004) are some of the rare exceptions. Leigii *et al.* (1994, p. 75) described the traditional plaster jacketing technique. Schulp *et al.* (2001) is reported a technique where a steel collar was welded around a large block in order to remove it. One of the disadvantages of such a technique is that it requires welding in the field, which necessarily increases the logistics required. In Watabe *et al.* (2004) it is described a technique that although very safe for the block requires large quantities of plaster-of-Paris.





Fig. 7 – Field map. Each square scales 1m<sup>2</sup> in the field. Black – isolated elements; Grey – material composing the block.

### LABORATORY TECHNIQUES: MECHANICAL PREPARATION

Both an angle grinder and an electric grinder (also known as a hand grinder) were used during the preparation of ML433. This revealed to be very effective in the initial stages of block preparation due to the extremely hard matrix composition. The use of a high-speed rotation electric grinder instead of the traditional hammer and chisel reduces vibration and damage to the specimen. The conditions that

allow the effective use of these tools are 1) the contrast in colour between the matrix and fossil bones (in this case, the bone is black and the matrix is whitish, making it easy to use such heavy tools), and 2) the good preservation of the skeletal elements. Large quantities of matrix can be removed quickly using the electric grinder with minimal risk for the bone, but it is only advisable for the early stages of dismantling the block elements.

The use of the electric grinder releases a large quantity of rock dust, so working with dust

extractors and in highly ventilated areas is recommended. Good dust proof masks, gloves, plastic.

The electric grinder is composed of an electromagnetic motor that, through a shaft, transmits mechanical energy to a rotational diamond disk. Several techniques can be applied at different locations on the block relative to the position of the exposed bone:

1) "groove and break" (fig. 8A) is used when there is a high probability that what is being removed is exclusively composed of matrix. The grinder is used perpendicular to the matrix and 1 to 3 cm furrows are cut, producing a series of parallel grooves. The remaining matrix can be destroyed with the disk parallel to the matrix or with the airscribe, depending how close the exposed bone is. A long and pointed airscribe stylus should be used when applying the "groove and break" technique.

2) "polishing": with lateral movements on the matrix, slowly pulverizing the rock. This technique is used when unexposed bone is expected below the surface of the matrix (fig. 8B). It is still possible to use the electric grinder very close to the bone, but expertise is required when handling the grinder. It is important to have a side bar on the grinder to enhance grip, manoeuvrability and security. The grinder is held almost parallel to the matrix and hands must be firmly supported against the block. As

the rotating disk gets closer to the matrix, thin slices start to split from the block, and the bone remains preserved. If it is not possible to reach with the electric grinder or it is too dangerous to use this tool, then the airscribe can be used as an alternative. However, using the disk parallel to the matrix might enhance risk, since unwanted pressure is developed. Nevertheless, most of the grinders are designed for lateral pressures.

One of the disadvantages of this technique is that once a mistake is made, it is irredeemable, unlike the case when using chisel and hammer, as it is still possible to glue the pieces back together. On the other hand, the time spent during preparation using the electric grinder is much reduced. Because this technique releases large quantities of dust which obscures the bone it is important to keep the block as clean as possible (with an air exhaust system, vacuum cleaner, or compressed air pistol).

In a second approach, when the block was dismantled and the bones individually separated, lighter tools were used, namely: sandblaster and micro-airscribe. Both of these tools are widely used among fossil preparators, but during the preparation of ML433 they were used in very specific circumstances (e.g. when dealing with fragile bones, such as the dermal plates). Most of the bones have a perfect cleavage between the bone and the matrix.






Fig. 8 – Mechanical preparation techniques using angle grinder: A- “groove and break”, notice the perpendicular position of the angle grinder relative to the matrix ; B- “polishing”, aspect of the matrix after applying the “polishing” technique”.

### **LABORATORY TECHNIQUES: ADHESIVES AND CONSOLIDANTS**

Consolidants have been used during mechanical preparation, impregnating the bones with increased cohesion and strength to the bone. And, adhesives were used most of the times

post mechanical preparation, in order to glue separate pieces and fragments together. Consolidants and adhesives were widely used. Acrylic polymer resins diluted in acetone were mainly used were initially (brands: Plexigum® a product of the German company Rohm, Osteofix®, and Paraloid B-72), and subsequently the cyanoacrylates. Consolidant

concentration normally used was 10%v/v. Acrylic polymer dissolved in acetone was applied to the surface of the bones, which served as a nimpregnator, and cyanoacrylates were used as adhesives. Two-component epoxy adhesives were applied when the areas to be glued were larger than 10 cm<sup>3</sup>, or when gaps were present between the two surfaces. Epoxy glues seem to be a better gap filler since it has stronger binding properties, although it takes longer to dry (4-8h). However, cyanoacrylate adhesives were preferable than epoxy glues, since it allows a more controlled handling. The epoxy glues tend to oxidize superficially and turn into a n altered yellow colour with time (two years or more), which does not happen with acrylics.

Polyethylene glycol was used successfully, serving as a rigid reversible (soluble on water and liquefiable by heat) base to prepare the very fragile skull bones and osteoderms.

#### LABORATORY TECHNIQUES: ACID PREPARATION

---

Formic (HCOOH) and hydrochloric acid (HCl) were tried at different stages of preparation of the ML433 block and were not successful for gross initial preparation. During gross preparation, the rate of dissolution using formic acid was far lower when compared to the effectiveness of mechanical preparation. Furthermore, it endangered the bone most of the times. However, during final detailed preparation, such as removing sediment traces from the bone surface, acid preparation proved useful. Formic and hydrochloric acids (5-10%) were used.

Bath immersions of specimens for a period of 2 to 5 of hours in acid proved to be very effective. In such cases, tri-calcium phosphate was used as the buffer solution (see Braillon 1973, about the use of acids in fossil preparation). One should test the efficiency of the bath immersion first only for a few minutes, in order to use adequate proportions. Acid baths allow preparation in areas that are not reachable with physical methods.

#### INSTRUMENT MAINTENANCE

---

Regular maintenance of the instruments is highly advisable: this increases average longevity, effectiveness of the equipment, and it is more secure for the user.

In order to keep the electric grinder working properly, important routine tasks need to be carried out: 1) the interior of the engine should be sprayed daily through the ventilation slots with compressed air; and 2) every six months the rubber springs in the body of the grinder should be replaced, reducing the risk of engine damage.

The separate pieces of the airscribe were oiled and cleaned every day. A jet of compressed air is particularly effective to clean each separate piece. The stylus must always be sharp. A non-controlled experiment to test the effectiveness of a sharp airscribe stylus versus a non-sharpened one was performed: approximately three and a half times more matrix can be removed while maintaining the stylus sharp. A bench grinder is the recommended tool. Constant cooling of the stylus while sharpening is crucial to extend its longevity and maintain the properties of the tungsten stylus. To cool down the stylus, it is preferable to dip it in any kind of oil rather than water, since oils are better heat conductors. This procedure is recommended since hot temperatures reach while sharpening the stylus can alter significantly the properties of the tungsten.

#### MOULDING AND CASTING

---

##### Moulding

The partial preparation of the main block revealed an exquisite set of bones and it was decided to mould the block at this stage. Moulding a partially prepared block not only preserves precious taphonomical data, but also the cast is an informative way to show the different states of preparation for display purposes (fig. 9). A compromise had to be made between moulding the partially prepared block and the bones one by one in an economic way.



Fig. 9 – Main block cast, after being painted and mounted. The cast was painted with regular water-based colours. Note that the different pieces of the mould are not detectable, they were connected with screws, pieces of plywood and fibre glass mats with polyester resin.

Regular silicone rubber (RTV – room-temperature vulcanizing – which means it dries at ambient temperature) was used as a mould both for the individual bones and for the block. Polyurethane resin was used to cast the block (fig. 10). For individual bone casts both polyurethane resin (for small bones) and polyester resin (for larger bones) were used. Polyurethane resin is preferable for small casts because it is easier to handle: not only it hardens faster, but also when mixed with plaster it foams becoming adherent to the

surface of the mould keeping the details and texture.

A general moulding procedure using silicone rubber is described in Rigby and Clark (1965) and Goodwin and Chaney (1994). However, these techniques require a large quantity of silicone, meaning more costs and risk for the bone, especially when moulding intricate-shaped bones. The technique described in this paper makes use of a relatively thin layer when compared with the techniques given in the literature, and it is therefore a lot more economic. When compared with other materials

(e.g. latex) silicone rubber, although more expensive, is easier to detach from the bone or cast and shrinks in a lesser degree (Goodwin and Chaney 1994, p. 239). It is also flexible, long-lasting and strong.

ML433 block mould had to be made in three different parts, due to its large dimensions. A large mould is not only harder to handle, but also occupies lots of storage room. The mould

and supporting moulds should be attachable to each other. To achieve this, drill through the bordering walls of the contacting areas of the supporting mould and use bolts and screws. Each piece was moulded separately by raising putty-like modelling clay walls, which separated each part of the block to be moulded. A similar procedure as explained above was performed (fig.10).



Fig. 10 – Moulding the main block: A – raising modelling clay retaining walls; B – aspect of the block after applying the first layer of silicone; C – aspect of the mould once the second and third layers of silicone were applied; D – polyester resin supporting mould.



Fig. 11 – General procedure for moulding: A – defining thoughtfully where the mould should be divided, clay is used to separate the two parts of the mould; B – application of the first thin layer; C – in the second layer thixotropic additive is added, giving a yoghurt viscosity to the silicone; D – ladies stockings can be applied directly on the mould or pieces of cotton cloths can be embedded with silicone with a spatula before proceeding to its application on the previous layer of the mould; E – aspects of the mould with all the silicone layers applied; F – plastic film should be applied before making the supporting mould; G – aspect of the supporting mould once dried; H – on the other side, the final aspect of the silicone rubber.

As Fox (2003) noted, the first decisions (e.g. establishing the mould divisions and number of parts) and steps (e.g. filling voids, adhesives used) when moulding are fundamental to avoid damage to the bone. A general procedure to mould a medium-sized bone (e.g. vertebra, fig. 11) is as follows:

Before start moulding, all the preparation work should be completely done. Thus, the bone

should be well impregnated and stabilized with appropriate binding adhesives. Gaps should be filled with polyurethane putty or epoxy glue. Holes, like neural channels in vertebrae, should be closed with regular clay or modelling clay. The first layer (the most important) is composed of : hardener ( 5-7,5% w/ w), colouring powder and thixotropic additive (0,5 to 2% w/w; 0,5% is recommended for the first

layer). The colouring powder is used to check the effectiveness of stirring: the more homogeneous the colour, the better stirred the silicone is (fig.11B). Note that a temperature of approximately 20°C works best, however it varies between different types of silicone rubber. Use a light colour pigment for the first layer, so it can contrast with the bone and the subsequent layers. It is convenient to preheat the silicone rubber (1 litre for about 1 to 2 minutes in a microwave at maximum power). The silicone should be slightly warmer than room temperature. Apply the second layer on top of the first when the latter is almost dried and still sticky (use a greater percentage of the thixotropic additive, so it has a viscosity approximating yoghurt; maximum: 2% w/w). Impregnate small (10×10cm) pieces of nylon canvas (ladies' stocking is a good material for that) using a spatula. Ladies' stocking material can be used for intricate shapes. Alternatives are pieces of cotton cloth, or even pieces of anti-weed tissue. The silicone rubber can either be spread using a spatula or applied directly on the tissue with caution. Apply the impregnated tissue on the first two layers. Prominent areas should be reinforced with more layers of silicone or cotton cloth. Ladies' stocking material is flexible, resistant, porous and durable, all useful characteristics; however, it is relatively hard to apply because it is difficult to avoiding air bubbles (fig. 11D, E). Cotton cloth is easier to handle but less flexible. A fourth layer should be applied if the thickness appears to be too thin (this decision has to be made for each mould); the average thickness of a mould should be 5mm maximum.

#### Supporting mould casting in polyester resin

Once the silicone mould is made, and prior to its removal, a hard shell cover should be made in order to give support and keep the general shape. The technique corresponds to the following protocol:

- Cover the mould with a plastic film;
- To make the mould support, fibre glass mats impregnated with plain polyester resin are used. It is also possible to use plaster-of-Paris: a more environment-friendly solution but much less resistant and durable when compared to a polyester resin mould support;
- After stirring the polyester resin and the corresponding accelerator, the fibre glass mats should be embedded. Use an inexpensive brush and impregnate fibre glass mat pieces sweeping it on both sides. Apply the fibre glass mats onto the plastic film covering the mould; two to three layers should be enough (max 10mm), if 300g/m<sup>2</sup> mat is used.

It should be noted that one disadvantage of polyester resin is that it shrinks about 1% v/v. To solve that problem fibre glass mats impregnated with epoxy resin can be used instead.

#### Storing moulds

Since this technique makes use of a very thin layer of silicone rubber, some practical tricks should be carried out to prevent the deformation of the mould, and therefore the deformation of the next cast. For large bones (e.g. a bone from the appendicular skeleton) the borders of the mould should be attached with screws to a rigid polyester support (fig. 12). Fill the interior of the mould with toilet paper – for example – in order to keep the mould fitted as much as possible to the polyester support mould. Store the mould in a safe, constant-temperature room.

Effective storing moulds described in Jabo *et al.* (2006) were made and applied in the Smithsonian Vertebrate Paleontological collection.



Fig. 12 – Storing moulds: screws attach the silicone mould to the rigid polyester resin supporting mould.

#### Casting in polyester resin

The technique consists of applying three layers that, together make optimal use of the strength and flexibility of the polyester resin (fig. 13). Furthermore, polyester resin offers special characteristics which makes it useful for casting, not only it keeps all the detail from the mould, but it is also a very versatile material since it is chemically compatible with fibre glass, aluminium powder, calcium carbonate, *hollowfill*, etcetera. When combined in different proportions with these additives, polyester resin can be adapted to many different circumstances.

For a polyester resin cast, the following procedure is generally applied:



- The first layer should be more liquid than the subsequent ones, giving the base coat the shiny characteristics of fossil bone, but most importantly the surface details. Furthermore, the right colour pigments mixture will have great relevance in the final appearance and visual texture of the cast. To prepare it, one should use: *hollowfill* (e.g. Dacron®) working as a thixotropic powder (25-100% v/v), plus the peroxide catalyser (1-4%w/w; lower

concentrations when room temperature is higher than 20°C, and higher concentrations when applying thick layers, or in cold temperatures). In some instances other additives can be used such as calcium carbonate powder, aluminium hydroxide powder, or glass spheres that in different quantities produce different characteristics;



Fig. 13 – Casting: A – using a pouch as a pastry bag containing polyester resin; notice the piece of steel wire inside the mould, providing a rigid structure to the cast. B – applying polyester resin; this layer serves as the base colour for the subsequent painting (photos by Pedro Viegas).

- The main purpose of the second layer should be to even out the surface. This layer makes use of the same components, but it should be a thicker, more viscous liquid. Thixotropic powder stone filler (e.g. calcium carbonate powder or chalk) has been used; 10-50% w/w;
- Spread a layer of fibre glass chopped strands on top of the second layer while still moist to structurally reinforce the first layers;
- The fourth layer is made by plain polyester resin and fibre glass mats. The fibre glass mats are impregnated from both sides on the working table (not on the cast) and then applied directly onto the other three layers. Tear pieces of fibre glass by hand instead of cutting with scissors, so the fibres are loosened. Once the polyester resin is applied, leave the mat and wait for 1 to 2 min until it becomes flexible. The mats should be applied at least 2cm over the edge of the cast. Two to three layers of fibre glass mats are

normally enough (with 300g/m<sup>2</sup> fibre glass mat);

- While the impregnated fibre glass mats are still hardening it is possible to cut them with a Stanley-knife along the edge (1 to 2h after the last layer);
- Wait a few hours to remove the cast from the mould; it still should be a little flexible. Waiting overnight is not advisable since the cast would get too rigid;
- In order to join the two parts of the cast together, one can screw pieces of plywood (5×5cm) on the inner surface of the cast with embedded fibre glass mats (5 or 10 wooden pieces per meter). Additionally, one can use thin metal strips with holes that are screwed through the bone holding the two halves. This way, the two halves of the cast will be firmly held.

### Filling with polyurethane

- Roll a piece of moist grey clay into a cylinder shape. Apply it on the space between the two halves of the cast, in order to avoid the polyurethane foaming out. The polyurethane will be applied in the next step, and if it comes out it is likely to ruin the detailed surface of the cast.
- Drill a 2cm wide hole through the cast.
- Mix a small amount of polyurethane foam and pour it through the hole. This step should be done at least three times, since an excess of polyurethane can damage the detailed surface of the cast. Wait 10 minutes and remove the clay once the polyurethane foam has reacted entirely.

### Finishing the cast

- To fill the space that separates both halves of the cast, tinted polyester putty has been used successfully. It is also possible to use car body filler but it is difficult to tint the right colour and it is necessary to use much more colouring pigment powder. Preparing polyester putty requires: plain polyester resin, thixotropic powder (1000g – 25-50% v/v), gel coat (1000g 10-50% v/v), colour (pre-mixed with polyester or powder), cobalt (2-10% w/w; it works as a catalyser), and peroxide hardener (2-3%). Mix the cobalt before the hardener;
- Once the polyester putty is made, use a plastic or rubber pouch or bag as a pastry bag (fig. 11A). Cut with scissors the corner (5mm) of the pouch. Spread some putty in the pouch and squeeze it a long the space separating the two halves of the mould;
- Before it starts to harden use paint thinners (e.g. acetone) and a soaked brush on it. Manipulate the putty with the brush, creating detail on the cast surface as needed. Always keep the brush well saturated;
- After it sets, remove excess polyester putty with sandpaper. A hot air gun can be used so that the putty becomes viscous again, making it possible to scrape it off;
- To give different tonalities to the cast it can be painted in layers with a water-based acrylic. The first layer takes away the shiny appearance of the polyester resin; the second layer can be applied with a "dry brush" method. The "dry brush" method consists of: 1) spreading some water-based acrylic on a board (whitish/yellowish ochre), 2) stirring the brush on the board so the brush is coated with paint evenly, and the

paint is almost dry, and 3) gently painting the cast, highlighting the natural structure of the bone. Applying two or three more layers should result in a great resemblance to the original bone.

- If the cast is going to be exposed outdoors, the polyurethane will require a UV-protection coat. Since the UV-protection is normally very shiny, add talc powder (5-10% w/w) to its original composition. This procedure allows complete mounting of skeletons in a quick and inexpensive way (fig. 14).

A few notes will be considered attending polyurethane resin. It is preferable to use polyurethane resin to cast bones no larger than 20cm. This happens because polyurethane resin is easier to handle and mix. If it is desired, anyway, to use polyester resin for small bones it is necessary to use special fillers and to control the heat produced during polymerization. Polyurethane resin, in the other hand, is much harder to handle for large surface bones due to its rapid set time, leaving no possibility to spread it evenly on the bone. If used for small bones with a mixture of plaster it has excellent results, giving the internal appearance of bone. Polyurethane resin was firstly described for paleontological purposes by Jansen (1961). The first two layers determine the quality of the cast but also the final appearance of the polyurethane resin. The colour of the first layers should be chosen carefully, reflecting the outer tonalities of the bone; the second layer is the base colour. When the second layer is applied – while the first layer is still wet – it gives some heterogeneity in the final aspect of the cast. This situation is desired since fossil bones do not have a homogeneous colour.

As noted, polyurethane resin has also been successfully applied but only for small casts or intricate structures. It is a two component compound, and when mixed with dried regular plaster in equal proportions it foams. If 1 or 2 drops of water are added it will have a similar effect. The stirring should be as homogeneous as possible, and for that purpose we recommend a drill with a mixer attached. Polyurethane resin is particularly effective when poured in single orifice moulds.




Fig. 14 - Mounted skeleton of the stegosaurian dinosaur ML433.

#### Further notes on the casting procedure

To accomplish the casting procedure successfully:

- Two people are preferred for this task; casting and moulding is a complex and difficult task, thus the cooperation between two people reveals much more effective. The division of the sub-tasks (e.g. stirring up components, brushing, applying chop strands, etcetera) should be consistent during the entire process;
- Use gas mask, latex gloves and a lab coat (see "Health and protection issues" section). Either polyester and polyurethane resin are extremely noxious while polymerizing;
- If it is necessary to save the brushes they should be immersed in thinner and cleaned

with a spatula or metal brush long before the polyester or polyurethane resin dries up (polyurethane resin has a faster period of drying). In order to do that use a clean and plain surface, put the brush obliquely to the surface and scrap vigorously several times with the spatula until all the liquid polyester is removed. Then dip the brush in thinner for 12h. To reuse brushes used in moulding a brush with metallic bristles, and scrap vigorously the already hardened silicone off against a clean and plain surface;

- All of these components are easily accessible. They are widely used for fibre glass boats industries, for example.



Fig. 15 – ML433 digital cervical vertebra, all the anatomical structures can be easily understood using 3D scanning.

### 3D SCANNING

In order to have anatomical information in digital format, the 14th cervical vertebra of ML433 was digitalized using a laser non-contact digitizer scanner Minolta Vivid VI-910 (fig. 15) with the assistance of the company Scorzio/B'Lizzard Ltd. The scanner combines the 3D surface information, acquired by a laser beamer, and real colour acquired using an incorporated photographic camera. The information obtained during each scan was a polygon representing the bone surface from that perspective. The vertebra had to be scanned in multiple perspectives in order to gather information on all sides and surfaces of the bone. Each individual scan was merged into a single analysis that gathered all perspectives, providing a complete tri-dimensional digital vertebra.

The digital vertebra file can be exported to several 3D file formats including \*.stl, which allows rapid prototyping into real 3D. An optimized polygonal version was saved into an executable file permitting easy access and visualisation.

The data in the post-processing stage covers a large number of possible options. The basic options are essentially aligning and merging the unprocessed data into a complete, solid triangle mesh. The final step in the post-processing procedure is to export the completed mesh into the 3D file format and resolution desired.

This technology has as multiple uses: 1) to produce objects appropriate for cost-effective rapid prototyping; 2) to generate \*.cnc machining paths from the object; 3) to generate 2D images of the object with optimal lighting for use within publications or on web sites; and 4) to generate 3D objects with optimal lighting for use within Kiosks or on web sites.

Advantages: 1) the scanner is portable and compact, it is possible to use it outdoors (although uncontrolled daylight is not ideal for scanning); 2) because it is a non-contact scanner the output is quickly acquired, being more effective and ideal for sensitive objects; 3) the resolution of 307.000 points each 2,5 seconds allows fast digitizing in very large objects; and 4) the file with the scanned bone morphology is easy portable.

Disadvantages: the data processing requires specialized skills that are time consuming or costly.

### HEALTH AND PROTECTION ISSUES

Field and laboratory work raises some health issues. Some suggestions are given here:

- Keep a complete and updated first-aid kit always easy accessible.
- Users of heavy equipment, such as jack hammers and angle grinders, should have adequate training and supervision, and always wear suitable eye, ear, hand, and respiratory protection. A dequate clothing should be used as well.
- Chiselling should be done with large-headed hammers. Classic geological hammers are not suitable for chiselling.
- Polyurethane should be handled with hand and respiratory protection.
- Acid baths should be conducted in a fume hood, with skin, eye and respiratory protection.

### FINAL REMARKS

#### **Making a field jacket for a large monolith**

We described an alternative to the traditional plaster-of-Paris field jacket. The main advantages of the described jacketing technique were: a significantly lighter than a traditional jacket; a thick and flexible protection for the block against shocks; it can even out irregularities in the shape of the block that could make it more fragile; a shortening of the time taken to make it and to have it become solid enough for transport. Exposed bones are covered tightly in a traditional way with aluminium foil or wet paper. Then a thin layer of plaster-soaked burlap was applied to seal of the bone completely. A frame, consisting of hollow iron tubes welded (or tied) together, is placed over the block to provide rigidity. Cardboard walls were raised around the whole block and sealed off at the bottom with earth. Two component polyurethane foam is then mixed and poured into the sealed off area. As the foam quickly grows and solidifies, the monolith and the metal frame are firmly interlocked to form a solid field jacket.

Also, whereas a rotational cutter is mostly needed in order to open a traditional plaster-of-Paris field jacket, a polyurethane field jacket can be opened very quickly and easily using a large knife or a saw.

#### **Mechanical preparation**

Airscribes of various sizes and power are used in most preparation laboratories, with great success. When working close to the bone or exposing embedded bone, they are strong yet

precise. However, when working far from the bone and in hard matrix the progression is very slow and unnecessarily wears on expensive machines. Generally hammer and chisel would be used in such a case, but this can create vibrations that may damage fragile specimens (the same goes for powerful air scribe; e.g. Mightyjack®). When acid preparation is not effective, then an electric grinder can be a very powerful tool, and can be used in several ways to eliminate large quantities of matrix quickly and with a minimum of vibrations. The electric grinder was mainly used in two ways: 1) "groove and break": producing a web of swallow vertical grooves with the grinder and then breaking of the small knobs that remain between the grooves using a chisel gently or using an air scribe. 2) "polishing": using sub-horizontal movements to slowly pulverize the rock, to rapidly decrease the thickness of the rock over the bone.

### Moulding of a bonebed

Moulding a partially prepared block or bonebed not only preserves precious taphonomical data, but also creates an impressive and informative display item for an exhibit. It is suggested to make several individual moulds in order to keep down the weight and therefore make the moulds easier to handle and to store. A complete protocol for making thin and strong high quality silicone moulds is detailed, including advices for making the support moulds and storing the moulds. The suggested protocol makes use of a multi-layer approach and reinforces this thin mould internally with silicone-soaked cloth. Advantages include: using relatively small quantities of silicone, which reduces the cost and making very strong and thin moulds, which can easily be extracted from holes and undercuts.

### Casting techniques

A complete protocol for making high quality, cheap and strong, medium to large sized, casts using a combination of polyester and fibreglass is specified. A four layer approach is presented. First a thin liquid layer of polyester is applied to fill in all the details and avoid air-bubbles. A second more viscous layer is created by mixing calcium carbonate powder, aluminium hydroxide powder, or micro glass spheres into the liquid polyester. Chopped strands of fibreglass are sprinkled over the second layer while it is still sticky and after some minutes (when they have begun to disintegrate), they are touched-over gently with a brush soaked in polyester with low viscosity. Finally, fibreglass mats are soaked in thin

polyester and placed on all the surface and after some minutes they too are touched-over gently with a brush soaked in thin polyester liquid. Tips for colouring, including a double coloured basecoat, are also included.

### 3D scanning

To test the usability of a hand-held 3D scanner to help acquire morphological information and store it in a digital format, one of the vertebrae of ML 433 was scanned. An optimized polygonal version was saved into an executable file permitting easy access and visualisation. This test helped open our minds to possible applications of such methods.

## PERSPECTIVES AND POSSIBLE IMPROVEMENTS

---

### Monolith

A way to improve the transport of the monolith is that it is possible slide wooden bars, shovels or other tools into the hollow iron structure. These provide excellent grip for lifting and transport such block. One could imagine having especially constructed bars with wheels attached at their ends, that one could slide into the holes.

Since polyurethane foam remains relatively brittle, one could strap a net over the outside of the polyurethane in order to increase the rigidity of the block.

### Mechanical preparation

Some alternatives to the grinder do exist. However, there are several disadvantages: 1) lack of power for heavy duty work (e.g. Dremel®), so if pressed too hard they might stop or jump backwards - which is dangerous both for the user and for the fossils; 2) cylindrical design (e.g. Dremel®), which makes them manoeuvrable, but provides a poor grip.

One of the advantages of using a grinder is that the rotational plan of the disk follows the length of the operator's arm, i.e. it enables the preparator to operate for longer periods of time without exhausting. Whereas the rotary cylinder design goes perpendicular to the arm of the preparator, meaning wrist muscles are required.

The thickness and broadness of conventional grinders at the attachment point of the disk is one of the most limiting factors, since it makes it impossible to reach some places.

It would probably be possible to produce a tool that was more adapted to vertebrate paleontological preparation than a traditional

grinder. It should be more resistant to lateral torsion on the disk as this sort of pressure is created when "polishing". So far, it has been only used regular rock cutting disks, but other types (e.g. like those used for polishing metal) could also be used. If a special tool was created it would probably be possible to create special disks that would be better adapted for the different tasks. However, a traditional grinder is relatively cheap (nowadays it can be bought for 20€, two years warranty) and can be acquired in almost any hardware shop.

### 3D scanning

The experimental 3D scanning work presented here projects to the future possible pathways for the usage of this technology in aiding effectively preparation. As hand-held 3D scanning devices become less expensive, it is likely that they will become integrated in routine laboratory and field work. One could track the whole preparation process and it would also be possible to create 3D field maps in this way. An advantage is that it will enable to repeat the process several times, in order to visualize the advancement of work and to envisage clearly what bones lay under others as the preparation advances.

As for scanning bones completely after full preparation, it would be a huge leap ahead for scientists to be able to visualize all bones of a skeleton in 3D digital format, instead of comparing photos and notes like as it is done now. It can cut down on travel costs to see specimens and it would permit for a accurate comparison of already studied specimens.

### ACKNOWLEDGMENTS

We are grateful to all those that helped in the excavation, preparation and mounting of this specimen, in particular Rui Soares, Inês Fernandes, Rui Castanhinha, Dean Wright, Marisa Amaral, Rui Lino, Bruno Pereira, Dennis Roessler, Alexandra Tomás and Plamen Ivanov. We thank Pedro Canavilhas and his team, who were essential in the 3D technology part. To Simão Mateus that provided the fig. 2, and to Pedro Viegas, Alan Lam and Jesper Milán who kindly provided us some photographs. We are also grateful to Susannah Maidment, who reviewed the manuscript.

### REFERENCES CITED

- Antunes, M.T. and Mateus, O., 2003.** Dinosaurs of Portugal. *Comptes Rendus Palevol*, 2: 77-95.
- Braillon, J., 1973.** Utilisation de techniques chimiques et physiques dans le dégagement et le triage des fossiles de vertébrés. *Bulletin du Muséum National d'Histoire Naturelle*, 3<sup>e</sup> Série, 176, Sciences de la Terre 30 141-166
- Carpenter, K., Madsen, J. and Lewis, A., 1994.** Mounting of fossil vertebrate skeletons. In Leiggi, P., and May, P. (eds.). *Vertebrate Paleontological Techniques*. Cambridge University Press, NY, 285-322.
- Fox, M., 2003.** Basics of moldmaking – filling and mold design considerations. *Journal of Vertebrate Paleontology*, 23 (supplement 3): 51A.
- Goodwin, M.B. and Chaney, D.S., 1994.** Molding and casting: techniques and materials. In Leiggi, P., and May, P. (eds.). *Vertebrate Paleontological Techniques*, Vol. 1. Cambridge University Press, NY
- Jabo, S.J.; Kroehler, P.A. and Grady, F.V., 2006.** A technique to create form-fitted, padded plaster jackets for conserving vertebrate fossil specimens. *Journal of Paleontological Techniques*, 1: 1-6.
- Jansen, J., 1961.** A new casting medium for use in flexible and rigid molds. *Curator*, 4(1): 76-90.
- Leiggi P., Schaff C. R. and May P., 1994.** Field organization and specimen collecting. In Leiggi, P., and May, P. (eds.) *Vertebrate Paleontological Techniques*, Vol. 1. Cambridge University Press, p. 59-76.
- Leiggi, P. and May, P., 1994.** *Vertebrate Paleontological Techniques*, Vol. 1. Cambridge University Press. NY.
- May P., Reser P., Lieggi P., 1994.** Laboratory preparation. In Leiggi, P., and May, P. (eds.) *Vertebrate Paleontological Techniques*, Vol. 1. Cambridge University Press, p.113-128.
- Mateus, O., 2006.** Late Jurassic dinosaurs from the Morrison Formation, the Lourinhã and Alcobaça Formations (Portugal), and the Tendaguru Beds (Tanzania): a comparison. in Foster, J.R. and Lucas, S.G.R.M., eds., 2006, *Paleontology and Geology of the Upper Jurassic Morrison Formation*. New Mexico

Museum of Natural History and Science  
Bulletin 36: 223-231.

**Mateus, O. and Araújo, R., 2008.** Stone-Splitters and expansive demolition agents in vertebrate paleontological excavations, *Journal of Paleontological Techniques*, 3:1-6.

**Mateus, O., Maidment, S. and Christuansen, N., (in press).** A new long-necked 'sauropod-mimic' stegosaur and the evolution of the plated dinosaurs. *Proceedings of the Royal Society of London B*.

**Rigby J. K. and Clark D. L., 1965.** Casting and Moulding. *In* Kummel B. and Raup D. (eds.) *Handbook of paleontological techniques*. p.389-413.

**Schulp A. S., Jagt J. W. M., Dortangs R. W., Hofman A., Philippens J., 2001.** An alternative to plaster jacketing in extremely large vertebrate specimens. *Journal of Vertebrate Paleontology*, 21 (supplement 3): 98A.

**Serviços Cartográficos do Exército, 1946.** Carta Militar de Portugal: folha 3 49 Lourinhã. Escala 1:25 000

**Watabe, M., Sonoda, T., and Tsogtbaatar, K., 2004.** The monolith - A method for excavation of large-sized dinosaur skeletons Hayashibara Museum of Natural Sciences Research Bulletin 2:29-43.

Additional images and material can be downloaded at <http://www.jpaleontologicaltechniques.org/>