

Research Directions on the Pegasus Toroidal Experiment

J.A. Reusch

G.M. Bodner, M.W. Bongard, R.J. Fonck, C.M. Pierren, A.T. Rhodes,
N.J. Richner, C. Rodriguez Sanchez, C.E. Schaefer, J.D. Weberski



University of
Wisconsin-Madison

60th Annual Meeting of the APS
Division of Plasma Physics
Portland, OR

9 November 2018




PEGASUS
Toroidal Experiment




Non-Solenoidal Startup Remains a Critical Need for Spherical Tokamak, and May Benefit AT

- PEGASUS research program has focused on LHI
 - Local DC helicity injection + poloidal field induction
 - Demonstrated $I_p > 200\text{kA}$ with $I_{inj} < 8\text{kA}^*$
- Need for dedicated facility for NS startup studies
 - LHI/CHI/RFCD/PF induction and others
- Enhancements to PEGASUS will provide a dedicated development station for non-solenoidal startup


Pegasus HFS LHI



$$I_p \sim N_{turns} I_{inj}$$




$$I_p \gtrsim N_{turns} I_{inj}$$



$$I_p \gg N_{turns} I_{inj}$$

RF Startup Experiments

RF Method	Device	I_p [kA]
ECH + PF induction	DIID-D	166
	JT60-U	100
ECH	QUEST	70
	DIID-D	33
	KSTAR	15
ECH + LHCD	T-7	20
EBW	MAST	73
	LATE	15
LH	PLT	100
	TST-2	25
	GLOBUS-M	21



NSTX Transient CHI





URANIA Experiment: Converted PEGASUS Facility for US Non-Solenoidal Startup Development Station

- Mission: compare / contrast / combine reactor-relevant startup techniques
 - Goal: guidance for ~ 1 MA startup on NSTX-U, beyond
- PEGASUS to URANIA:
 - New centerstack and divertor assembly
 - Next generation LHI injectors
 - Transient, Sustained CHI (w/ Univ. Washington, PPPL)
 - EBW RF Heating & CD (w/ ORNL, PPPL)
 - Improved diagnostics including diagnostic neutral beam



URANIA Experiment

Collaborative Enterprise:






Heart of the Facility Enhancement is New TF Assembly

Parameter	PEGASUS	URANIA
I_{TF}	0.288 MA	1.15 MA
N_{TF}	12	24
ψ_{sol} (mWb)	40	0
R_{inner} [cm]	5.5	12
TF Conductor Area [cm ²]	13.2	151
$B_{T,max}$ [T] at $R_0 \sim 0.4$ m	0.15	0.60
B_T Flattop [ms]	25	100
ΔT_{bundle}	< 10°C	< 40°C
R_0 [cm]	45	48
A	1.15-1.3	1.33-1.4


URANIA Concept Drawing




PEGASUS




High-Stress OH
Solenoid
12-turn TF Bundle



URANIA



Solenoid-free
24-turn TF
Bundle







Local Helicity Injection on URANIA Will Test Critical Scalings for Extrapolation to Larger Scale

- LHI physics basis at increasing B_T
 - MHD, I_p scaling and CD mechanism
 - Electron heating and confinement
 - PMI
 - Compatibility with subsequent sustainment
- Injector technology
 - Large-area
 - Low V_{inj}
 - High B_T
 - Longer pulse

$I_p > 0.2$ MA Demonstrated on Pegasus



0-D Power-Balance Projections for URANIA




LFS System



HFS System

Injected Current Stream

Local Helicity Injectors








High- B_T of URANIA Facilitates Coaxial HI Studies

- CHI utilizes coaxial passive electrodes
 - RF heating compatibility
 - Target plasma characteristics
 - Flux conversion efficiency (T-CHI)
- Next-Gen CHI systems
 - Transient and sustained CHI capability
 - No vacuum vessel break
 - Flexible, segmented floating electrodes
 - Refractory metallic electrodes initially
 - Consider active (LHI-like) electrodes

Vacuum Field for 300kA Transient CHI on URANIA



Pre-Conceptual Segmented CHI Electrode Design on URANIA







RF/EBW for Startup and Sustainment

- ~ 400 kW EBW, 8 GHz
- Synergy of heating with LHI/CHI
- Explore EBW CD as handoff tool
- Direct RF current drive for startup
- High T_e for non-inductive sustainment (e.g. NBCD)
- Pre-ionization for PF induction experiments

Favorable wide range of injection angles for O-X-B



*GENRAY, CQL3D Modeling Indicates
Core Absorption for EBW Heating, CD*






Improved Diagnostic Suite of URANIA Facilitates Physics Understanding for Extrapolation to Larger Scale

- DNB spectroscopy
 - $B(R, t), J(R, t), T_i(R, t), n_z(R, t),$
 $v(R, t), n_e(R, t)$
- Impurity diagnostics
 - SPRED
 - Bolometry
- Insertable probe arrays
 - 3D magnetics (Hall, \dot{B})
 - Langmuir, Mach, Rogowski

Diagnostic Layout for URANIA






Broadening Studies of Non-Solenoidal Startup on PEGASUS with Transition to URANIA



- **Evaluate leading concepts for non-solenoidal startup in single dedicated facility**
 - Local Helicity Injection
 - Coaxial Helicity Injection (Transient, Sustained)
 - EBW startup and assist
 - Poloidal Field Induction
 - Future: NBI heating and current drive
- **Develop common understanding & validation of all approaches**
- **Goal: develop validated concept, equipment for ~ 1 MA startup on NSTX-U and beyond**



Collaborative Enterprise:



WISCONSIN
UNIVERSITY OF WISCONSIN-MADISON



UNIVERSITY of
WASHINGTON

