

NaI(Tl+Li) Neutron-Gamma Scintillator

NaI(Tl) crystal containing ^6Li for neutron detection

NaIL is a game-changing scintillation material for gamma-ray and neutron dual detection. ^6Li (95% enriched) co-doping introduces efficient thermal neutron detection to the most established gamma-ray scintillator while retaining the favorable scintillation properties of standard NaI(Tl).

Excellent solution for area monitoring

Up to 57% efficient for thermal neutrons

Similar gamma ray performance as standard NaI:Tl

The NaIL advantage

Uniquely, NaIL can provide large volume, single material detectors for both gammas and neutrons at low price per volume. Consider the following:

- It is easy and cost effective to grow large NaI crystals.
- Sodium and iodine barely compete with ^6Li for neutron attenuation.
- Using low ^6Li concentrations and large thicknesses achieves neutron detection capabilities as good as ^3He or CLYC or CLLB detectors at a lower cost.
- Large volume detectors add efficient gamma ray spectral detection. There is no longer a need to compromise on the detectability of one specie to be efficient for the other.

Material	NaI:Tl + 1% ^6Li
Density	3.66 g/cm ³
Decay constants gamma neutron	240ns, 1.4 μ s 230ns, 1.1 μ s
Light yield	35k photons/MeV
Thermal neutron GEE	3.2 MeV
Peak emission wavelength	419 nm

*Currently in pre-commercialization phase
and material performance subject to change.*



50x100x200 mm³
2"x4"x8" NaIL

CRYSTALS



SAINT-GOBAIN

NaIL™ Neutron-Gamma Scintillator

Straightforward gamma and neutron separation

Neutrons and gamma rays are easily distinguished through pulse shape discrimination (PSD). With the addition of Li into the NaI matrix, gamma ray scintillation pulses become longer than neutron reaction pulses. The effect is dramatic, and simple PSD techniques create complete separation.


When considering neutron detection capability, often the metric $A \cdot \epsilon$ is used. A is the detector area and ϵ is the probability of detecting an impinging thermal neutron. When price and gamma detection ability are factored in, NaIL often becomes the best solution.



Detector	n_{th} detection capability $A \cdot \epsilon$ (cm ²)
NaIL \varnothing 50 x 50 mm	13
NaIL \varnothing 50 x 100 mm	26
NaIL 50x100x400 mm ³	216
³ He \varnothing 13 x 50 mm, 8 atm	7
³ He \varnothing 50 x 1830 mm, 2.9 atm	613
CLYC \varnothing 50 x 50 mm	20
CLLB \varnothing diameter 50 x 50 mm	22

Relative to standard NaI:TI performance

The scintillation properties of standard NaI(Tl) are preserved. Energy resolutions of 6.5-8% at 662 keV are typical even for large crystals. Light yield is slightly lower, but still substantial at approximately 35k photons/MeV. Furthermore, the scintillation properties of NaIL degrade less at high temperature than standard NaI(Tl).



SAINT-GOBAIN
Saint-Gobain Crystals
www.crystals.saint-gobain.com

Currently in pre-commercialization phase and material performance subject to change.

Manufacturer reserves the right to alter specifications.

©2017-2019 Saint-Gobain Ceramics & Plastics, Inc. All rights reserved.

(06-19)