

SECOND EDITION

PRECISION AQUEOUS CLEANING OF: VINYL RECORDS



By: Neil Antin

Copyright© 2021-Neil Antin. Some Rights Reserved. Institutions and individuals are free to download and print this document for use. No rights are extended to distributing, altering or modifying this document beyond individual use. The effectiveness of the cleaning process(es) specified herein have not been compared to other commercial products and no guarantee is implied or intended that they will meet the needs of all users. Institutions or individuals who prepare, use or modify the process(es) herein do so at their own risk. No person or affiliate associated with the cleaning process(es) specified herein will be liable for any injury to any person, animal, or ecosystem, or for damage to any item resulting from the use of any of the materials, chemicals, or procedures described herein.

MARCH 2021

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

FOREWORD

This document is provided as an effort to “give back” to the communities in which I spent my career and life as an engineer with the U.S. Navy engaged in precision cleaning techniques and as an audio enthusiast who has witnessed increasing interest in effective cleaning methods for vinyl records. It is provided for those intrepid souls who receive enjoyment from the audible and physical experience that is uniquely part of listening to music reproduced by a vinyl record.

Six years ago, after a 20-year hiatus, I returned to the unique experience and challenge of listening to vinyl records. My initial reentry was less than stellar, but by combining my background, perseverance and an appetite for knowledge an effective, simple, economical, and safe vinyl record manual cleaning process was developed. This second edition of the paper continues to document the journey, and is offered with no expectations other than an opportunity to share knowledge. However, it is my observation that, to effectively clean a vinyl record, a precision cleaning process is required and what lies within the grooves of a vinyl record may have yet to be fully realized.

In this second edition, I have taken into account the feedback I received from readers who had posed questions and comments on the various audio forums about the first edition of May 2019; I benefitted significantly from that in shaping this revised edition to better meet reader needs. Additionally, the paper expands upon many of those general discussions to delineate the many details with a deeper understanding of the ‘why’. The previous edition’s use of ‘Sections’ has been changed to ‘Chapters’ with other format improvements for ease of use and the following changes have been made.

- Chapter I addresses the challenge of cleaning a vinyl record has been expanded to discuss and show examples of record wear.
- Chapters II to V detail the manual cleaning procedure. Chapter II has been modified to add polyvinyl-alcohol (PVA) clean room sponge, disposable pipettes and some alternatives for those in the EU/UK. Chapter III has been modified for those in the EU/UK. Chapter IV has been expanded to show additional ultraviolet (UV) light pictures of records. Chapter V has minor modifications to address technique when cleaning, and use of the PVA sponge for drying with some revised photos for clarity.
- Chapter VI addresses maintenance of cleanliness and has been extensively revised with expanded discussion of static.
- Chapter VII discusses water quality and has been revised to show why water better than demineralized/distilled is not required, and addresses methods and the cost associated with home production of distilled or demineralized water.
- Chapter VIII discusses pre-cleaner chemistry and has been extensively revised to address isopropyl-alcohol, anti-static and biocide solutions, and adds discussion of mold and scale, and of the more popular do-it-yourself (DIY) compositions.
- Chapter IX discusses final cleaner chemistry and has been updated to include BASF™ DEHYPON® LS-54 a non-ionic surfactant available only to consumers in EU/UK, and Tergikleen™.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

FOREWORD (Cont'd)

- Chapter X discusses material compatibility and has been completely rewritten based on the details of the RCA™ record composition and a Hansen™ solubility parameter analysis.
- Chapter XI addressing industry cleanliness levels and how they relate to a vinyl record has been completely written and retitled as “Discussion of Cleanliness Criteria”. An error in the table showing soil film thickness was corrected and detailed analysis of the record groove velocity and resultant amplitude has been added to justify the rationale for the recommended cleanliness criterion.
- Chapter XII which discusses the overall cleaning process retains the information that was in Section XI.
- Chapter XIII that now discusses vacuum record cleaning machines (RCM) has been revised to add images and a table describing the various design features and to reflect lessons learned.
- Chapter XIV that now discusses ultrasonic cleaning machines (UCM) has been extensively revised adding new information on the ultrasonic cleaning process and lessons learned.
- References are identified in each instance and the full citations are hyperlinked for download in the **APPENDIX C - RECORD OF CHANGES** at the end of this paper. Hyperlinks are provided only to secure (<https://>) sites.

Some of the contents of this paper, which has grown from a monograph to what amounts to a handbook on record cleaning, may be considered too detailed or excessive. No apologies are made; the devil is in the details and documenting those details provides others with the opportunity to explore. One reaction from a lot of readers was “At last, a highly detailed and comprehensive document on record cleaning!” Many readers were lacking good information on the processes and the rationale for using one chemical over another, and their trial-and-error attempts to improve results were not guided by a sufficient understanding of either the chemistry or the process. For those who found the first edition to be overwhelming in its detail, there are a number of “off-ramps” which enable you to take advantage of certain processes described here or improve some aspect of your cleaning regimen without entirely changing what you do (Cleaning a vinyl record is similar to the overall audio upgrade journey in this respect—you can make changes incrementally with certain elements remaining constant to have some control over results). At its simplest there is a core approach outlined in Chapters II to VI which provides anyone with just reasonable skill and cost, the opportunity for clean, mostly extraneous noise-free, high fidelity vinyl record play achieved easily and safely; record pressing quality notwithstanding. And once cleanliness is achieved, using reasonable care and appropriate practices, easily maintained.

All cleaning procedures specified herein are presented as only “a” way to clean a record. No claim is made there is only one way to approach the process. All methods/procedures specified here present opportunity for experimenting with different cleaning agents, different cleaning brushes, different drying cloths, and different cleaning equipment, and future revisions will continue to take into account the community feedback from forums such as Audiogon®, Audiokarma®, VinylEngine®,

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

FOREWORD (Cont'd)

The Steve Hoffman Forum™, The VinylPress™ and VPI™, to name just a few. If you proceed down this path, the information provided by this document will guide you to informed decisions that adheres to the three axioms when cleaning:

- ✓ **Do No Harm to Yourself or Others; and**
- ✓ **Do No Harm to the Item Being Cleaned – the Record; and**
- ✓ **Do No Harm to the Environment**

Wishful Thinking: Everyone wants the silver bullet – the single cleaning solution. There was only one safe, nonflammable, cheap, superior solvent ever manufactured that could degrease and remove fine particulate in one step with a boiling point low enough to dry quickly leaving essentially no residue, and compatible with just about all materials - 1,1,2-Trichloro-1,2,2-trifluoroethane (CFC-113), often known as Freon® PCA (precision cleaning agent). Unfortunately, chloro-fluorocarbon CFC-113 had this “small” problem with damaging the ozone layer, and by the Montreal Protocol of 1986, all manufacture stopped 1996. In its place were created the many equivalent aqueous cleaning processes now in-use. As a note of caution, non-flammable, high performance chlorinated hydrocarbon solvents such as perchloroethylene that are still manufactured; and easily purchased, are not CFCs but are highly toxic and known to cause cancer among other unpleasant effects.

Author Bio: Mr. Antin volunteered his time to prepare this document and is a retired Naval Sea Systems Command (NAVSEA) Technical Warrant who from the late 1980's for 20-years was the NAVSEA technical authority for *MIL-STD-1330 Precision Cleaning and Testing of Shipboard Oxygen, Helium, Helium-Oxygen, Nitrogen, And Hydrogen Systems* and *MIL-STD-1622 Standard Practice for Cleaning of Shipboard Compressed Air Systems*. During the early 1990's he led the NAVSEA effort to mostly eliminate chlorofluorocarbon (CFC) solvents from these military standards. His efforts were successful and are documented in *MIL-STD-1330D* and *MIL-STD-1622B*, and acknowledged with an EPA Ozone Protection Award 1995, two US Patents US 5427729 and 5520837, and NAVSEA Engineer of the Year 1997. The procedures and discussion detailed herein follow many of the fundamentals and practices that were developed for *MIL-STD-1330D* and *MIL-STD-1622B*. After his turn at precision cleaning, Mr. Antin professionally moved on to other unrelated projects before retiring in 2019 after 44-years of combined U.S. Navy experience as a Sailor, Defense Contractor and Civil Servant.

Acknowledgement: Extend my thanks to Bill Hart of The Vinyl Press™ <https://thevinylpress.com/>, who has graciously offered his expertise as an Editor and host of this paper on his site for distribution. Neither myself nor Bill Hart will receive any financial benefit from this paper, and we have agreed that should any financial benefit result, the proceeds will be donated. Additionally, I wish to thank all those who shared their experience and knowledge; each of you in many ways stimulated my thinking and either helped me better understand the nature of the problem or how to better describe a solution to the challenges presented.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

PAGE

TABLE OF CONTENTS

FORWARD	2
CHAPTER I VINYL RECORD CLEANING CHALLENGES	8
CHAPTER II PROCESS SUMMARY AND LIST OF MATERIALS	14
CHAPTER III CLEANING SOLUTION PREPARATION	18
CHAPTER IV RECORD INSPECTION	22
CHAPTER V MANUAL CLEANING PROCESS	26
CHAPTER VI MAINTAINING CLEANLINESS	41
CHAPTER VII DISCUSSION OF WATER QUALITY	51
CHAPTER VIII DISCUSSION OF PRE-CLEANERS	55
CHAPTER IX DISCUSSION OF FINAL CLEANERS	75
CHAPTER X DISCUSSION OF MATERIAL COMPATIBILITY	80
CHAPTER XI DISCUSSION OF CLEANLINESS CRITERIA	92
CHAPTER XII DISCUSSION OF THE CLEANING PROCESS	107
CHAPTER XIII DISCUSSION OF VACUUM RECORD CLEANING MACHINES	113
CHAPTER XIV DISCUSSION OF ULTRASONIC CLEANING MACHINES	118
APPENDIX A - LIST OF REFERENCES	139
APPENDIX B – LIST OF ABBREVIATIONS & ACRONYMS	144
APPENDIX C - RECORD OF CHANGES	145

LIST OF FIGURES

Figure 1 - Record Groove Under SEM at 142 Magnification	9
Figure 2 - Record Groove Under SEM at 324X Magnification	10
Figure 3 – Particle Size of Common Contaminants.....	11
Figure 4 – Record Wear Spherical vs Elliptical Stylus – 50 Plays.....	12
Figure 5 – Record Wear Shibata vs Conical Stylus – 100 Plays	12
Figure 6 – Precision Aqueous Vinyl Record Cleaning Process Summary.....	14
Figure 7 – Preparing Cleaning Process Solutions.....	18
Figure 8 – Two New Records Inspected UV Light – Generally Clean	23
Figure 9 – One Record Inspected UV Light – Heavily Soiled with Staining	24
Figure 10 – One Record Inspected White & UV Light Before-After Cleaning	25
Figure 11 - Step 1: Assemble Cleaning Process Solutions and Materials	26
Figure 12 - Step 2: VinylStack™ Vinyl ‘1’ Stack Record Label Protector Assembly w/o Stand	27

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

	PAGE
Figure 13 - Step 3: VinylStack™ Vinyl '1' Stack Record Label Protector w/Stand Assembly	28
Figure 14 – Step 4: Pre-Rinse with Tap Water	28
Figure 15 – Step 5: Pre-Clean with CLEANER Solution & Brush.....	29
Figure 16 – Step 6: Pre-Clean Rinse with Tap Water & Brush.....	31
Figure 17 – Step 7: Final Clean with NID Solution & Brush	32
Figure 18 – Step 8: 1 st Final Rinse with Tap Water & Brush.....	34
Figure 19 – Step 9: Final Rinse with Distilled Water	35
Figure 20 – Step 10: Drying with Super Cool™ PVA Cleanroom Sponge	36
Figure 21 – Step 11: Drying with Kinetronics™ Anti-static Cloth.....	37
Figure 22 – Step 12: VinylStack™ Vinyl '1' Stack Record Label Protector Disassembly w/o Stand....	38
Figure 23 – Step 13: VinylStack™ Vinyl '1' Stack Record Label Protector w/Stand Disassembly.....	38
Figure 24 – Step 14: Records Drying on Rack.....	39
Figure 25 – Triboelectric Series	43
Figure 26 – Ground Cable.....	47
Figure 27 – Bertech™ ESD Vinyl Record Mat	48
Figure 28 – Leather Mat Under UV Light	49
Figure 29 – Surfactant Micelles.....	56
Figure 30 – Contact Angles and Wetting.....	58
Figure 31 –IPA + Water Flashpoint Temperature.....	62
Figure 32 – Water + IPA Boiling Point	63
Figure 33 –Water + IPA Surface Tension of at 25°C.....	64
Figure 34 – Organic Soil Roll-Up	64
Figure 35 – Records Inspected UV Light – Pigment Variations.....	82
Figure 36 – Record NVR Following Precision Aqueous Cleaning Process	96
Figure 37 – Record Groove Wavelength to Produce Hz	97
Figure 38 – Stylus Acceleration	99
Figure 39 – Record Groove Velocity	99
Figure 40 – Groove Velocity vs Amplitude vs Gross Contamination.....	102
Figure 41 – Groove Velocity vs Amplitude vs Contamination Levels	104
Figure 42 – Groove Velocity vs Amplitude vs Best Possible Cleanliness.....	106
Figure 43 – VPI™ MW-1 Cyclone Vacuum-RCM	114
Figure 44 – Keith Monks™ Vacuum-RCM	115
Figure 45 – Fundamentals of Ultrasonic Cavitation.....	119

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

	PAGE
Figure 46 - UT Tank Frequency Cleaning Guide	120
Figure 47 - VinylStack™ Ultra Sonic Spin.....	125
Figure 48 – Batch Processing – UCM to Holding Tank – Unfiltered.....	133
Figure 49 – Batch Processing – Holding Tank to UCM – Filtered	134
Figure 50 – Centrifugal Pump Curves	135
Figure 51 – Positive Displacement Pump Curves.....	136

LIST OF TABLES

Table I Manual Record Cleaning Process Material List.....	16
Table II EU/UK Manual Record Cleaning Process Material Substitution List	17
Table III Human Hands Electrical Resistance.....	44
Table IV Water Quality Specifications.....	51
Table V Residue Thickness Microns from Water Residue.....	53
Table VI Mica Conductivity from Condensed Water Film.....	66
Table VII Nonionic Surfactant Performance Properties.....	76
Table VIII Hansen Solubility Parameter Record Polymers & Solvents	89
Table IX Hansen Solubility Parameter Record & Solvents Analysis.....	90
Table X MIL-STD-1246C Particulate and NVR Cleanliness Levels	94
Table XI Remaining NVR Analysis After Pre-Cleaning & Final Cleaning	96
Table XII Record Groove Velocity vs Frequency & Amplitude	101
Table XIII Residue Thickness from Cleaner Residue	105
Table XIV Vacuum-RCM Features.....	113
Table XV Air Filter Ratings	117
Table XVI Pre-Clean Methods.....	128
Table XVII Batch vs Recirculation Filtration	132

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER I. VINYL RECORD CLEANING CHALLENGES:

The *ARSC Guide to Audio Preservation, 2015* (4) commissioned for and sponsored by the National Recording Preservation Board of the Library of Congress, states: “*Vinyl discs are the most stable physical sound recording format developed to date; they can last 100 years in a controlled environment.*” With the recent resurgence of vinyl records, history may prove that the durability of the simple vinyl record exceeds 100 years, and let us not forget that the National Aeronautics and Space Agency (NASA) Voyager space probe carries a gold record with simple directions for playback.

- I.1 However, the challenge of cleaning a simple vinyl record is well known as detailed in the technical paper *THE WEAR AND CARE OF RECORDS AND STYLI*, by Harold D. Weiler, 1954 (26) with excerpts as follows:
- I.1.a “*Completely removing dust and grit from a record is not a simple problem. A number of factors must be considered. Firstly, the cleaner must not contain any gummy substance that will remain in the engraved depressions in the record groove. Secondly, the cleaner must completely penetrate these same depressions and remove any dust or grit they may contain. Thirdly, the cleaner must not affect the record material itself in any manner.*”
- I.1.b “*Record dust/dirt when examined under a microscope consists of grease, stylus particles, abrasive material, and solids which resemble wool fibers covered with a soft waxy substance. An analysis of the "dust" removed from a number of stylus tips, which had been used on dirty records, showed that it consisted of approximately; 12% jagged silica particles, 35% diamond dust, 40% miscellaneous particles, including soot, grit and particles worn from the record groove itself. The remaining 13% consisted of fibers and lint.*”
- I.1.c “*Complete removal of dust and grit from the record grooves resulted in increases of up to 60% in the useful life of both records and styli.*” “*Careful handling, storage and cleaning of one's record collection is more than repaid in better reproduction and greatly increased record and stylus life.*”
- I.2 The paper *Record Contamination: Causes and Cure* by Percy Wilson, *Journal of The Audio Engineering Society* April 1965, Volume 13, Number 2 (52) echoes Harold D. Weiler (26) when it discusses three types of contaminants “...discrete particles such as soot, dust, grit, textile fluff, tobacco ash and cosmetic powders: fluids which, after evaporation, leave behind crusty deposits, such as household sprays and saliva deposits; and condensates formed from fumes, such as tobacco smoke, cooking vapors and automobile exhaust fumes.”
- I.3 Expanding upon the discussion written *THE WEAR AND CARE OF RECORDS AND STYLI* by Harold D. Weiler 1954 (26) and *Record Contamination: Causes and Cure* by Percy Wilson, 1965 (52) , the challenge posed by cleaning vinyl records is to remove a variety of organic and inorganic contaminants from a circular disc whose nominal dimension is 12-inches diameter,

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

manufactured from various proprietary compositions of a polyvinyl chloride-acetate/polyvinyl chloride (PVCA/PVC) blend (see **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:** for further details), that is grooved with sidewall ridges as follows:

- I.3.a V-shaped groove with 'nominal' dimensions of 56 microns (0.0022") wide at the top, a radius of 6 microns (0.00025") at the bottom, and a 'nominal' depth of 28 microns (0.0011"). Actual groove width and depth will vary based on the frequency and amplitude of the audio signal. Consecutive groove spirals are nominally 200 to 250 grooves per inch equal to a groove separation of 125 to 100 microns (0.005"). Larger separations are used to reproduce high output low frequency sound.
- I.3.b The groove is cut (often referred to as modulations) so that the stylus can move side-to-side (laterally) or up-and-down (vertically) to produce the audio signal. Groove sidewall ridges are used to reproduce right and left high frequency information for stereo. **Figure 1** illustrates record grooves using a scanning electron microscope (SEM) at 142X magnification with some details of the side-wall ridges. The side wall ridges are closely spaced to produce high frequency signals; 10 microns for a 33.333 rpm record to produce 20 kHz. The distance from the peak of the side wall ridge to its valley is the lateral amplitude and these can be less than 1-micron.




Figure 1 - Record Groove Under SEM at 142 Magnification
(Image courtesy of University of Rochester: URnano)

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- I.3.c **Figure 2** is a close-up (324X magnification) of **Figure 1**. However, while **Figure 2** shows smooth groove side-wall ridges, SEM photos at 1000X show much more ragged details of the sidewall ridges that can be seen here <https://www.sciencephoto.com/media/215071/view>.




Figure 2 - Record Groove Under SEM at 324X Magnification
(Image courtesy of University of Rochester: URnano)

- I.4 Except for the grooves per inch and the low frequency groove modulations all other dimensions are invisible to the naked eye under bright white light that is limited to about 50 microns (*source MIL-STD-1330D (42) & MIL-STD-1622B (43)*). Ultraviolet (UV) blacklight at 365 nano-meters (nm) can detect particles that fluoresce that are about 25 microns, but the groove bottom and groove sidewall ridges will not be individually detectable. Also, based on the groove dimensions, particles of interest can be very small – less than 10 microns and per **Figure 3**, common in any residential environment. While individual particles of less than 1 micron ‘may’ be of little consequence (see **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:** for a detailed analysis), groups of these small particles can conglomerate into larger masses. Consequently, the cleaning process has to be able to remove invisible contaminants. Obviously, “looks clean” to the naked eye is basically meaningless other than to note significant defects resulting from the pressing process, handling or abuse and to see some of the more obvious manifestations of contamination, *e.g.*, fingerprints or large dust particles. To effectively clean a record, we must approach the task with a level of precision that is not

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

readily apparent to the naked eye. This calls for more precision in method and the selection and application of chemistry as well as the removal of the cleaning agents, once they have performed their function.




Figure 3 – Particle Size of Common Contaminants
(Image from United States EPA)

CONCLUSION

Cleaning a vinyl record falls under the category of “Precision Cleaning”.

- I.5 To effectively remove particulate, the item must first be degreased. Organic contaminants (i.e., oil/greases/tobacco-tar) and anything similar can cover over and trap particulate. Failure to remove large particulate in the groove will result in audible pops, clicks and other annoying sounds. However, of equal importance is that since the groove sidewall ridges are not deep, contamination can fill-in the ridge spaces and effectively attenuate and or distort high frequency sounds. But concentrated cleaners can often leave enough non-volatile-residue (NVR) behind requiring a final clean to remove the residue left from the “pre-cleaner”.
- I.6 Record wear is influenced by the stylus shape, vertical tracking force and the record material. **Figure 4** (circa 1968) shows groove wear caused by two different styluses after 50 plays obtained from *Record -Groove Wear, J G. Woodward, HiFi Stereo Review Magazine, October 1968 (29)*: Photo A shows the wear produced by a 0.7 -mil spherical stylus tracking at 5

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

grams. Photo C is a 0.2 x 0.7 -mil elliptical at 1.5 grams. The wear shown in **Figure 4** is permanent plastic deformation, but very little material has actually been removed.




Figure 4 – Record Wear Spherical vs Elliptical Stylus – 50 Plays
(Image Groove Wear, J.G. Woodward, *HiFi Stereo Review Magazine*, October 1968, Page 88 "scan courtesy of www.worldhistory.com")

- I.7 **Figure 5** (circa 1976) shows record wear of a long-wearing record material developed by RCA™ for the Shibata stylus and quadrasonic sound; from *RCA Engineer Magazine*, 1976, Issue 02-03, *Development of Compound for Quadradiscs*, by G.A. Bogantz S.K. Khanna (61). Photo A is a Shibata stylus at 1.5 gram after 100 plays, showing little or no wear. Photo B shows a Conical stylus at 4.5 grams after 100 plays, showing clean trenching. But RCA™ also showed significant wear with material from another vendor after just 25 plays with a Shibata stylus at 1.5 grams and just 10 plays with a Conical stylus at 4.5 grams after 10 plays.




Figure 5 – Record Wear Shibata vs Conical Stylus – 100 Plays
(Image *Development of Compound for Quadradiscs*, G.A. Bogantz & S.K. Khanna, RCA 1976 "scan courtesy of www.worldhistory.com")

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- I.8 The record wear in **Figure 4** and **Figure 5** can be accelerated by the cleaning method. Solvents and some aggressive concentrated aqueous cleaners can soften by swelling the leading edge of the side-wall ridges that could cause loss of high frequency fidelity as the stylus permanently smears the leading edge with accelerations over 1,000 g's and pressures equivalent to 20,000 pounds per square inch (psi) and greater that are influenced by the stylus shape and proportional to the vertical tracking force (VTF) (*source: Disc Phonograph Records by Dr. A. M. Max, RCA Engineer Magazine 1966-08-09 (1)*). Alternately, solvents and aggressive concentrated aqueous cleaners "may" extract components of the vinyl record leading to hardening of the leading edge of the side-wall ridges that could similarly cause loss of high frequency fidelity caused by premature record wear by the stylus. See **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:** for detailed discussion of cleaning agent material compatibility.
- I.9 Verifying cleanliness is a further challenge. When is a record clean? Currently other than use of a SEM, there is no practical quantitative method to verify record cleanliness. Visual techniques such as white light and UV-blacklight have detection limits that will not be sufficient to verify that the record is actually clean. Very thin, transparent soil films associated with mineral-based oils and greases can be difficult to detected below 100 milligrams per square foot (mg/ft²), and this type of contamination generally does not fluoresce under UV-blacklight. Other common industry cleanliness verification techniques such as solvent wash and measure of effluent non-volatile residue (NVR) and particle count are not practical for many reasons; cost, compatibility of available solvents with the vinyl record, skill and the very difficult geometry illustrated **Figure 1** and **Figure 2** just to name a few. Performing cleanliness verification with the assistance of an ultrasonic (UT) tank is possible, but is at best qualitative (see **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES:**). In the absence of a practical quantitative cleanliness verification method, the subjective after cleaning play-test - how does the record sound - prevails.

CONCLUSION

The 'precision cleaning process' must be robust enough to provide a large margin for error.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER II. PROCESS SUMMARY AND LIST OF MATERIALS:

The manual precision aqueous vinyl record cleaning procedure detailed by this document began with the cleaning process used by the *United States Library of Congress* (34) to clean delicate lacquer records. That procedure was then modified following the fundamentals developed for *MIL-STD-1330D Precision Cleaning and Testing of Shipboard Oxygen, Helium, Helium-Oxygen, Nitrogen, And Hydrogen Systems* (42) and *MIL-STD-1622B Standard Practice for Cleaning of Shipboard Compressed Air Systems* (43). The resulting cleaning procedure is a multi-step process that uses readily available materials, is very economical, is safe (when used correctly) and is summarized in **Figure 6**.



Figure 6 – Precision Aqueous Vinyl Record Cleaning Process Summary

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



- II.1 **SAFETY:** Safety is emphasized throughout. Being courageous or cavalier with safety when handling concentrated chemicals can lead to injury. It is very easy to get chemical on a gloved hand and then not thinking rub your eye(s) for any number of reasons. Most residential homes do not have an eye-wash station, and eye injury can occur. All highly concentrated cleaning agents such as Alconox™ Liquinox™ and Dow™ Tergitol™ 15-S-9 should be handled with appropriate personal protective equipment (PPE) such as gloves and eye protection and be protected from accidental ingestion by children and pets. In the event of accidental ingestion, contact the Poison Control Center® hotline 1-800-222-2222.
- II.1.1. Some concentrated (and not so concentrated) chemicals and cleaners can have chronic (long-term) exposure concerns, obviously the worst being cancer. But others can attack the central nervous system, respiratory or any number of organs over a prolonged exposure, and this can be much worse for young children and reproductive females. No such product is recommended here. But, if substituting cleaning agent(s), readers are advised to consult the material safety data sheet (MSDS) for appropriate safety precautions.
- II.1.2. All aqueous cleaning agents recommended by this document once diluted as specified herein, are not flammable, have no reported acute or chronic toxicity hazard, and are often safer than common household, concentrated dish detergents.
- II.2 The manual cleaning procedure in **CHAPTER III. CLEANING SOLUTION PREPARATION: and CHAPTER V. MANUAL CLEANING PROCESS:** are formatted with specific steps. All steps are further separated by a dotted line. All Cautions are generally placed after the step but before the applicable image. Information notes generally are placed after the applicable step. All **Figures** follow (placed after) the applicable step.
- II.3 **Table I** is a list of all materials used or otherwise referenced in this paper for the manual precision aqueous cleaning of vinyl records detailed **CHAPTER III. CLEANING SOLUTION PREPARATION; CHAPTER IV. RECORD INSPECTION: and CHAPTER V. MANUAL CLEANING PROCESS;** indicating applicable sources and estimated cost as of the version date of this document.
- II.4 **EU/UK Material Substitution.** Some materials such as Alconox™ Liquinox™, Dow™ Tergitol™ 15-S-9, and the Record Doctor brush are not sold in the EU/UK. Substitutes are available and are listed **Table II**.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Table I
Manual Record Cleaning Process Material List

Item	Source	Estimated Cost
VinylStack™ Vinyl '1' Stack Record Label Protector (or Groovemaster™ label protector - cost ~\$46.00 Amazon™ & eBay™)	https://thevinylstack.com;	\$35.00
Dow™ Tergitol™ 15-S-9 nonionic surfactant 1 pint (16 ounces)	https://www.talasonline.com;	\$22.00
Alconox™ Liquinox™, 1-Qt	Amazon™ & Others	\$22.00
Record Doctor™ Clean Sweep Record Brush (or OSAGE or STASIS Groove Nylon Record Cleaning Brush - \$30)	Audio Advisor™, Amazon™ & Others	\$20.00
UF-3 PVA white cleanroom sponge 4.92" x 3.35" x 1.38", 130 microns PVA Sponge, Shammies, Mops, and Wipes	Supper Cool Products™ PVA Clean Room Sponges, Wipes, and Mops (super-cool-products.com)	\$9.00
Kinetronics™ Tiger anti-static microfiber cloth, 10-inch x 18-Inch Cloth	Amazon™ & Others	\$15.00
Two (2) clean white translucent HDPE spray bottles about 16 ounces (or 32 ounces) each	Amazon™ & Others	\$10.00
One (1) gallon distilled (battery) or demineralized water	Local Grocery or Automotive Store or produce your own (see Chapter VII).	\$1.00 & up
Powder-free disposable nitrile gloves, box of 50 (or 100), or reusable nitrile glove(s)	Local Grocery, Hardware or Drug Store, or Amazon™	\$15.00 & up
Safety Glasses or Goggles	Local or Online Hardware Store or Amazon™	\$2.00 & up
Disposable Low-Density Polyethylene (LDPE) Pipettes 3-mL and/or 5-mL capacity to mix concentrated cleaners. Bags of 50 or 100.	Amazon™	\$5.00 & up
Anti-static, Lint-Free, Archival Quality Record Sleeve	Audio Advisor™, Music Direct™, Elusive Disc™, Sleeve City™ & Others	\$20.00 & up (for quantity 50)
Optional: VinylStack™ Drying Stand (\$20 if purchased with VinylStack™ Vinyl Record Label Protector)	https://thevinylstack.com;	\$25.00
Optional: UV Blacklight 365nm, 10W, Alonefire Model SV003 (or equivalent)	Amazon™	\$25.00
Optional: Nalgene™ 500 mL wide mouth wash bottle (LDPE), or equal, to use for cleaner solution.	Amazon™ & Others	\$20.00
Optional: OXO™ Good Grips Dish Rack (or equal)	Container Store™ & others	\$20.00

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Table II
EU/UK Manual Record Cleaning Process Material Substitution List

Item	Source	Estimated Cost
Loricraft™ 12" LP Record Nylon Cleaning Brush	Loricraft 12" LP Record Nylon Cleaning Brush - SCOTT NANGLE AUDIO (snvinyl.co.uk)	£18.99
BASF™ Dehypon® LS 54 nonionic surfactant 1 Liter	Dehypon – Conservation Resources (UK) Ltd (conservation-resources.co.uk)	£22.00
ILFORD-ILFOTOL™ wetting agent/nonionic surfactant	Amazon™ UK & eBay™ UK	£23.00
Triton™ X100 Lab-Grade	Amazon™ UK search "Triton X-100"	£28.00

Alconox™ Liquinox™ cannot be purchased in the EU/UK. At the time of this 2nd Edition, no direct equivalent has been found.

- The product Vinyl Clear™ is clear (so no dye), appears to be formulated for records and is concentrated. It is available as a [Record Machine Cleaning Fluid Concentrate - 250ml by: Amazon.co.uk: Electronics](#). The vendor site [FAQs – Vinyl Clear](#) talks about dust which implies the cleaner if not rinsed (or subject to final clean) can leave a residue in the form of a dry powder. So long as using only for pre-clean, this should not be experienced.
- A cheaper alternative could be a hand dishwashing detergent that is not colored (no dyes), unscented (no fragrance) and contains no anti-bacterial agents. These will tend to have a number of ingredients that have nothing to do with cleaning such as thickeners, but diluted-down into a spray bottle can work as a pre-cleaner.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER III. CLEANING SOLUTION PREPARATION:

III.Step 1. Assemble all cleaning agents, distilled water, spray bottles, measuring devices, and personal protective equipment (nitrile gloves and safety glasses). It is recommended to clean (wipe down) the local area to minimize cross contamination.



Reuse of household cleaner plastic spray bottles for DIW, NID and CLEANER spray bottles is possible with appropriate cleaning, but at the user's own risk of contaminating the distilled water, Alconox™, or Tergitol™ cleaning agents. The recommended spray bottle material is white translucent high-density polyethylene (HDPE).



Figure 7 – Preparing Cleaning Process Solutions

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

III.Step 2. Prepare the DIW Spray Bottle: For first time use, fill one spray bottle with tap-water about 1/4-full, install sprayer, shake vigorously, check for foam, exercise sprayer and then dump to sink to pre-clean/rinse spray bottle. If there was foam noting that tap-water does not foam, repeat the tap-water rinse until there is no evidence of foam. Then, final-clean spray bottle by filling about 1/4-full with distilled water, exercise sprayer and then dump to sink. Then, fill spray bottle full with distilled water and label the spray bottle “DIW”.

III.Step 3. Pre-Clean the NID & CLEANER Spray (or Wash) Bottles: For first time use, clean/rinse by filling the bottles with tap-water about 1/4-full, install sprayer (or cap for wash bottle) and shake vigorously, check for foam, exercise sprayer (wash-bottle) a few times and then dump to sink. If there was stable foam more than about 1/4-inch noting that tap-water does not foam, repeat tap-water rinse until there is no evidence of a high stable foam (bubbles over and above the liquid surface); a small number of bubbles on the surface is inconsequential.

III.Step 4. Prepare the CLEANER & NID Spray (or Wash) Bottles: Don nitrile gloves and eye protection. Add distilled water to spray (or wash) bottle and fill about 1/2 to 3/4 full.



Store concentrated Alconox™ Liquinox™ cleaner and Dow™ Tergitol™ 15-S-9 surfactant away from children and pets. Dispose of any unused concentrated product in accordance with the material safety data sheet (MSDS) available on the internet – search “Alconox™ Liquinox™ MSDS” or “Dow™ Tergitol™ 15-S-9 MSDS”. Store labeled diluted solutions same as any general household spray cleaner.



Wear eye protection when handling the concentrated Alconox™ Liquinox™ cleaner or Dow™ Tergitol™ 15-S-9 surfactant. In the concentrated state, Alconox™ Liquinox™ and Dow™ Tergitol™ 15-S-9 are classified as a severe eye irritant. The concentrated Alconox™ Liquinox™ cleaner and Dow™ Tergitol™ 15-S-9 have the consistency of a light-weight oil and while unlikely to splash, small amounts on your gloves could be a risk if you rub your eyes.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Wear nitrile gloves to protect hands from cleaner exposure and prevent cross contamination. Unlike standard dish detergent, concentrated and diluted solutions of Alconox™ Liquinox™ and Dow™ Tergitol™ 15-S-9 contain no additives to protect the skin.

III.Step 4.a) Alconox™ Liquinox™: Add about 5 mL of the Alconox™ Liquinox™ to 16 ounces (470-500 mL), or about 10 mL to 32 ounces (0.95 to 1.0 liters) to obtain about a 1.0% solution. Install sprayer (or wash bottle cap) and gently shake to mix. Then top off to full with distilled water, and label bottle “CLEANER”. This solution will produce a lot of foam when agitated. NOTE: Alconox™ Liquinox™ is about 50% active ingredients so that the 1% solution is actually 0.5% concentrate.

III.Step 4.b) Dow™ Tergitol™: Add about 0.5 mL of the Dow™ Tergitol™ 15-S-9 surfactant to 16 ounces (470-500 mL) or about 1 mL to 32 ounces (0.95 to 1.0 liters) to obtain about a 0.1% solution. Install sprayer (or wash bottle cap) and gently shake to mix. Then top off to full with distilled water, and label bottle “NID” (nonionic detergent). The low concentration of this NID solution will produce foam when agitated.



Any use of other water-based record cleaner(s) is at the user's own risk. Alconox™ Liquinox™ and Dow™ Tergitol™ 15-S-9 (or equivalents) are being recommended based on the detailed MSDS, known ingredient(s), detailed use data, and human and environmental safety when diluted.



General rule of thumb is that 15-18 drops equal one 1 mL, but this can vary to as high as 25-drops/mL. Disposable LDPE 3-mL or 5-mL graduated pipettes are very convenient and inexpensive.



Using too much Alconox™ Liquinox™ or Dow™ Tergitol™ 15-S-9 to prepare the CLEANER or NID solution is worse than using too little. Too high a concentration will not significantly increase the detergency. It will increase the cleaning solution preparation time, and it will increase the time, effort and quantity of water required to rinse.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



All solution concentrations since they are liquid are indicated as only % and are intended as percent by volume (sometimes noted as v/v%). Since most of the cleaner surfactants used have a specific density close to 1.0 same as (water), the v/v% is very close to weight % (wt%). Any small differences are inconsequential for their intent as cleaning agents.

III.EU/UK. Prepare the NID Spray (or Wash) Bottles: Don nitrile gloves and eye protection. Add distilled water to spray (or wash) bottle and fill about 1/2 to 3/4 full.

- a) For BASF™ Dehypon® – All prior **CAUTIONS** for handling Dow™ Tergitol™ apply. Add about 0.2 mL of the BASF™ Dehypon® LS 54 nonionic surfactant to 500 mL or about 0.4 mL to 1.0 liter to obtain about a 0.04% solution. Install sprayer (or wash bottle cap) and gently shake to mix. Then top off to full with distilled water, and label bottle “NID” (nonionic detergent). The low concentration of this NID solution may produce some foam when agitated.
- b) For ILFORD ILFOTOL™: Add about 20 mL of the ILFORD ILFOTOL™ wetting solution to 500 mL or about 20 mL to 1.0 liter to obtain about a 0.1% active solution (ILFORD ILFOTOL™ is only 5% nonionic surfactant). Install sprayer (or wash bottle cap) and gently shake to mix. Then top off to full with distilled water, and label bottle “NID” (nonionic detergent). The low concentration of this NID solution will produce foam when agitated. NOTE: ILFORD ILFOTOL™ is only 5% active so the dilution formula is as follows a 0.1%/L solution: $(1000 \text{ mL}) \times (0.001)/(0.05) = 20 \text{ mL/L}$.
- c) For Dow™ Triton™ X100: All prior **CAUTIONS** for handling Dow™ Tergitol™ apply. Add about 1.5 mL of the Dow™ Triton™ X100 nonionic surfactant to 500 mL or about 3 mL to 1.0 liter to obtain about a 0.3% solution. Install sprayer (or wash bottle cap) and gently shake to mix. The Dow™ Triton™ X100 will dissolve slowly. Then top off to full with distilled water, and label bottle “NID” (nonionic detergent). This NID solution will produce foam when agitated.

III.EU/UK. Prepare the CLEANER Spray (or Wash) Bottles: If using Vinyl Clear™ mix in accordance with manufacturer directions. If using a hand dishwashing detergent add distilled water to spray (or wash) bottle and fill about 1/2 to 3/4 full. Add about 10 mL of the detergent to 500 mL or about 20 mL to 1.0 liter to obtain about a 0.5% active solution. Install sprayer (or wash bottle cap) and gently shake to mix. Then top off to full with distilled water, and label bottle “CLEANER”. This CLEANER solution should produce foam when agitated. NOTE: Most thickened dishwashing detergents are about 25% active so the dilution formula is as follows for a 0.5%/L solution: $(1000 \text{ mL}) \times (0.005)/(0.25) = 20 \text{ mL/L}$.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER IV. RECORD INSPECTION:

- IV.1 Visually inspect the record to assess how dirty is the record. This document uses the following 'grades' to define the record condition as it applies to cleaning.
- IV.1.a **Exceptionally Dirty** - Records that have tightly adherent contamination on top of the record such as mildew or oily residue; i.e., resurrecting a flea-market find. These records should receive the pre-clean step twice with the Alconox™ Liquinox™ 1.0% CLEANER solution as specified **CHAPTER V. MANUAL CLEANING PROCESS:** before proceeding to the final clean step. For mold and hard water spots see **paragraphs** VIII.10.3 & VIII.12 for additional information.
- IV.1.b **Heavily Soiled** - Records that are neither exceptionally dirty nor generally clean. These records have visible soil that is in the groove(s). These records should receive the pre-clean step once with the Alconox™ Liquinox™ 1.0% CLEANER solution as specified **CHAPTER V. MANUAL CLEANING PROCESS:** before proceeding to the final clean step.
- IV.1.c **Generally Clean** - Records that have visible particulate and/or some evidence of oily fingerprints, or have a strong static charge. These records should receive the final clean step using Dow™ Tergitol™ 15-S-9 0.1% NID solution as specified **CHAPTER V. MANUAL CLEANING PROCESS:.** Final clean should be adequate to remove light oily fingerprints, other very light oils, and fine particulate, and the nonionic wet cleaning process will remove the static charge that is common on new records. Even though the record may play quiet, that does not mean that the record is completely clean and even new records should be subject to the final clean step. The record pressing plants are essentially industrial facilities with high background levels of very fine airborne particulate from many sources including the humans handling/packaging the records. Generally clean records may benefit from the pre-clean step. Even though the record may appear to be generally clean, invisible, tenacious, thin-film contamination may be deep in the groove or on the grooved side-walls.
- IV.2 Inspection with the optional low-powered UV-blacklight (see **Table I**) can improve the inspection process. But, be careful of too much light. Industrial 100-watt UV blacklights can cause record damage, and some LED tactical flashlights produce enough white light to "wash-out" the surface leaving no contrast to be able to see small particles.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Do not view a UV-Blacklight directly to avoid eye injury.



There should be no record damage using the UV light. The UV light exposure is just a few seconds, exposure is a single UVA wavelength 365 nano-meter vs the entire UV spectrum, and the 10-watt UV light source listed **CHAPTER II. PROCESS SUMMARY AND LIST OF MATERIALS:Table I** is not very powerful.

IV.3 **Figure 8** shows examples of generally clean records under UV blacklight. With only white light, the records in **Figure 8** appeared clean, but under UV blacklight showed a lot of particulate.



Figure 8 – Two New Records Inspected UV Light – Generally Clean

IV.4 **Figure 9** shows an example of a heavily soiled record under UV blacklight. With only white light, the record in **Figure 9** did not appear heavily soiled, but under UV blacklight showed a variety of contaminants with staining that was not removable. The record in **Figure 9** was subsequently fully cleaned as specified **CHAPTER V. MANUAL CLEANING PROCESS;** and although the staining was not removed, it played quiet with reasonable fidelity.

IV.4.a Note that some fingerprints may actually be etched into the surface of the record and this can be determined with jeweler's loupe, or equal type magnification. These fingerprints are not removable and unless deep into the groove can play without distortion. Some

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

'defects' may be remnants of the pressing process and can include metal chards that are embedded; but the record may play fine.

- IV.4.b The staining in **Figure 9** may be caused by using recycled (repressed) records whose label(s) were not completely removed per a conversation at *VPI™ Forum, General Audio, "UV Inspection of Records Results"* thread of *Tue Mar 10, 2020 2:12 pm* (56). A person who worked at Columbia Records factory in 1972 and 1973 was in the department that supplied the record material to the presses. The person indicated that the equipment that removed the labels from returned or over-pressed records would frequently malfunction. Labels were then part of the recycled vinyl mixed with virgin material used for pressing records that were allowed to be pressed with recycled material.



Figure 9 – One Record Inspected UV Light – Heavily Soiled with Staining

- IV.5 No similar fluorescence has been seen with records manufactured from virgin material, but fluorescence has been seen on some recently pressed records. The cause is currently unknown. While older records can show the large wave-shape of **Figure 9**, the newer records show only a few stains that are unlikely to be caused by recycled vinyl containing label pieces. These stains 'may' be from wax-type lubricants used in the record composition that may not be uniform with some near the surface. The staining noted on the new records is not removable by the cleaning process specified **CHAPTER V. MANUAL CLEANING PROCESS:** and follow-on play has not removed it either. Additional details on record composition are discussed **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:**

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

IV.6 **Figure 10** is a well-known record. Photo A is white light after the record had been cleaned with a well-known record brush and an optical cleaning solution that will only lightly wet the record; very similar to the Discwasher™ process. Photo B photo is the record under UV light and it shows a lot of particulate remaining, and the record played as it looked, very noisy. Photo C is the record after cleaning as specified **CHAPTER V. MANUAL CLEANING PROCESS:**. The cleaning process removed a lot of particulate, but there is still particulate that is deep in the grooves that are not being removed. This record plays as it looks – there is some ticks throughout. In this case this is not the best pressing. In comparison, the *Bill Evans* and *Liz Story* records in **Figure 35** show almost complete absence of any particulate under UV light and they play as the look – very quiet.




Figure 10 – One Record Inspected White & UV Light Before-After Cleaning

IV.7 There are limitations with using UV blacklight. Animal and vegetable-based oils and greases such as an oily fingerprint, waxes and hard-water mineral residue will generally fluoresce. However, mineral-based oils and greases such as motor oil, and synthetic greases generally will not fluoresce. Many natural fibers (including the record label) and lint fluoresce, but synthetic fibers such as the VinylStack™ microfiber cloth and the Kinetronics™ Tiger anti-static microfiber cloth do not fluoresce.

CHAPTER V. MANUAL CLEANING PROCESS:



This “manual cleaning process” uses tap-water for some rinsing and assumes the quality is close to USA EPA guidelines (or equivalent). The rationale for use is discussed **CHAPTER VII. DISCUSSION OF WATER QUALITY:** If not, substitute DIW for all rinse steps. This will incur greater cost and will lose the benefit of the force and volume of tap-water dropping from a faucet when rinsing. **Paragraph VII.4** discusses some options to produce higher quality water. Otherwise **CHAPTER XIII. DISCUSSION OF VACUUM RECORD CLEANING MACHINES:** may be the better cleaning process.

V.Step.1 Assemble all equipment, material and solutions in a location that has access to a relatively large sink such as a residential kitchen. **Figure 11** shows optional stand and UV light (*items not shown optional Nalgene wash bottle and dish rack*). If required, prepare cleaning solutions as specified **CHAPTER III. CLEANING SOLUTION PREPARATION:** It is recommended to clean (wipe down) the local area to minimize cross contamination and obtain best cleaning results. Don nitrile gloves.



Figure 11 - Step 1: Assemble Cleaning Process Solutions and Materials

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



If using the optional VinylStack™ Drying Stand adhere to the neodymium magnet precautions. The VinylStack™ Drying Stand can be used during assembly/disassembly (noted as **V.Step.3** and **V.Step.13**) with a simple modification. Install clear self-adhesive rubber/vinyl bumpers/pads to the bottom to prevent the stand from sliding as indicated **Figure 11**.

V.Step.2 Method w/o Stand: Place VinylStack™ Vinyl '1' Stack Record Label Protector on flat surface, remove outer label protector, install record, assemble and tighten. After first tight, tighten about 1/4 to 1/3 additional turn to secure the label protector.



Figure 12 - Step 2: VinylStack™ Vinyl '1' Stack Record Label Protector Assembly w/o Stand

V.Step.3 Optional Method w/Stand: If using the stand as modified per **Figure 11**, place VinylStack™ Vinyl '1' Stack Record Label Protector on Drying Stand (magnet will secure the label protector), remove outer label protector, install record, assemble and tighten. When tight the record will spin against the magnet, remove from the stand, grip the record label protector (front or back) and tighten about 1/4 to 1/3 additional turn to secure the label protector.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Figure 13 - Step 3: VinylStack™ Vinyl '1' Stack Record Label Protector w/Stand Assembly

V.Step.4 Pre-Rinse: Move record to kitchen sink (or equivalent), and pre-rinse with steady stream of lukewarm to warm tap water (no need to use spray) to remove loose debris.



Using a plastic or rubber kitchen sink mat can protect the record should you drop the record into the sink. Placing the record against a hard surface and using physical force to 'deeply clean' is not recommended due to risk of record damage. Let the process chemistry and fluid agitation do the work. Additionally, using a plastic or rubber faucet protector can protect the record from the faucet.




Figure 14 - Step 4: Pre-Rinse with Tap Water

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

V.Step.5 Pre-Clean: Pre-clean with CLEANER (1% Alconox™ Liquinox™). Using the CLEANER spray (or wash) bottle, liberally wet both sides of the record with the cleaning solution. The solution will wet the surface (not bead-up) almost instantly. Applying only a light pressure (the brush handle can scratch the record), use the Record Doctor™ Clean Sweep Record Brush (or equivalent) in moderately short, fast, back and forth motions (such as two back-and-forth motions per second) that follow (are parallel to) the arc of the grooves, and clean the record both sides with the CLEANER solution. For those familiar with record cleaning machines (RCMs) – clean the record the equivalent of 3 to 5 rotations. The back-and-forth motion of the brush will perform the same as reverse rotation. Holding the record on an angle (about 45° to 60°) can assist with the cleaning process. The low surface tension of the CLEANER will keep it on the record. The CLEANER will develop foam as noted **Figure 15** with most of the foam collecting in the brush.



Figure 15 – Step 5: Pre-Clean with CLEANER Solution & Brush

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Aerosol from the CLEANER spray bottle similar to any household spray cleaner may cause respiratory irritation during extended exposure such as sequentially cleaning more than a few records. Operating the sprayer partly or slowly (versus quick full-pumps) will reduce the amount of airborne aerosol. Operating a kitchen range hood will improve local ventilation. Otherwise, instead of a spray bottle use a Nalgene™ wash bottle (see **CHAPTER II. PROCESS SUMMARY AND LIST OF MATERIALS: Table I & Figure 7**) to apply the CLEANER solution.



For generally clean records, if the pre-clean **V.Step.5** will not be performed, proceed to final clean **V.Step.7**. However, the small amount of CLEANER used and the few minutes of added time to complete pre-clean **V.Step.5** and rinse **V.Step.6** are recommended if there is any uncertainty to the record condition.



When performing the pre-clean **V.Step.5**, limit the exposure time to the pre-cleaner to less than 5 minutes per side to mitigate any material compatibility risks with the vinyl record composition (material compatibility is discussed **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:**).



The foam that is developed by the cleaning process is beneficial. It helps to lift debris and soil from the record groove. The Nylon brush adsorbing the foam assists with lifting the debris and soil from the record minimizing the risk of grinding debris and particles into record.



For “exceptionally dirty” records such as those covered with large areas of mold or oily residue, recommend performing the pre-clean/rinse **V.Step.5 & V.Step.6** twice. The process uses very little CLEANER and exceptionally dirty records may not be cleaned using only one application of the CLEANER.

V.Step.6 Rinse: Using lukewarm to warm tap water, flush the record with a steady stream (no need for spray) of water on both surfaces until the record is free of any cleaner. While rinsing, with very light pressure, use the Record Doctor™ Clean Sweep Record Brush (or equivalent) in moderately slow long back-and-forth motions (i.e., similar to using a paint brush) that follow (are parallel to) the arc of the grooves to assist the water rinse and to flush the record brush of CLEANER. But, at the end, separately rinse the record both sides and the brush with only a steady stream (no need for spray) of water to ensure removal of CLEANER from both.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Water spray is not necessary. But, if water spray is used, wear eye protection to protect from cleaner back-splash.



Figure 16 – Step 6: Pre-Clean Rinse with Tap Water & Brush



If local tap-water is of insufficient quality and DIW is being substituted, recommend using a Nalgene™ (or equivalent) wash/rinse bottle as indicated **Table I** and shown **Figure 7**. This will obtain much better flow and rinsing than using a spray bottle.

V.Step.7 Final-Clean: Final clean with NID (0.1% Dow™ Tergitol™ 15-S-9). Using the NID spray (or wash) bottle, liberally wet both sides of the record with the cleaning solution. The NID solution will wet the surface (not bead-up) almost instantly. Applying only a light pressure (the brush handle can scratch the record), use the Record Doctor™ Clean Sweep Record Brush (or equivalent) in moderately short, fast, back and forth motions (such as two back-and-forth motions per second) that follow (are parallel to) the arc of the grooves, and clean the record both sides with the NID solution.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

For those familiar with RCMs – clean the record the equivalent of 3 to 5 rotations. The back-and-forth motion of the brush will perform the same as reverse rotation. Clean the record the equivalent of 3-5 rotations. Holding the record on an angle (about 45° to 60°) can assist with the cleaning process. The low surface tension of the NID will keep it on the record. There will be some foam with the NID as noted **Figure 17**.



Aerosol from the NID spray bottle similar to any household spray cleaner may cause respiratory irritation during extended exposure such as sequentially cleaning more than a few records. Operating the sprayer partly or slowly (versus quick full-pumps) will reduce the amount of airborne aerosol. Operating a kitchen range hood will improve local ventilation. Otherwise, instead of a spray bottle use a Nalgene™ wash/rinse bottle (see **Table I & Figure 7**) to apply the NID solutions.




Figure 17 – Step 7: Final Clean with NID Solution & Brush

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



When performing the final clean **V.Step.7**, limit the exposure time to the final cleaner to less than 5 minutes per side to mitigate any material compatibility risks with the vinyl record composition (material compatibility is discussed **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:**).



If a high stable foam develops, the record may not have been adequately rinsed following the pre-clean **V.Step.6** or an excessive quantity of the Dow™ Tergitol™ 15-S-9 was used to prepare the NID cleaning solution.

V.Step.8 First Final Rinse: Using lukewarm to warm tap water, flush the record with a steady stream (no need for spray) of water on both surfaces until the record is free of any cleaner. While rinsing, with very light pressure, use the Record Doctor™ Clean Sweep Record Brush (or equivalent) in moderately slow, long back-and-forth motions (i.e., similar to using a paint brush) that follow (are parallel to) the arc of the grooves to assist the water rinse and to flush the record brush of cleaner. But, at the end, separately rinse the record both sides and the brush with only a steady stream (no need for spray) of tap-water to ensure NID is removed from both. Gently shake the record to remove bulk/large water drops.



Water spray is not necessary. But, if water spray is used, wear eye protection to protect from cleaner back-splash.



If local tap-water is of insufficient quality and DIW is being substituted, recommend using a Nalgene™ (or equivalent) wash/rinse bottle as indicated **Table I** and shown **Figure 7**. This will obtain much better flow and rinsing than using a spray bottle.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Figure 18 – Step 8: 1st Final Rinse with Tap Water & Brush

V.Step.9 Final DIW Rinse: Using the DIW (distilled/demineralized water) spray bottle, liberally spray the record surface from top to bottom (both sides) to remove the tap water. The surface should readily bead-up evidence that all cleaner has been removed. This will leave only DIW that when dry will leave a clean, spot free surface. Gently shake the record to remove bulk drops.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 19 – Step 9: Final Rinse with Distilled Water

V.Step.10 First Dry: Using the Super Cool™ PVA Cleanroom Sponge, following the arc of the record grooves, lightly wipe the surface to remove most water. Excess pressure may produce a squeaking sound similar to wiping a mirror.



Read the use instructions that come with the Super Cool™ PVA Cleanroom. This sponge is delivered moist in a plastic package. If allowed to dry, the sponge will become very hard, but as specified in the instructions will soften when rinsed with DIW. The Super Cool™ PVA Cleanroom Sponge should be able to dry about 3 records before requiring a squeeze to expel excess DIW moisture. The yellow microfiber cloth provided with the VinylStack™ is good for drying your hands and can be used to absorb water from the PVA sponge.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 20 – Step 10: Drying with Super Cool™ PVA Cleanroom Sponge

V.Step.11 Second Dry: Using the Kinetronics™ Tiger anti-static cloth, with very little pressure, final dry the record in a circular motion after which there should be very little moisture left and the surface will be free of static charge. Then, away from the sink, give the record a good two (2) shakes to dislodge moisture that is under the edges of VinylStack™ Vinyl ‘1’ Stack Record Label Protector. Wipe away any visible drops. This will minimize wetting the label when the record label protector is removed.



When shaking the record, grasp tightly the VinylStack™ Vinyl ‘1’ Stack Record Label Protector handle so you don’t accidentally throw the record across the room.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 21 – Step 11: Drying with Kintronics™ Anti-static Cloth



The Kintronics™ Tiger anti-static cloth is mostly lint-free, but the cloth edges are not finished or sealed, so some lint may be produced during use. Avoid exposing the cloth edges to the record. Otherwise, lint from the Kintronics™ Tiger anti-static cloth is visible in normal lighting and is easily removed by lightly brushing the record with the cloth. When using the Kintronics™ Tiger anti-static cloth to remove lint, periodically shaking the cloth during use (away from the record) will minimize transferring lint and particles from the cloth onto the record.

V.Step.12 Method w/o Stand: Place record with VinylStack™ Vinyl '1' Stack Record Label Protector on hard surface. Grip VinylStack™ Vinyl '1' Stack Record Label Protector and remove handle and outer record label protector. A few water drops are normal. Wipe away any visible drops with the Kintronics™ Tiger anti-static cloth. Flip record and wipe away any visible drops with the Kintronics™ Tiger anti-static cloth.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 22 – Step 12: VinylStack™ Vinyl ‘1’ Stack Record Label Protector Disassembly w/o Stand

V.Step.13 Optional Method w/stand: If using the stand modified per **Figure 11**, place record with VinylStack™ Vinyl ‘1’ Stack Record Label Protector on the Drying Stand. Grip label protector and remove handle and outer record label protector. A few water drops are normal. Wipe away any visible drops with the Kinetronics™ Tiger anti-static cloth. Flip record and wipe away any visible drops with the Kinetronics™ Tiger anti-static cloth.




Figure 23 – Step 13: VinylStack™ Vinyl ‘1’ Stack Record Label Protector w/Stand Disassembly

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



This process instruction has been designed for batch cleaning of up to about six (6) records. If cleaning only one (1) record, and time is not critical, the record can be left in the VinylStack™ Vinyl '1' Stack Record Label Protector to completely dry before proceeding to disassembly by **V.Step.12** or **V.Step.13**. However, the longer the record stays exposed to the ambient environment the greater the risk of invisible airborne particulate (such as fine lint that is visible with the UV Blacklight) depositing on the clean record.

V.Step.14 Final Dry: If cleaning more than one record, remove record from the VinylStack™ Vinyl '1' Stack Record Label Protector, place in dish rack such as the OXO™ Good Grips Dish Rack (*has soft rubber tips and can stack 6-records*), and repeat the process starting with **V.Step.2** or **V.Step.3**. Otherwise proceed to **V.Step.15**.



Figure 24 – Step 14: Records Drying on Rack

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Using a portable room or desk-type high efficiency particulate air (HEPA) filter can reduce the risk of the records being contaminated with airborne particulate during the drying step. Room or desk-top HEPA air filters are readily available at prices (and quality) that start at about \$75 and can increase to many hundreds of dollars for units such as those manufactured by Austin Air™ and Dyson™. The HEPA air filter elements are generally rated for about 2,500-hours of use or greater. Replacement HEPA air filters for small-room or desk-top units are generally about \$50 and greater. Selecting a stable supplier will ensure availability of replacement filters.

V.Step.15 Once completely dry, place clean record(s) in an anti-static, archival quality record sleeve. Inspection with optional UV light may show lint/particulate that can be removed by lightly brushing with the Kinetronics™ Tiger anti-static cloth. If cleaning three or more records, the first record will likely be dry and ready to sleeve after cleaning the third record.



Do not view a UV-Blacklight directly to avoid eye injury.



Minimize handling the PVA sponge and microfiber cloths with bare-hands to keep the sponge and cloths clean. Dry hands shed dead skin cells constantly. The PVA sponge and the microfiber cloth with gloved hands can be cleaned/rinsed with DIW. If the PVA sponge or drying cloths become so dirty to require detergent laundering, they should be replaced.

V.Step.16 Using the DIW spray or wash/rinse bottle, flush the Record Doctor™ Clean Sweep Record Brush, let dry and recommend storing in clean plastic bag or container to maintain cleanliness. Squeeze excess water from PVA sponge and store moist in a plastic bag or container. Hang microfiber cloth(s) to dry and once dry shake to remove any particulate, then recommend storing in clean plastic bag or container to maintain cloth cleanliness. Remove nitrile gloves and dispose, or if using reusable nitrile gloves, dry and store for future use.

CHAPTER VI. MAINTAINING CLEANLINESS:

Once record cleanliness has been established, the goal is to maintain cleanliness. The web has many good recommendations for record care such as handling to avoid fingerprints on the grooved surface, avoiding sunlight, packaging in anti-static, and lint-free archival quality record sleeves. But very small particulate and static can be a challenge, and some practices can do more harm than good.

- VI.1 In the technical paper *THE WEAR AND CARE OF RECORDS AND STYLI*, by Harold D. Weiler, 1954 (26) states “*Many methods have been devised and improvised to combat the problem of dust on records and to reduce its effect on wear and reproduction. However, none of these methods were ever completely effective, and they all passed into oblivion with one exception, the cleaning pad. Unfortunately, this device is in general use in 1954, despite the fact that it does not clean records! A record pad can actually damage records by scratching them and grinding microscopic particles of dust and grit into the grooves. In addition to causing excessive wear of records and styli, these dust particles also increase the noise level of the record. Since the particles of dust and grit are often as large as the recorded impressions in the record groove which create the sound, they will affect the stylus movement, causing random impulses which are translated as noise. This increase in noise level due to dust and grit is the biggest contributing factor to the hissing sound commonly and mistakenly referred to as “needle scratch”.*”
- VI.2 In the paper *Record Contamination: Causes and Cure* by Percy Wilson, 1965, (52) it echoes what Harold D. Weiler wrote and discusses how dry cleaning can give back more than it removes. The dry-cleaning material will ultimately become saturated with particle/soil and then instead of removing, redeposits to the record. The paper also states that “*...repeatedly-used damp pad or like device can become a positive menace.*”. And yet, the widely used Discwasher™ brush US Patent 3,951,841 of 1976 (13) which makes no mention of the papers Percy Wilson, 1965, and Harold D. Weiler 1954 states “*The brush of this invention is made of a developed fabric having a very fine, slanted and angularly oriented pile of sufficiently small fiber dimension to reach the bottom of the record grooves. The brush picks up and holds dirt when brushed against its angulated fibers, and the brush also soaks up, as in a form of capillary attraction, the fluid and the dirt mollified by the fluid. And, the angulated pile of this brush is designed to provide for release of its accumulated surface dirt and dust when brushed in an opposite direction on any other fabric surface.*”.
- VI.3 However, the use of record brushes and pads of various designs continues; used for the purpose of either removing some particulate or removing static charge through use of a conductive brush or wetted pad. One of the issues with static charge is that it causes the record to attract dust from the air that causes clicks and pops. *MIL-HDBK-263B Electrostatic Discharge Control (ESD) Handbook for Protection of Electrical and Electronic Parts, Assemblies and Equipment* (39), for purposes of Electrostatic Discharge (ESD) uses the following definitions, noting that conductive and dissipative materials are considered anti-static.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VI.3.a **Surface Conductive Material.** Materials with a surface resistivity less than 10^5 ohms per square, or materials with a volume resistivity less than 10^4 ohm-cm.
- VI.3.b **Surface Dissipative material.** Materials with a surface resistivity equal to or greater than 10^5 but less than 10^{12} ohms per square, or materials with a volume resistivity equal to or greater than 10^4 but less than 10^{11} ohm-cm. As a general note, dissipative in ESD terms generally implies that static charge is dissipated slowly - generally within a few seconds. Dissipative surfaces are used to prevent accidental shorting of sensitive semi-conductors if they were placed on a conductive surface.
- VI.3.c **Insulative material.** For the purpose of ESD protection, materials not defined as conductive or dissipative (greater than 10^{12} ohms per square or greater than 10^{11} ohm-cm) are considered to be insulative.
- VI.4 **Triboelectric Effect (source MIL-HDBK-263B (39)):** *“The generation of static electricity caused by contacting or rubbing two substances is called the triboelectric effect. A triboelectric series is a list of substances in an order of positive to negative charging as a result of the triboelectric effect. A substance higher on the list is positively charged (loses electrons) when contacted with a substance lower on the list (which gains electrons). The order of ranking in a triboelectric series is not always a constant or repetitive. Furthermore, the degree of separation of two substances in the triboelectric series does not necessarily indicate the magnitude of the charges created by triboelectric effect. Order in the series and magnitude of the charges are dependent upon the properties of the substance, but these properties are modified by factors such as purity, ambient conditions, pressure of contact, speed of rubbing or separation, and the contact area over which the rubbing occurs. **In addition to the rubbing of two different substances, substantial electrostatic charges can also be generated triboelectrically when two pieces of the same material, especially common plastic in intimate contact, are separated as occurs when separating the sides of a plastic bag. Some metals, can create significant charges from triboelectric generation. Aluminum, when rubbed with a common plastic can generate substantial electrostatic charges.”***
- VI.5 **Figure 25** is a Triboelectric series showing relative positions of various materials obtained from *Effect of the relative permittivity of oxides on the performance of triboelectric nanogenerator, Yeon Joo Kim, Jaejun Lee, Sangwon Park, Chanho Park, Cheolmin Park and Heon-Jin Cho, RSC Adv., 2017, 7, 49368*; modified to show the position of human hands. There are a number of published quantitative Triboelectric series, the most recent *Quantifying the Triboelectric Series* published 2015 (54). The table in this recent series compares similar to the previous widely accepted *The Triboelectric Series, Bill W. Lee, David E. Orr; ©2009 by AlphaLab, Inc (9)*.
- VI.5.a PVC is very high (potential for negative charge) on the triboelectric series. However, there can be substantial variation for natural products such as leather whose moisture level can

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

change the material from low (positively charged) to moderately high (negatively charged). The vinyl record is very susceptible to developing static charge, and the ambient humidity is probably the single greatest factor.

- VI.5.b. When the ambient humidity drops below 35% (common during winter) the probability of developing static charge is high. Using a room humidifier has benefit, bacteria and particulate generation notwithstanding. A simple recommended practice by Dr. A.J. van den Hul <https://www.vandenhul.com>; is to place a sponge (recommend anti-bacterial) wetted with distilled water to increase the localized humidity in the vicinity of the turntable. Monitoring home humidity is worthwhile, and inexpensive devices such as the Acu-Rite™ Model 01083M are readily available (<https://www.acurite.com/acurite-01083m-pro-indoor-temperature-and-humidity-monitor.html>);).




Figure 25 – Triboelectric Series
(Image Courtesy of RSC Adv., 2017, 7, 49368)

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VI.6 In the triboelectric series, human hands can be very positively charged (loses electrons) while vinyl records (mostly PVC) can be very negatively charged (gain electrons). Use of a conductive brush to remove static from a record that is intended to use the human body as the ground path may not work if the human body is not grounded, and even then, the human body depending on many variables may at best only be dissipative. Referring to **Table III**, in a humid environment, the human body resistivity can be low enough to be conductive, but in dry air when developing static on a record is common, the human body is at best dissipative. Otherwise, depending on the ambient conditions, the opposite may occur, the human body via the conductive carbon-fiber brush may actually charge the record. So, always ground yourself to something metal before using a conductive brush to remove static from a record.

Table III
Human Hands Electrical Resistance

Human Hands Condition	Resistance	
	Dry	Wet
Finger Touch	40 kΩ to 1 MΩ	4 kΩ to 15 kΩ
Finger-Thumb Grasp	10 kΩ to 30 kΩ	2 kΩ to 5 kΩ

- VI.7 The article *Phonograph Reproduction 1978*, James H. Kogen, *Audio Magazine May 1978 (28)* goes into some detail on static; what causes it and what does not – the needle in the groove was not a source of static. The article indicates that static is not uniform, but exists as islands on a record. Additionally, once the static gets high enough to discharge to the cartridge it only reduces to about 4200 volts. A static charge on the record of 4200 volts will not create noise by itself, but it can by electrostatic attractive forces cause a transient increase in cartridge VTA as much as 0.375 grams leading to distortion and premature wear. So, managing static has many benefits. Deep wet cleaning as delineated in **CHAPTER V. MANUAL CLEANING PROCESS;** **CHAPTER XIII. DISCUSSION OF VACUUM RECORD CLEANING MACHINES;** and **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES;** will remove any and all static from the record. Then it becomes, an issue of maintaining cleanliness.
- VI.8 **Brushes:** The three popular brush materials for anti-static (conductive brushes) and dust are carbon fiber and Thunderon® with the following details from Gordon Brushes® (24), and Corebrid®.
- VI.8.a **CARBON FIBER:** *A very fine [Ø 0.000283] (~7.6 microns) fiber of 95% pure carbon. Fiber has a tensile strength of 575 ksi, a tensile modulus of 35 msi, and an electrical resistivity of 0.00055 Ohms in. Popular in light touch to non-contact grounding brushes due to its high conductivity. Not recommended for uses with high flexural requirements since carbon fiber has low flex fatigue resistance and can break off rather easily.* This implies that carbon brushes should only be used to just lightly touch the record. Also, the carbon fiber diameter is small enough to deeply penetrate the record groove which could lead to fiber break-off creating particles instead of removing particles. There are many variations of carbon record brushes. The most efficient are those used by the ESD industry that have a full aluminum handle for maximum fiber conductivity such as [Carbon Fiber Brushes \(amstat.com\)](http://amstat.com).

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VI.8.b **THUNDERON®:** *An extremely soft acrylic fiber that has been chemically bonded with a layer of copper sulfide. This outer layer becomes a part of the host fiber itself, which precludes the 'flaking' problem experienced by other conductive fibers. The fiber diameter is available in two diameters, 0.07 mm (0.0028"/~70 μm) and 0.11 mm (0.0043"/~110 μm). Its conductive layer is a super thin 300-1,000 (angstroms). Thunderon® has an electrical specific resistance of $10^1 - 10^2 \Omega \text{ cm}$.".* Thunderon® while classified as conductive, is not as conductive as carbon fiber, but the bristle diameter will not deeply penetrate the record groove and the product flexibility is less prone to fracture and breaking off. The common brush design has the bristles embedded in a conductive plastic handle.
- VI.8.c **COREBRID™ B®:** A hollow acrylic fiber that is filled with a conductive material manufactured by Mitsubishi Chemical™. This fiber is 0.03 mm (0.0012"/~30 μm) diameter and its electrical resistance measures between $10^0 - 10^2 \Omega \text{ cm}$. This fiber is used in the Analog Relax™ record brush.
- VI.8.d A simple observation of a carbon fiber or Thunderon® record brush with bright white light or UV blacklight at 30 to 45-degree angle can observe that the brushes often only move the dust. This is consistent with the *NASA/TM—2011-217231, report on Evaluation of Brushing as a Lunar Dust Mitigation Strategy for Thermal Control Surfaces (49)* that evaluated the effectiveness and performance of various brush materials and designs to remove dust from thermal control paint or aluminized thermal control surface. The report summarized that *"Although there was only one carbon bristle brush tested, it had by far the poorest performance."* The NASA study also tested Thunderon®. The Thunderon® was in laboratory conditions effective in removing dust from the aluminized thermal control surface, but not effective in removing dust from thermal control paint surface. The NASA report indicated that the best brushes for removing particulate were the Zephyr™ fiberglass fingerprint brush and the Escoda™ Nylon fan brush. However, these brushes penetrating the record groove potentially doing more harm than good but are very effective in removing dust that accumulates on the turntable.
- VI.8.e Nylon brushes such as the Record Doctor™ Cleaning Brush are beneficial as a 'wet' cleaning brush since the bristle diameter at 0.002" will not deeply penetrate the record groove. But used "dry" can cause a static charge to develop on the vinyl record because of the triboelectric effect with the Nylon having a strong positive charge and the vinyl record having a strong negative charge.
- VI.9 **Removing & Preventing Static:** How to remove static and dust from the record surface without doing more harm than good? From the preceding discussion, removing static and particulate are two different problems.
- VI.9.1 Static can be removed from the record by using conductive brushes, but these should just barely contact the record surface and you should be grounded unless the brush has a

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

separate ground wire. There are tonearm-like anti-static sweepers that use a conductive brush and ground-wire to continuously remove static during record play.

- VI.9.2 Other methods to minimize static include increasing the ambient humidity (the most effective). Additionally, the web addresses success with point of use ionizing devices such as the Milty Zerostat™ 3 Anti-static Gun, and the continuous DS Audio ION-001 Vinyl Ionizer. But be advised that any ionizing device can develop ozone and that Buna-N (nitrile) rubber is very sensitive to cracking when exposed to ozone; while EPDM (ethylene propylene diene monomer) rubber is not ozone sensitive.
- VI.9.2.a Inexpensive plasma arc lighters such as the RONXS™ Candle Lighter [RONXS Lighter, Candle Lighter with Multi-protect Safety System, Rechargeable | RONXS](#) can be used to remove static. The reason they work is that the blue arc that is created is a corona. And corona's produce charged electrons; and this device being VDC depending on the charge of the anode - can produce either negative or positive electrons. Audio forums have stated that the RONXS™ device works which indicate that it is producing positive electrons that neutralize the negative electrons (static) on the record. For use, some have stated to circle the record for a few seconds, while others apply as the record is turning - move across the record for a few seconds both of which will bath the entire record surface in positive electrons; keeping the device about 1" above the record surface. For information, a small amount of ozone is produced; however only infrequent use (not more than a few seconds per 1/2-hr) should be of little concern.
- VI.9.2.b For carpets and rugs, rubbing the surface near the turntable with a clothes dryer-softener sheet is an effective method for applying a temporary anti-static coating (residue) to a carpet or rug. Anti-static record sprays will likely leave a film on the record containing a quaternary ammonium salt ingredient that is also a cationic surfactant commonly used in strong disinfectants – see **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS:** for discussion of surfactants and anti-statics.
- VI.9.3 Grounding the record platter if metal can sometimes help to reduce static charge on the record. In this case, a ground strap/wire is connected between the platter bearing housing and an electrical ground point. Different ground locations can have different results. The first ground attempt should be to the phono-preamp ground connection. If this is not successful try a ground point closer to the outlet providing VAC power to the audio system and connecting to the VAC outlet ground via the cover plate attachment screws is an option.
- VI.9.3.a In accordance with *NASA Electrical Bonding: A Survey of Requirements, Methods, and Specifications, NASA/CR-1998-207400, Mar 1998 (47)*, effective bonding (grounding) for non-explosive electrostatic discharge should be 10 megohms or less resistance to ground. This is easily achieved with a simple single gauge wire. However, this industry ESD requirement is intended for safety, and is not designed to drain as much static charge as possible to minimize a vinyl record attracting dust that leads to clicks and pops. The

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

NASA paper addresses that for fuel systems, the electrostatic discharge bonding should be 1-ohm or less resistance to ground.

- VI.9.3.b Realistically, providing the lowest impedance path to ground is the goal. Tinned-copper braided cable at 1/4-inch wide is readily available and can be used to easily assemble a low impedance ground cable using appropriate end-connectors, 1/4-inch PET expandable braided sleeving for appearance and protection, and heat shrink to seal the ends. The 24-inch 1/4-inch wide tinned-copper braided cable in **Figure 26** measured 0.1-ohms while the 24-inch green single gauge wire ground measure 0.3-ohms. For short distances, the difference is marginal, but if you need to ground back to a wall outlet that is 8-feet away, the difference may be more significant.



Figure 26 – Ground Cable

- VI.10 **Static & Record Mats:** Various record mats have been reported to have various levels of success in removing or preventing static. I have success with a Do It Yourself (DIY) record mat material that is used for ESD Work Surfaces shown **Figure 27**. The material is Bertech™ ESD Vinyl Mats and Mat Kits, 3059 Series [ESD-Vinyl-Mats-Datasheet-3059.pdf \(berotech.com\)](https://www.berotech.com/ESD-Vinyl-Mats-Datasheet-3059.pdf). The material is only 0.1" (3/32) thick but is 3-layers. The top is lightly embossed (gray or blue) vinyl that is formulated to be dissipative, the bottom is smooth vinyl that is formulated to be dissipative and the center is a conductive 'fleece'. The material is stiff (but the center is porous and not completely hard) with durometer of 85A so it has some damping, but can be cut with scissors. The center is electrically conductive. The Bertech™ 3-layer mat surface is specified as being impervious to just about any cleaner so durability of anti-static properties should be very good. Note: It comes rolled-up, and after cutting will take some time to fully flatten. Also, slightly undercut the spindle hole of the mat with a box cutter tip to make sure it makes good contact with the spindle.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 27 – Bertech™ ESD Vinyl Record Mat

- VI.10.a My aluminum platter/spindle is grounded as specified (**paragraph VI.9.3**) to a wall outlet and measured 0.5-ohm between the conductive mat center and the wall outlet. But the mat surfaces being vinyl match the record material but being embossed is not a tight seal to the record so static should not be developed. Any static on the record should be dissipated across the surface to the grounded spindle or through the top dissipative vinyl cover to the conductive center to the grounded spindle. Even though the platter shaft/spindle is grounded, any static charge that is conducted to the platter, the path of least resistance can be to the record if it is in direct contact (large surface area) noting that the platter bearing is lubricated which provides some insulation, and only the spindle is in direct contact with the platter. The top and bottom dissipative vinyl surfaces prevent triboelectric effect from the aluminum platter to the record. And, any static charge that may be conducted to the platter from the EPDM rubber drive belts is dissipated by the mat to the platter spindle.
- VI.10.b The mat material and use are not breaking any new ground; it just appears to be a good collection of anti-static and damping properties that follows established ESD such as ground all conductors and minimize insulating type materials. Unfortunately, the insulating vinyl record that as previously addressed is very negative on the triboelectric scale cannot be eliminated. The article *Do Turntable Mats Work? You Bet! Robert Stockton, Audio Magazine June 1979 (59)* goes into a good summary on the topic and no reason to repeat here and further illustrates the flow of static charge and the benefits of damping.
- VI.10.c Prior to the Bertech™ ESD mat, for a couple of years, I was using a very thin (~1mm) leather mat – suede side-up/skin side-down that I cut from a remnant. However, I started to notice that side-two of the record was noisy and overall, the records were noisy. A quick check with a UV light showed the problem (see **Figure 28**) – the mat was full of fibers and once

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

it had become saturated with fibers it began giving them back; and no amount of brushing or beating was going to clean it. Before this thin leather mat, I “briefly” tried a store-bought thicker leather record mat. So much static developed that the record lifted the mat from the platter. So, the experience with the leather mat highlighted the need to be more careful with mat cleanliness.




Figure 28 – Leather Mat Under UV Light

VI.10.d Earlier in 2020 I tried the Technics/Panasonic™ mat PN RGS0008. This is a 3 mm thick relatively soft rubber mat. It is likely manufactured from nitrile rubber (near neutral on the Triboelectric scale) because it did not attract dust/lint/particulate and any was easily brushed away. So, this mat met the cleanliness criteria. However, it so affected the acoustic performance that after a while I found myself listening more to my digital sources than my vinyl; and my vinyl source by design is supposed to be better than my digital. The best way to explain the effect was that it softened and homogenized the music. It’s that soft focus that makes everything look (and sound) good; but takes away all the interesting details. So, damping by the record mat can have a profound effect. However, this mat is now used as a covering after play for protection from dust or any hard objects.

VI.11 **Dust & Particulate:** As far as dust and particulate, there is an entire science for precision cleaning to remove particulate from surfaces, and good sources are the paper *Adhesion and Removal of Fine Particles on Surfaces, Aerosol Science and Technology*, M. B. Ranade, 1987 (38) and the 573-page book *Particle Adhesion and Removal*, Editors K.L. Mittal and Ravi Ja, John Wiley & Sons, Inc, 2015 (53). Curiously enough, the book makes no mention of any bristle type brushes for particulate removal; but the chapters on wipes is focused on flat surfaces associated with semi-conductor chips and cleanroom maintenance. The record with its finely grooved surface presents quite a challenge.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VI.11.a The paper *Record Contamination: Causes and Cure by Percy Wilson, 1965, (52)* makes an observation that the record in motion draws contaminants to it. The observation was made by blowing tobacco smoke across the record and watching how it deposited. This observation is likely flawed since the density of tobacco smoke is about 1000X higher than air (66), so if exhausted over the record it will deposit/fall upon it by simple gravity; and the deposition will follow the spinning groove motion. The record motion is not fast enough to develop air currents large enough to counter the weight of the tobacco smoke. However, for many households, tobacco smoke is no longer a source of contamination. My own observations pre- and post-play with UV light shows no signs of particle deposition during play (also noting that household cooking grease/oil aerosols fluoresce brightly under UV light). If the record is allowed to sit stationary – yes, particles in the air will drop onto the record.
- VI.11.b Camera lens blowers may be OK for lens or delicate sensors, but the air flow is often not enough to dislodge fine lint that electrically attaches to the vinyl record or stylus, and very few have an inlet air filter to prevent depositing lint/particulate. Additionally, there is risk of blowing very fine particulate that is only on the record surface deeper into the record groove. The Orbit HEPA Blower <https://photosol.com/products/orbit-hepa-blower/>, does have a suction-side HEPA filter and uses an anti-static silicone air-bulb, and limited success has been noted with removing some dust.
- VI.11.c Ultimately, as stated in the opening paragraph of this chapter, the recommendations of *THE WEAR AND CARE OF RECORDS AND STYLI, Harold D. Weiler, 1954 (26)* and *Record Contamination: Causes and Cure by Percy Wilson, 1965, (52)* are still applicable. In essence once cleanliness is achieved, the only item that should see the groove is the stylus. A very light brushing with anti-static brushes can remove some surface particulate. I have had some success using the Kinetronics™ Tiger anti-static lint-free microfiber cloth, and others have reported success with silk cloth. A smaller piece cut from the large cloth used as a swipe (just lightly touching the record surface) to essentially brush/dust the record can remove surface lint and particulate without penetrating the groove. Also, the orange color of the cloth allows easy observation of any fibers that may be deposited from the cloth.

REMAINDER OF PAGE INTENTIONALLY BLANK

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER VII. DISCUSSION OF WATER QUALITY:

Table IV lists a variety of water quality specifications from potable/tap (drinking) water, to purified water to pure-water to ultra-pure water. Detailed discussion of water purification methods is available in the *GE-Osmonics™ Pure Water Handbook (18)*.

Table IV
Water Quality Specifications

Specification	Resistivity (ohms-cm)	Total Dissolved Solids (ppm) (see Note 1)	Water Classification
EPA Drinking Water Standards	>1.0K	<500 ppm	2018 Edition of the Drinking Water Standards and Health Advisories Tables
MIL-STD-1330D Grade B (see Note 2)	>50K	<10 ppm	Purified Water by Distillation, Mixed-Bed Resin or Reverse Osmosis
ASTM D1193 Type 4 (see Note 3)	>200K	<2.5 ppm	Purified Water by Distillation, Mixed-Bed Resin, or Reverse Osmosis
MIL-STD-1330D Grade A (see Note 4)	>400K	<1.25 ppm	Pure Water by multiple steps of Distillation or Mixed-Bed Resin
ASTM D1193 Type 2 (see Note 5)	>1,000K	<0.5 ppm	Pure Water by multiple steps of Distillation and or Mixed-Bed Resin
ASTM D1193 Type 1 (see Note 6)	18,000K	<0.028 ppm	Ultra-Pure Water prepared by many steps such as triple distilled

Notes:

1. Total dissolved solids (TDS) listed is a conversion from resistivity and for purified water and better assumes only chloride and sodium salts, and uses a conversion factor of 0.5. The formula for TDS = $(K) \times (1/\text{Resistivity})$.
2. The U.S. Navy MIL-STD-1330D Grade B water (42) is used for final rinse after cleaning of general high-pressure oxygen system components. The specification allows some degradation of purified water quality when used in a general environment; i.e., not within a cleanroom. Once purified water is packaged or exposed to a general environment, the quality can quickly degrade from the ambient contaminants.
3. ASTM D1193, Standard Specification for Reagent Water (6), Type 4 is achieved by distilled water (condensation of steam).
4. The U.S. Navy MIL-STD-1330D Grade A demineralized pure-water (42) is used for final rinse after cleaning of critical high-pressure oxygen and life support system components. The specification allows some degradation of Pure Water quality when used in a more controlled environment; such as a Class 100,000 cleanroom with personnel wearing appropriate cleanroom clothing.
5. ASTM D1193 Type 2 pure water (6) is commonly used for preparation of precision cleaning solutions; and used in precision cleaning processes. But, once exposed to air will degrade from absorption of air contaminants such as carbon dioxide.
6. ASTM D1193 Type 1 ultra-pure water (6) is intended for critical laboratory analyses and often used for extreme precision cleaning of semi-conductors in carefully controlled environments such as a Class 100 cleanroom.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Table V
Residue Thickness Microns from Water Residue

Water Quality	ppm	mg/L	mL of Water Allowed to Dry on Record				
			0.25	0.50	1.00	2.00	3.00
Ultra-Pure	0.028	0.028	0.00000	0.00000	0.00000	0.00000	0.00000
Pure	0.5	0.5	0.00000	0.00001	0.00002	0.00004	0.00005
	1.5	1.5	0.00001	0.00003	0.00005	0.00011	0.00016
Purified	2.5	2.5	0.00002	0.00004	0.00009	0.00018	0.00026
	10	10	0.00009	0.00018	0.00035	0.00070	0.00105
Tap-Water	100	100	0.00088	0.00175	0.00351	0.00702	0.01053
	200	200	0.00175	0.00351	0.00702	0.01404	0.02105
	400	400	0.00351	0.00702	0.01404	0.02807	0.04211
	800	800	0.00702	0.01404	0.02807	0.05614	0.08421
	1600	1600	0.01404	0.02807	0.05614	0.11228	0.16842

VII.4 **Home Production of DIW:** In some locales or countries, where the quality of tap water is questionable with either high TDS or high suspended solids, or ready access to Purified water is not available, various alternatives are available. These alternatives are home water distillers or multi-stage filters that combine at least a sediment filter to remove particulate, a demineralizer to remove TDS, and sometimes a carbon filter to remove soluble organics (often noted as odor). The following are examples of a distiller and two filter-systems that can produce purified water. Similar if not the exact equipment is available EU/UK.

VII.4.a Countertop water distillers are available such as the H2O Labs™ Models 100, 200 and 300 [Countertop Water Distillers | Home Water Distiller Systems from H2O Labs](#). The model 200 can process 1 gallon (3750 mL) of tap water in approx. 5 hours using about 3-kW of power (0.6 kWh). Periodic cleaning and descaling with white vinegar or specific descaling chemical is required; some reporting after every 5-7 gallons. The H2O Labs™ Model 200 MSRP is \$199; and each anti-scale pad is \$9.90 and is good for 3-6 months and activated carbon pods (if using for drinking water) are \$29.90 for six and last 30-gallons each. It's unknown how long the device will last, but some users report years of operation producing 1500+ gallons before failure. Assuming a 6-yr use at 300-gal/yr; 1800-gallons total, the item cost would be \$199 for the unit; \$299.90 for carbon pads, and \$237.60 for anti-scale pads, and \$396 for 300 cleanings with the H2O Labs™ cleaning crystals (\$29.50 for 1-lb at \$1.32/cleaning). The total life cycle cost could equal = \$1,132.50 not including cost for power; resulting in a cost/gallon of (\$1132.50/1800 gal) = \$0.63/gallon.

VII.4.b There are a number of vendors manufacturing countertop pitcher/filter systems that can produce Purified water. The ZeroWater™ units [Water Filters & Water Filter Pitchers - Clean Water at Home – ZeroWater](#) have the benefit of containing the most amount of demineralizer resin. Each filter can produce from 40-gals with very low TDS tap-water (<50 ppm) to about 8-gals with very high TDS tap-water (>400 ppm). The filter MSRP is two filters for about \$30, and a 30-cup/240-ounce pitcher with one filter MSRP is about \$40. Assuming a TDS of 150 ppm, each filter should produce about 30-gals of purified


Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

water; and the initial cost of purified water would be $(\$40/30\text{-gals}) = \$1.34/\text{gal}$. Follow-on cost based on the two-filter replacement cost would be $(\$30/80\text{-gals}) = \$0.38/\text{gal}$ not including the cost of the tap-water.

VII.4.c For those who process a lot of records, purchasing a large, refillable demineralizer can significantly improve access to and reduce the cost of purified-water; one example is <https://dirinse.com/product/d-i-rinse-pro-50-unit/>; If tap water is of reasonable quality, this demineralizer can produce about 2000 gallons of demineralizer water at an initial cost of about \$0.20/gallon, and it can be refilled (~\$200 for 2 resin refills), and the valve arrangement makes a very convenient install. Follow-on cost would then be $(\$100/2000\text{-gals}) = \$0.05/\text{gal}$. An outlet filter is generally recommended and a 10-inch Pentek™ housing and 1-micron filter (see **paragraphs** XIV.17 and XIV.19.1) will cost about \$50, with replacement filters less than \$10 each. This sediment filter should last at least 2000-gals for an initial cost of $(\$50/2000\text{-gals}) = \$0.03/\text{gal}$ with follow-on cost of $(\$10/2000\text{-gal}) = \$0.01/\text{gal}$ not including the cost of the tap water. For those who wash their own cars, purified water systems such as this are often used to get a spot-free rinse.

VII.5 **Deionizing Resin:** The following example with sodium-chloride salt (NaCl) illustrates how the deionizing/demineralizing process functions to produce pure water. An H/OH mixed-bed resin is used to exchange ions (such as mineral salts) for hydronium ions (H_3O^+) and hydroxide ions (OH^-) that combine to form pure water. Because resin exchanges ions, it has a limited life; and the amount it can purify is directly proportional to the resin bed size and the influent TDS. There are different grades of H/OH mixed-bed resin depending on use; demineralization of tap-water to produce purified water or polish to achieve pure water. Resin is recyclable by regenerating it with a strong acid backwash restoring the hydronium ions and a strong base backwash to restore hydroxide ions.



VII.6 An unrelated but common question that arises – Is purified (demineralized) water safe to drink? The World Health Organization (WHO) has studied the health aspects and the details are documented *WHO Nutrients in Drinking Water, 2005 (69)*. Long term use should be approached with caution due to chronic electrolyte imbalance. Using to rehydrate during and after any excessive sweating activity will not replace critical electrolytes and any number of acute electrolyte imbalance symptoms can occur. But Naval ships that can be at-sea for 90-days, all have some form of water purification – either distillation or reverse osmosis; and other than adding a disinfectant (bromine or chlorine) no other treatment is routinely performed (source *Manual of Naval Preventive Medicine, Chapter 6, Water Supply Afloat(36)*).

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER VIII. DISCUSSION OF PRE-CLEANERS:

Fundamentally, and consistent with the precision aqueous cleaning processes discussed *MIL-STD-1330D* (42) and *MIL-STD-1622B* (43), any safe, compatible, and effective broad-based cleaner can be used for the pre-clean step.

- VIII.1 Alconox™ Liquinox™ is recommended as a pre-cleaner that is safe, effective, compatible (with appropriate exposure) with both the vinyl record and the final cleaner, and of known ingredients from a long-established supplier. Additionally, detailed technical information is readily available at <https://alconox.com>; and product is readily available to the consumer at a reasonable cost. Some general details of Alconox™ Liquinox™ are provided as follows:
- VIII.1.a The product is a combination of anionic surfactants (good for general detergency), nonionic surfactants (good for oil emulsion and wetting) and foaming agent (to lift and float debris from the surface).
- VIII.1.b The product is concentrated with about 50% active ingredients, the remainder water. So, a 1% solution is about 0.5%/5,000 ppm active.
- VIII.1.c The product mixes easily, rinses easily and the 1.0% neutral pH product surface tension is 29 dynes/cm, so it has excellent wetting capability.
- VIII.1.d The Alconox™ Liquinox™ surfactant blend of anionic and nonionic surfactants is compatible with the Dow™ Tergitol™ 15-S-9 nonionic final cleaner and with appropriate exposure the vinyl record (see **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:** for further discussion of material compatibility).
- VIII.1.e The product is non-flammable, is biodegradable, has no reported acute or chronic toxicity hazards, and has been widely accepted and used in many industries for many years, and product quality is very high.
- VIII.2 To better understand the ingredients of cleaning agents, the following brief overview of surfactants is provided for information, but no attempt is being made to formulate cleaners. It is my position that there are adequate detailed formulations readily available for pre-cleaning such as Alconox™ Liquinox™.
- VIII.2.1 The term "surfactant" is a contraction of "surface-active agent," and includes synthetic organic chemical products used for purposes such as wetting, emulsifying, dispersing, solubilizing, and foaming. Aside from cleaning agents there are 100's of different surfactants used in 100's of different products.
- VIII.2.2 Surfactant molecules consist of two parts – the head that is water soluble often called hydrophilic (water-loving) and a tail that is oil-soluble often called hydrophobic (water-

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

hating) or lipophilic (oil-loving). Surfactants when they are first added to water collect at the surface lowering the surface tension. There is a concentration when the surface tension will not decrease any further, and this point is known as the “critical micelle concentration” (CMC).

VIII.2.3 When the surfactant concentration is greater than the CMC, the surfactant forms aggregate cylindrical and spherical type structures called “micelles” as illustrated **Figure 29**. As the micelle forms, the surfactant hydrophilic heads position themselves so they are exposed to the water, while the lipophilic tails are grouped together in the center of the structure protected from the water. Micelles are what provide the detergency of a surfactant. As the surfactant concentration increases other micelle structures can form. The hydrophobic/lipophilic (oil-loving) tails of the surfactant micelle are what surrounds soils and releases them from the surface being clean, and depending on the specific ionic nature can perform functions such as oil emulsification, foaming, and antibacterial. To provide adequate reserve of micelles for cleaning, concentrations of 5 to 20 times the CMC are generally used. Basic spherical and cylindrical micelles can measure from about 4 to 15 nano-meters (nm) = 0.004 to 0.015 microns, while oil emulsions can measure 10 times greater.




Figure 29 – Surfactant Micelles
(Image from United States NIST Information)

VIII.2.4 Depending on the electrical charge of the hydrophilic head, the surfactant is classified as anionic, cationic, nonionic or amphoteric.

VIII.2.4.a Anionic surfactants ionize in aqueous solutions so that the hydrophilic head has a negative (-) charge.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VIII.2.4.b Cationic surfactants ionize in aqueous solutions so that the hydrophilic head has a positive (+) charge.
- VIII.2.4.c Nonionic surfactants for the most part do not ionize in aqueous solutions so that the hydrophilic head has a neutral charge. A unique property of nonionic surfactants is “cloud point”. Cloud point is the temperature when the mixture starts to phase-separate, and two phases appear, thus becoming cloudy. The cloud point is the optimum temperature for nonionic surfactant detergency, but above the cloud point the surfactant comes out of solution and detergency drops.
- VIII.2.4.d Amphoteric surfactants can ionize in aqueous solutions so that the hydrophilic head, depending mostly on the solution pH, is either anionic (-) or cationic (+).
- VIII.2.5 Each type of surfactant has different strengths, and for general cleaners are blended along with other ingredients (commonly called ‘builders’) to achieve the desired performance. Blended surfactants can form blended micelles that can enhance the properties of the surfactants.
- VIII.2.5.a Anionic surfactants are used to attack a broad range of soils. They are the primary ingredient of most general cleaning agents. Anionic surfactants have excellent foaming characteristics to float away soils, are very effective for displacing visible particulate, but are not as good at emulsifying oil, are generally not compatible with acidic solutions and tend to require relatively large concentrations for effectiveness.
- VIII.2.5.b Cationic surfactant strengths are their disinfectant and anti-static characteristics, and these are very common in commercial and consumer antibacterial spray cleaners. Contact-time is required for cationic surfactants to work. Cationic surfactants (such as quaternary ammonium compounds) are generally not soluble with anionic surfactants, and if mixed in an aqueous solute (i.e., water) can form an insoluble – described as ‘gooey’ - precipitate/paste. This risk is generally not associated with a surface that has a thin layer of quaternary ammonium compound cleaned with a large volume of anionic surfactant cleaner. But, if a record had anionic surfactant residue from incomplete rinsing, and then a light spray of anti-static containing a cationic surfactant was applied, a precipitate/paste “could” form.
- VIII.2.5.c Nonionic surfactant strengths are their ability to emulsify oil and to achieve very low water surface tensions at very low concentrations. Dow™ Tergitol™ 15-S-9 at 52 ppm can lower the surface tension of water to 30 dynes/cm. When cleaning very small and complex geometries – i.e., the record groove, the ability to wet the surface is crucial and is enhanced by a fluid with a low surface tension. For perspective, CFC-113 (Freon™ PCA) had a surface tension of 17.3 dynes/cm. Nonionic surfactants are soluble with either anionic or cationic surfactants.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

VIII.2.5.d Amphoteric surfactants are most often used in personal care products such as shampoos and cosmetics.

VIII.3 Supporting the discussion of surfactants, is the concept of ‘wetting’. All fluids have a surface tension measured in dynes/cm (English units); “*the attractive force exerted upon the surface molecules of a liquid by the molecules beneath that tends to draw the surface molecules into the bulk of the liquid and makes the liquid assume the shape having the least surface area.*” All solids have surface energy that is likewise measured in dynes/cm and is often called “critical surface tension”. Most metals have a very high critical surface tension (copper = 1360 dynes/cm), much larger than the surface tension of water (72 dynes/cm). But the PVC/PVA in a record is very low at 38/36 dynes/cm; much lower than water. When a fluid is placed on a solid surface, depending on the difference in surface tensions (and other factors), the fluid will form a contact angle with the surface, and this is illustrated in **Figure 30**.




Figure 30 - Contact Angles and Wetting

VIII.3.a Absent any surface oil or similar contamination, if water (at 72 dynes/cm) is placed upon copper (at 1360 dynes/cm) it will ‘wet’ the surface. The contact angle will be essentially 0°. This concept of water wetting a surface is sometimes used in verifying metal surface cleanliness by ‘water-break’. If water is sprayed on a clean metal surface it will wet the surface. If there is oil on the surface, the water will bead-up (large contact angle).

VIII.3.b Given the proportions of a record, its critical surface tension is likely closer to PVC than PVA, but both are listed for completeness.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VIII.3.c However, in **Figure 30**, the critical surface tension of the record's materials is much less than water, and the large contact angle produced by water is consistent with **Figure 19** that shows DIW beads-up when sprayed on the clean record.
- VIII.3.d But, the Alconox™ Liquinox™ (and Dow™ Tergitol™ 15-S-9) low surface tension that is less than the record materials critical surface tension wets the record, and this is evident in **Figure 15** (and **Figure 17**).
- VIII.3.e Wetting is important since it allows the cleaning fluid to fully contact the surface being cleaned. Wetting alone does not dictate cleaning performance; there is still the chemistry and its performance with various soils. Adding agitation enhances cleaning performance. However, a flowing fluid can overcome surface tension differences and this is evident in **Figure 14**. The initial flowing tap-water rinse wets the record surface.
- VIII.4 There are a variety of different record cleaning solutions in the market whose effectiveness is discussed on the various audio forums. The author makes no assessment or recommendation of these products due to the absence of a Material Safety Data Sheet (MSDS) with detailed ingredients. On the web at various forums there is a lot of discussion of various do-it-yourself (DIY) mixed record cleaning solutions. As addressed in this paper's opening **Forward**, there are many 'opportunities' to experiment. The following discusses only some of the more frequently addressed products, and discusses only those that the MSDS, or equivalent, has sufficient detail to analyze. This review is provided only as information to guide an informed decision, and to advise of any risks and environmental hazards.
- VIII.5 HOUSEHOLD DISH DETERGENT: The ingredients of many household dish detergent can be viewed at the *Consumer Product Information Database (CPID)*, <https://www.whatsinproducts.com/>. Most are basically a mild alkaline detergent with anionic surfactants, ethanol and sodium hydroxide (for pH) as primary ingredients. Some well-known brands can have as much as 10% ethanol. But, many of the most common contain as many as 14 other ingredients including isopropyl alcohol, d-limonene (sometimes listed as lemon oil or orange citrus), fragrances, dyes, gelation additives and maybe nonionic surfactants. Some of these ingredients in concentrated forms are listed by various plastic material manufacturers as being incompatible with PVC. While household dish detergents are generally used at low use concentration, the combination(s) may not be compatible with vinyl records (see **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY**: for additional discussion), especially the critical groove side wall ridges. Additionally, these detergents if used in excessive amounts will be difficult to fully rinse, potentially leaving detrimental residue. Any use for cleaning vinyl records should be approached with caution noting the advice in **Table II** for those in the EU/UK that cannot obtain Alconox™ Liquinox™.
- VIII.6 **ILFORD™-ILFOTOL™**: This is a wetting agent that is water mixed with a combination of 1-5% nonionic surfactant and <1% of an antibacterial inhibitor that can extend shelf-life. This wetting agent/cleaner will foam if agitated/shaken aggressively.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VIII.6.a The 2015 MSDS (manufacturers will reformulate products) indicates a nonionic surfactant that by the chemical abstract system (CAS) number 68131-39-5 is likely either Stepan™ BIO-SOFT™ N25-7 or N25-9. These nonionic surfactants are similar to Dow™ Tergitol™ 15-S-7 or 15-S-9 and have similar surface tension and CMC (see **CHAPTER IX. DISCUSSION OF THE FINAL CLEANERS:** for details). The product literature lists no surface tension data, but the Stepan™ BIO-SOFT™ N25-7 or N25-9 ingredient should result in about 30 dynes/cm. Some on the internet recommend for cleaning records to mix 50-mL to 1000 mL, that could yield a nonionic surfactant concentration of as much as 0.25% which is excessive. See **CHAPTER IX. DISCUSSION OF THE FINAL CLEANERS:** for using this product at 0.1% active nonionic surfactant as a final cleaner.
- VIII.6.b The antibacterial agent by the CAS number 55965-84-9 is widely used in many applications such as metal working fluids, circulating water systems, and paints and is a blend of methylchloroisothiazolinone (CMIT) and methylisothiazolinone (MIT). While the biocide is dangerous in a concentrated form, the diluted biocide that is also used in cosmetics is reasonably safe as determined by this toxicological report - [https://ec.europa.eu/health/scientific ... o 009.pdf](https://ec.europa.eu/health/scientific...o009.pdf), and its conclusion - "On the basis of the data submitted, the SCCS is of the opinion that the mixture of 5-chloro2-methyl-4-isothiazolin-3-one and 2-methyl-4-isothiazolin-3-one in a ratio of 3:1 does not pose a risk to the health of the consumer when used as a preservative up to a maximum authorised concentration of 0.0015 % in rinse-off cosmetic products, apart from its sensitising potential.". The CMIT/MIT biocide (commercially sold as Kathon™ in a concentrate) is effective at very low concentrations less than 15 ppm.
- VIII.6.c ILFORD™ recommends use beginning at 1-part cleaner to 200 parts water yielding a nonionic-surfactant concentration as high as 0.025% which could be as high as 10X the CMC, useable as a single point of use, photographic wetting agent with some detergency. As a wetting agent only, 0.0125% 5X the CMC would work.
- VIII.6.d Internet discussion of adding nonionic surfactant Dow™ Tergitol™ to essentially nonionic surfactant ILFORD-ILFOTOL™ to boost cleaning makes no sense, unless the ILFORD-ILFOTOL™ is diluted too much, or if is being used primarily as a biocide.
- VIII.7 **KODAK™ PHOTO-FLO 200:** This is a wetting agent that is water mixed with a combination of 25-30% propylene glycol (i.e., anti-freeze) that acts as a solvent and as an antibacterial and antifungal agent and 5-10% nonionic surfactant. The nonionic surfactant by the CAS number 9036-19-5 is most likely Dow™ Triton™ X-114. This type of surfactant (octyl-phenol ethoxylates) is an environmental aquatic toxin and is being phased-out (see **CHAPTER IX. DISCUSSION OF THE FINAL CLEANERS:** for details). If the surfactant is Dow™ Triton™ X-114, the surface tension will be about 31 dynes/cm, the CMC will be 120 ppm, but the low 25°C/77°F cloud-point limits this product mostly to applications equivalent to room temperature.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- VIII.7.a The product literature indicates use at 1-part cleaner to 200 parts water that will yield a diluted nonionic surfactant concentration of about 0.05%, which for this nonionic surfactant is near the lowest usable concentration for its intended purpose as a single point of use, photographic wetting agent.
- VIII.7.b The propylene glycol component makes for a very stable shelf-life, and as an ingredient is very safe. For information propylene glycol is an antibacterial and antifungal agent at concentrations 25% and greater; but at less than 1% can accelerate bacteria growth. As a solvent, propylene glycol is sometimes used in cleaning agents as a stabilizer and thickener. Any use as an anti-foaming agent would be at concentrations much higher than intended for cleaning a vinyl record. I did mix equal proportions of 0.05% propylene glycol with 0.05% Dow™ Tergitol™ 15-S-9 and there was no appreciable anti-foaming action.
- VIII.8 **ISOPROPYL ALCOHOL (IPA):** IPA (also known as 2-propanol; CAS # 67-63-0) is often added to DIY record cleaning solutions. IPA is in every residential medicine cabinet. It is an effective solvent, it can be an effective wetting agent; it is an effective disinfectant, it is fully miscible with water producing an azeotrope (does not separate when evaporating), but IPA can be very hazardous.



Any alcohol mixture that is flammable or whose vapors can be explosive should not be used in or near an electrified record cleaning machine or ultrasonic tank that is not EXPLOSION PROOF; appropriately designed to meet National Fire Protection Agency (NFPA)-70 National Electric Code (NEC). The NFPA classifies products flammable if they have a flashpoint less than 100°F/38°C.



Do not use any alcohol with delicate lacquer or shellac records - damage will occur. Concentrated alcohols can cause stress cracking in some plastics such as Acrylic. Low concentrations <5% can be acceptable but first dilute with water.

- VIII.8.1 **Fire Hazards of IPA (and most other alcohols):** IPA and most IPA + water solutions are flammable and the vapors can be explosive. IPA at 70% and greater is very flammable with a flashpoint of 21°C/70°F or less, and it burns with a blue-flame that is not immediately noticed.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

VIII.8.1.a Flashpoint is the temperature that a fluid can ignite. At 2% concentration and higher, IPA + Water solutions are classified as combustible with a flashpoint of 65°C/149°F and less. At greater than 10%, IPA+Water solutions are classified as flammable with a flashpoint less than 100°F/38°C as indicated **Figure 31**(Astbury, G.R. & Bugand-Bugandet, J. & Grollet, E. & Stell, K.M. (2005), *Flash points of aqueous solutions of flammable solvents. Institution of Chemical Engineers Symposium Series. 505-522 (5)*).




Figure 31 -IPA + Water Flashpoint Temperature

VIII.8.1.b Explosion limits are based on the concentration at 25°C/77°F that can explode if an ignition source is applied. At 100% IPA, the lower and upper explosive limits are 2.3 to 13.2%. But, even diluted with water, at 25% IPA + water, the lower and upper explosive limits can be 2.3 to 7.1%. Data source - *Effects of upper explosion limit for isopropyl alcohol by steam, inerting at 1 atm and 150 °C by 20-L-apparatus*, Shang-Yi Shen • Jia-Chi Chen • Shang-Hao Liu, Ron-Hsin Chang, Horng-Jang Liaw, Chi-Min Shu *J Therm Anal Calorim (2013) 113:1619–1624 (62)*.

VIII.8.1.c For information, a cigarette is not a credible ignition source for alcohol, but an electrical arc/spark is, source: *Geiman, Justin & Fuss, P., (2013). Investigation of cigarettes as an ignition source for Coleman fuel. Fire and Materials 2013 - 13th International Conference and Exhibition, Conference Proceedings. 759-768 (15)*.

VIII.8.2 **Toxicity Hazards of IPA:** IPA is toxic if ingested or breathed at high concentrations for extended periods. IPA ingested can seriously harm or kill with a little as 250 mL (known as the single lethal dose). IPA vapors have an Occupational Safety and Health Administration (OSHA) allowable 8-hour exposure limit of 400 ppm, but the American

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Conference of Governmental Industrial Hygienists (ACGIH) sets exposure limits for IPA at 200 ppm. The reported odor threshold for IPA is 22 ppm.

VIII.8.3 The purpose of alcohol is mixed. By itself it is often used as a drying agent with a dilution of 5% to 25% able to significantly reduce its boiling point (vapor-pressure) as noted **Figure 32**.




Figure 32 – Water + IPA Boiling Point

VIII.8.4 However, for aqueous cleaners with IPA and surfactants, the article abstract “*The Vapor Pressures Of Ethanol-Water Solutions Of Detergents*” by B.D.Flockhart, 1960 (7) indicates that the affinity between detergent and alcohol is strong enough such that the solution boiling point is not lowered, but instead increased. This would imply that alcohol as an ingredient with detergents does not improve drying, so its use is for other purposes such as a co-solvent for other ingredients especially in concentrated forms.

VIII.8.5 **Figure 33** shows that IPA will reduce the water surface tension improving wetting similar to a nonionic surfactant with about 15% to 20% being the optimum concentration for a surface tension of about 34.6 to 30.5 dynes/cm respectively. Data for **Figure 33** is from “*Surface Tension of Alcohol + Water from 20 to 50°C*”, Gonzalo Vazquez, Estrella Alvarez, Jose M. Navaza, *Journal of Chemical and Engineering Data*. 1 May 1995 (23). Various forums discuss using just DIW and a few percent IPA and getting improved cleaning, especially for particulate. This result is valid because even 2.5% IPA in water can reduce the surface

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

tension to about 60 dynes/cm, reducing the water-IPA solution contact angle with the record improving the wetting and improving the cleaning especially for fine particulate.




Figure 33 –Water + IPA Surface Tension of at 25°C

(adapted with permission copyright 1995, American Chemical Society)

VIII.8.6 IPA at low concentrations 2.5% to 10% can assist cleaning by combining with low surface tension surfactants to improve the solubility at water-oil interfaces causing some organic soils to swell thereby allowing surfactants (in the cleaner) to lift the soil from the surface as noted **Figure 34**. This is used to good effect in **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES**: for applications requiring a non-flammable, low residue formula. A solution of 2.5% IPA has shown to be complementary with very low concentrations of non-ionic surfactant added only for wetting.



Figure 34 – Organic Soil Roll-Up

VIII.8.7 When diluting various concentrations of IPA such 100%, 91% or 70% to achieve a final lower percent the following equation can be used noting that this is % by volume.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

$$V_{IPA} = \frac{C_f}{C_i} V_f$$

Where: V_{IPA} = Volume of IPA to add (mL)
 C_f = Final Concentration of IPA (v/v%)
 C_i = Initial Concentration of IPA (v/v%)
 V_f = Final Volume of Fluid (mL)

Examples: To obtain a 2.5% IPA in 1400 mL of solution using 70% IPA =
 $(0.025/0.70) \times (1400 \text{ mL}) = 50 \text{ mL}$.

To obtain a 2.5% IPA in 1400 mL of solution using 91% IPA =
 $(0.025/0.91) \times (1400 \text{ mL}) = 39 \text{ mL}$.



VIII.8.8 **Denatured Alcohol.** Denatured alcohol that is purchased on-line or at a hardware store is generally ethanol (drinking alcohol) that has been denatured (made undrinkable) by generally adding methanol. However, methanol can be very toxic (absorbed through the skin) at higher concentrations. It's important to read the label and/or the MSDS. There are many grades of "denatured alcohol" and the methanol content can range from relatively safe 0.5% in reagent-grade to hazardous >25% in industrial grades. Methanol vapors have an OSHA allowable 8-hour exposure limit of 200 ppm.

VIII.9 **ANTI-STATICS.** Read any audio forum, and there will likely be some discussion of using anti-static cleaners and sprays. Fundamentally, static can be dissipated from any surface with a film of water; and the film of water does not need to be very thick. A thickness of only 20 angstroms (equal to 0.0020 microns) appears sufficient. So, if the applied fluid can uniformly wet the record, static can be dissipated. The proof of this can be extracted from the following papers:

VIII.9.1 *Static Charge Removal with IPA Solution, Tadahiro Ohmi, Seiji Sudoh, and Hiroyuki Mishima, IEEE Transactions on Semiconductor Manufacturing, Vol. 1, No. 4. November 1994.* This article tested the ability of IPA+water solutions to remove charge from Teflon™ (PTFE plastic). Teflon™ per **Figure 25** is one of the most negative materials on the Triboelectric series and has a very low critical surface tension of about 19 dynes/cm. The paper demonstrated the ability of 20% IPA + water and greater % IPA to dissipate the charge from Teflon™. Less than 20% IPA + water did not. The explanation is that 20% IPA + water from **Figure 33** has a surface tension of about 30 dynes/cm and this is able to wet the Teflon™ enough to dissipate the static charge. So, any solution that will 'wet' the record can remove static charge.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

VIII.9.2 *Why Three Monolayers of Moisture Are Important, Tom Green, T.J. Green Associates, LLC, Bob Lowry, Electronic Materials Consultant, September 2016 (65).* This paper shows that very thin films of water only angstroms thick that naturally condensed on a surface of mica from ambient humidity can change the mica (which is an insulator) conductivity as shown **Table VI**. For information, a single monolayer of water is 2.8 angstroms (0.00028 microns). From various ESD guidelines, and anecdotal information, a dewpoint of about 50°F to maybe 55°F appears to be the threshold where static is not generally formed on a record. At 40% humidity/77°F, the water film should be about 20 angstroms thick (0.0020 microns), and this should be sufficient to essentially make the surface conductive or at least dissipative. From **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:** a water film of 0.0020 microns thickness on the record would be equal to about 0.020 mg water uniformly spread-out on one side of the record. Also, to note, is that ambient air contains enough ionic impurities such as salts, so that condensed moisture will not be pure water and should be conductive.

Table VI
Mica Conductivity from Condensed Water Film

Relative Humidity @25°C/77°F	Dewpoint	Ambient air water g/m ³	Conductivity measured across mica	Water Film Thickness - microns
20%	33°F	4.8	<0.01 pico-amp	0.0010
30%	43°F	7.1	~0.02 pico-amp	0.0016
35%	47°F	8.2	~0.08 pico-amp	0.0018
40%	51°F	9.6	~0.3 pico-amp	0.0020
50%	57°F	11.9	~1.0 pico-amp	0.0025
60%	62°F	14.2	~5.0 pico-amp	0.0030
70%	66°F	16.3	~10 pico-amp	0.0032

VIII.9.3 Some anti-static chemicals are used to leave a thin coating that then prevents static from developing, and these chemicals are all low vapor pressure (will not easily evaporate) and are very hydroscopic (absorb water). So, the thin coating absorbs moisture from the air developing a water film on the record surface. The most efficient are quaternary ammonium compound (QAC) cationic surfactants; which are also disinfectants. Propylene glycol is also very hydroscopic as can be non-ionic surfactants, but both to a lesser degree. Most of these anti-static coatings have limitations when the ambient humidity drops below about 35%.

VIII.9.3.a One common DIY record formulation uses HEPASTAT™ 256 as the source of the QAC. There is one industrial anti-static fluid not used in any DIY record cleaners - ACL Staticide® that uses Methyl bis(2-hydroxyethyl) cocoalkyl quaternary ammonium nitrates/chlorides for the QAC at about 0.1% (1000 ppm) and specifies useable to 15% humidity.

VIII.9.3.b In the paper *Investigating the impact of cleaning treatments on polystyrene using SEM, AFM and ToF-SIMS*, Anna L. Fricker, David S. McPhail, Brenda Keneghan and Boris Pretzel,

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Heritage Sci (2017) 5:28 (3), nonionic surfactant BASF™ Dehypon™ LS45 and anionic surfactant Orvus™ WA Paste were used at 1% (10,000 ppm) to clean polystyrene. The polystyrene was cleaned using microfiber cloths and rinsed with demineralized water wetted cloths to remove residual surfactant. Post rinsing inspection with time-of-flight secondary ion mass spectrometry (ToF-SIMS) showed evidence of surfactant residue measured as one-monolayer which is about 9 angstroms (0.0009 microns). Realistically, this layer will exist/mix with the water layer that naturally deposits from the air. But if that surfactant was a cationic surfactant, then the high fluid film conductivity could act as a strong anti-static; any negative effects to music playback notwithstanding.

VIII.9.3.c In the paper *Record Contamination: Causes and Cure by Percy Wilson, 1965 (52)* it states: “One thing, however, became abundantly clear during the early part of the investigation: the treatment of the record surface with any material whatsoever that leaves a deposit increases the liability to noisiness within a few months. Detergents in particular (whether anionic or cationic) will produce a battery of pitted sections of the groove in about 12 months' time. We surmised, though we have not investigated this thoroughly, that the action was not so much on the vinyl chloride as on the lead stearate or other additives that go to make up the modern disc material.” Note: This conclusion may not apply to modern records that no longer use lead-based ingredients; see **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:**. However, cleaner residue can still be audible as discussed **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:**

VIII.10 **BIOCIDES:** Chemicals are used to kill and/or control microbial growth such as bacterial, spores and viruses; and they can be categorized as those that can sterilize (kill everything), disinfect (kill most) or inhibit (prevent growth). Cationic surfactants that are positively charged and used as anti-static can also be very effective disinfectants and the specific type as previously discussed is quaternary ammonium compounds (QACs). However, QACs are not completely sporicidal (kill mold spores), but simple hydrogen peroxide is sporicidal. The CMIT/MIT chemicals in ILFORD™ ILFOTOL™ are inhibitors.



HEPASTAT 256 in its concentrated state it is classified as being flammable, an acute toxicity oral and dermal hazard, and can cause burns to exposed skin. Once diluted, it is much safer, but as a concentrate this is an industrial product and should be handled accordingly with appropriate PPE.

VIII.10.1 **HEPASTAT™ 256:** HEPASTAT™ 256 is a concentrated antibacterial (disinfectant), anti-static, general purpose alkaline cleaner and is intended to be diluted with tap water 1/2 to 1-ounce per gallon (diluted 1-part cleaner to 125 to 250 parts water). This product is very effective as a disinfectant able to kill just about any bacteria or virus (*including COVID-19*) with appropriate contact time as specified by the manufacture. This product

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

is used by some of the DIY cleaners, generally as an anti-static and sometimes recommended to extend ultrasonic tank bath life by inhibiting bacteria. The active ingredients are quaternary ammonium salt compounds. But, it's also a broad-based alkaline cleaner with many ingredients beyond the blend of cationic quaternary ammonium compound (QAC) surfactants including ethoxylated nonionic surfactant, ethanol, sodium metasilicate (for pH), sodium EDTA (to allow use with tap water), and fragrance.

- VIII.10.1.a Note that a 9/2015 bulletin from *New York Mount Sinai Silekoff Centers for Occupation Health* titled "*Quaternary Ammonium Compounds in Cleaning Products: Health & Safety Information for Health Professionals*" (51) raises sufficient respiratory health concerns that use of this product or any quaternary ammonium compounds (QACs) for cleaning records should be approached with Caution with those that may have asthma or other respiratory ailments.
- VIII.10.1.b Additionally, for information most quaternary ammonium compounds are classified as highly toxic to aquatic life according to the United Nations' Globally Harmonized System of Classification and Labelling of Chemicals (GHS).
- VIII.10.2 **BAK50:** BAK50 is 50% concentrated benzalkonium chloride CAS No. 8001-54-5. It's a cationic surfactant blend of alkylbenzyltrimethylammonium chlorides that are classified as QACs and are powerful disinfectants. It is similar to HEPASTAT™ 256 without the other nonionic surfactant and alkaline ingredients. BAK50 is readily available in small quantities and low cost in the EU/UK, but not in the USA. Laboratory grade is available in the USA at much higher cost. BAK50 is generally applied at 1-part BAK50 to 200 parts distilled/demineralized water, similar to HEPASTAT™ 256. As a concentrated product, the safety profile/hazards of BAK50 as a concentrate are the same as HEPASTAT™ 256.
- VIII.10.3 **MOLD:** There are essentially two different categories - there is mildew which is the dust type and has a musty smell and is relatively easy to remove from a record using most wet cleaning processes. Then there is the fuzzy/slimy mold, generally has a more pungent odor and this is something else and can be dangerous. The EPA has guidelines for mold remediation - [Mold Cleanup in Your Home | Mold | US EPA](#). If the record has fuzzy/slimy mold, the general recommendation is to avoid and do not try to recover unless of extraordinary value. For mildew-type mold, a full wet process such as **CHAPTER V. MANUAL CLEANING PROCESS:** is the safest since the mold should not become airborne - lots of water and lots of cleaner can be applied to 'remove' the mold. The same technique is used to 'remove' bacteria and viruses from your hands, and in the age of COVID we all know the drill - clean with soap and water for 20-seconds. If you dry brush the mold, it will become airborne and now becomes a respiratory hazard.
- VIII.10.3.a If there is concern that after washing there may still be live mold spores in the record, then a solution with sporicidal action is required. Using the *Centers for Disease Control*

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

(CDC) Guideline for Disinfection and Sterilization in Healthcare Facilities, 2008 Update: May 2019 (10) as a guide, some observations. Common disinfectants such as alcohol and QACs (sometimes referred to as Quats) such as HEPASTAT™ 256 and BAK50 do not have very good sporicidal activity. They may inhibit growth, but not necessarily kill the spores.

- VIII.10.3.b The safest sporicidal solution that should be compatible with records to kill mold spores is simple hydrogen peroxide. The one disadvantage is kill-time; 3% = 2.5-hrs while 6% = 1-hr. Sodium hypochlorite (bleach) does have very good sporicidal activity with much faster kill-time than hydrogen peroxide and should also be compatible with the record. However, specific record compositions may react differently; and the exact concentration to use is dependent on the starting concentration and household bleaches may contain other ingredients. If using hydrogen peroxide to kill mold, after soaking, lightly brush to agitate fluid and then dispose to drain. Apply tap-water rinse with brush assistance to remove all hydrogen peroxide noting that the hydrogen peroxide will mix with water almost instantly. Then continue to either general pre-clean or final clean.
- VIII.10.3.c Mildew/moldy record jackets are generally disposed and replaced with blank jackets such as [White Die-Cut LP Jacket \(Pack of 10\) \(sleevecityusa.com\)](http://sleevecityusa.com). If not severe, the www-web has a number of methods that can be tried. However, take appropriate precautions to avoid exposing yourself to airborne mold; such as perform outside and wear appropriate personnel protective equipment (PPE).
- VIII.11 **DISCWASHER™** 1976 U.S. Patent 3,951,84 *Phonograph Record Cleaning Composition (13)* (product availability is unknown). The Discwasher™ product along with the brush was/is a commonly used item for single point of use cleaning. The process applies liquid to the brush leading edge; wipes the record surface and then used the back-edge of the brush to dry. The patented solution composition is reviewed for historical purposes; the composition of the what is currently sold is unknown.
- VIII.11.1 Discwasher™ Formula: The formula is heavily centered around preventing the formation of micro-organisms (mold) in the record groove. Note: The common presence of micro-organisms in the record groove has not been validated. The record formulation is not biodegradable.
- VIII.11.1.a Sodium Azide - up to 0.3%-wt. Sodium Azide was added as the biocide.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Concentrated Sodium Azide is extremely hazardous and toxic and its use in any current record cleaning hopefully has been suspended. It is used in automobile air bags – it's the explosive, nitrogen gas producing ingredient.

- VIII.11.1.b Surfactant – up to 0.2%-wt. The surfactant was likely similar to if not Dow™ Triton™ X100 and is added as a wetting agent.
- VIII.11.1.c Propylene Glycol – up to 0.2%-wt. Propylene Glycol was added as an emulsifier.
- VIII.11.1.d Alcohol – up to 5%-wt. Alcohol was likely IPA and was added to assist with dissolving the surfactant into the water.
- VIII.11.1.e Distilled Water – remaining percent.
- VIII.11.2 Discwasher™ Assessment:
- VIII.11.2.a The patent states: *“And more importantly, even after this process is achieved, any remaining cleaning composition in the form of a residue that remains upon the surface of the phonographic record acts as a lubricant, and even when it should dry, it leaves little or no noticeable or actionable dry weight residue that may cause irritation to the record playing surface during its movement and contact with the phonographic needle.”*
- VIII.11.2.b One of the challenges with this cleaning solution is that it is essentially a wipe-cleaner. There is essentially no contact time. There is no time to dissolve/emulsify organic contaminants requiring brush pressure to do the work. But this can also force particulate deeper into the groove.
- VIII.11.2.c Review of the composition indicates that the solution NVR can have as much as 7000 mg/L from the Sodium Azide (~3000 mg/L) + Surfactant (~2000 mg/L) + Propylene Glycol (2000 mg/L) = 7000 mg/L. If 0.5 mL dries on the record surface, 3.5 mg of NVR will remain. The residue will be oily and will collect dust and particulate that forms from record play and is in the surrounding environment. Use of the brush/liquid for every record play will eventually leave a build-up of what will essentially be sludge, and historical experience indicates this is what happened.
- VIII.11.2.d The patent does state that the “..., the preferred formulation has been calculated to contain as little as 0.0004 grams per c.c. (same as 0.4 mg/mL) of dry components in a fluid treatment...”. This is true only if the solution was manufactured at the lowest possible concentration.
- VIII.12. **DESCALING:** Occasionally when resurrecting a Goodwill™ or flea market record find, there may be evidence of scale – such as hard water mineral spots. These mineral deposits will fluoresce under UV light. If normal pre-cleaning as specified **CHAPTER V. MANUAL**

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CLEANING PROCESS: does not remove the scale, distilled white vinegar can be very effective and safe. Distilled white vinegar is water and acetic acid (made from distilled grain alcohol), and the percent acetic acid should be identified as “% Acidity”. Note that distilled white vinegar is generally 5-10%, but can be as high as 30%. Distilled white vinegar at 30% should be compatible as indicated **Table IX**; but 5% is effective.

- VIII.12.1 The vinegar will need to soak the affected area for about 15-30 minutes. The vinegar by itself will not “wet” the record and unless immersed in a bath of vinegar will bead-up on the record. Adding 1-2 drops of Dow™ Tergitol™ 15-S-9 (or equivalent, see **CHAPTER IX. DISCUSSION OF THE FINAL CLEANERS:**) to about 50 mL of vinegar will allow the solution to “wet” the record.
- VIII.12.2 After soaking, water rinse with brush assistance to dilute/remove the vinegar and the softened scale. Then follow with a general pre-clean or final clean step to ensure removal of all scale & particulate. Note that there are many types of vinegars such as apple cider – use only “white distilled vinegar” which is the purest (little or no residue) form.
- VIII.13. **DIY RECORD CLEANING FORMULAS.** There are two widely used DIY record cleaning formulas with some variations thereof. One is based mostly on IPA and some nonionic surfactant; while the other is based mostly on cationic and nonionic surfactants with a small amount of IPA.
- VIII.13.1 **London Jazz Collector™ (LJC)** (<https://londonjazzcollector.wordpress.com/for-audiophiles/home-brew-cleaner-for-vacuum-rcms/>)
- VIII.13.1.a LJC Limitations: The formulator indicates that the cleaning solution is intended for vacuum record cleaning machines such as **CHAPTER XIII. DISCUSSION OF VACUUM RECORD CLEANING MACHINES:**, and does not recommend allowing to just evaporate to prevent leaving dissolved contaminants, e.g., NVR.
- VIII.13.1.b LJC Formula:
- IPA - 99.9% 1:4 with DIW (250 mL/L) = 25% IPA
 - ILFORD™ ILFOTOL™ (5% concentrate) 1:200 DIW (5 mL/1 L) = 0.5% (0.025% NID) = 250 ppm active nonionic surfactant
 - Overall Delivery is specified as 2.5 mL of LJC Formula to each record side.
- VIII.13.1.c LJC Assessment: The ILFOTOL™ concentration is about 8X the nonionic surfactant CMC so it has some detergency and should have a surface tension of about 30 dynes/cm so it should wet the record. The 25% IPA also has a low surface tension of ~28 dynes/cm. The high IPA concentration should reduce the fluid boiling point and assist with quicker evaporation. Additionally, the IPA at 25% is useful in assisting the ILFOTOL™ nonionic

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

surfactant for soil swell/roll-up. Overall, given the small applied quantity (2.5 mL) the risk of cleaner NVR from incomplete rinsing is very low; at 2.5 mL the solution will have <1 mg NVR. Additionally, per **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:** the small volume used at room temperature has no compatibility issues. But the solution is flammable with a flashpoint of ~27°C (81°F). However, the flammability risk is mitigated by the very small quantity used – only 2.5 mL per side, but larger quantities could pose a fire hazard.



Use of the **London Jazz Collector™** formula in an Ultrasonic Tank with 100's or 1000's of mL is dangerous. With an ultrasonic unit three mechanisms are now in play - the heat that speeds up evaporation; the record turning is drawing fluid out that is evaporating and the ultrasonics are agitating the fluid surface and a mist/vapor is often produced. All of this has the potential to setup the necessary conditions to develop flammable AND explosive vapors. At 100% IPA, the lower and upper explosive limits are 2.3 to 13.2%. But, even diluted with water, at 25% water-IPA, the lower and upper explosive limits are 2.3 to 7.1%. In a common domestic setting, it is very unlikely that the high ventilation turn-over rates that are required in medical and industrial settings that prevent the accumulation of flammable/explosive vapors will be used. So, the risk in a domestic setting is higher.

VIII.13.2 **Audiokarma™** (<https://audiokarma.org/forums/index.php?threads/record-cleaning-developing-the-best-possible-methods.689430/page-51#post>)

VIII.13.2.a Audiokarma™ Limitation: The formulator indicates that the cleaning solution is intended as a wash step using a brush “paint pad” as the applicator and then to be rinsed with DIW. The formulator indicates that the wash-step is followed with a final DIW rinse and dry with a vacuum-RCM. Furthermore, the formulator indicates success with using the cleaning solution in ultrasonic tanks at a 1:1000 dilution.

VIII.13.2.b Audiokarma™ Formula:

- HEPASTAT™-256 (~20% quats + 8% NID + 10% Na₂SiO₃/EDTA) @ 1:500 (2-mL/L) = 0.2% (yields 0.04% Quats + 0.016% NID + 0.02% Na₂SiO₃/EDTA) = 400 ppm Quats + 160 ppm NID + 200 ppm Na₂SiO₃/EDTA
- Dow™ Triton™ X100 (100% concentrated) - (2.0 mL/L) = 0.2% = 2000 ppm
- IPA 99.9% - (50 mL/L) = 5%

VIII.13.2.c Audioikarma™ Assessment:

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- The formulator addresses using the HEPASTAT™-256 for its negative-charge cationic surfactant anti-static capability. However, so long as the record is fully wetted, and the Dow™ Triton™ X100 concentration at 0.2% is about 10 times its CMC will ‘wet’ the record, any static on the record will be dissipated/eliminated. The double rinse that is specified will likely leave very little cationic surfactant (quats) residue behind to leave any long-term anti-static coating.
- Dow™ Triton™ X100 at 0.2% is about 10X its CMC and will be a good wetting solution with good detergency. But, Triton™ X100 at 0.2% will be difficult to dissolve without the 5% IPA, and the high concentration will require careful (aggressive) DIW rinsing for complete removal. Otherwise, Dow™ Triton™ X100 is a nonionic surfactant that has been in use for >25-yrs – see **CHAPTER IX. DISCUSSION OF THE FINAL CLEANERS:** for further details.
- The IPA at 5% is useful in assisting the Dow™ Triton™ X100 nonionic surfactant to dissolve in the solution and for soil swell/roll-up. Precedence with using 5% IPA to assist with mixing the Triton™ X100 in water is discussed in the *Discwasher™ 1976 U.S. patent 3,951,84 (13)*. The IPA at 5% will have a flashpoint of 50°C/122°F. For vacuum-RCM this is very low risk. However, for ultrasonic tanks where some users are reporting temperatures as high as 45°C/113°F, the margin of safety is only 10%. Additionally, at 5% when used in an ultrasonic tank there will be some loss of cavitation intensity see **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES:** for further details.
- Overall, the cleaning solution NVR is 2,760 ppm, so post rinse as specified is very important. If not rinsed, some of the NVR will dry to a powder/hard residue. The sodium metasilicate (Na₂SiO₃) if it dried on the record could form a very hard and tenacious residue similar to tap-water scale.

VIII.13.3. VinylEngine™

(http://www.vinylengine.com/turntable_forum/viewtopic.php?f=53&t=96199&sid=3b488611de75c83db5f3364e57422bf9#p814914). Note that the “Rushton Paul” DIY ultrasonic cleaning formula addressed [Ultrasonic Cleaning \(positive-feedback.com\)](http://www.ultimate-records.com/forums/showthread.php?p=1000000) is very similar.

VIII.13.3.a VinylEngine™ Limitations – The formulator indicates that the cleaning solution is “useful” for ultrasonic tanks and vacuum-RCMs since it inhibits bacteria/fungus growth. The formulator further indicates the cleaning solution concentration can be increased for manual cleaning, but regardless, cleaning is always followed by two rinses with DIW.

VIII.13.3.b VinylEngine™ Formula: Very similar to **paragraph VIII.13.2 "Audiokarma"** and developed by the same author. The concentration range for HEPASTAT 256 and Triton X100 is expanded as follows:

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- HEPASTAT™-256 (~20% Quats + 8% NID + 10% Na₂SiO₃/EDTA) @1:1000 to 1:500 (1-2 mL/1 L) = 0.1 to 0.2% (yields 0.04% to 0.02% Quats + 0.008% to 0.016% NID + 0.01% to 0.02% Na₂SiO₃/EDTA) = 200 to 400 ppm Quats + 80 to 160 ppm NID + 100 to 200 ppm Na₂SiO₃/EDTA
- Dow™ Triton™ X100 (100% concentrated) (1-5 mL/L) = 0.1 to 0.5% = 1000 to 5000 ppm
- IPA 99.9% (50 mL/L) = 5%

VIII.13.3.c VinylEngine™ Assessment:

- Same as **paragraph VIII.13.2 "Audiokarma"** for the applicable range.
- For the HEPASTAT™-256 used at 1:1000 in ultrasonic tanks, the cationic surfactant (quats) concentration is reduced to 200 ppm. The literature indicates that as the concentration of Quats is reduced the "kill" time for bacteria and viruses is increased. But, the 200 ppm should be adequate as a biocide inhibitor for the ultrasonic tank water volume. However, similar biocide capability should be achieved with the ILFORD™ ILFOTOL™ with much less NVR and simpler chemistry that is compatible with the Dow™ Triton™ X100 or other nonionic surfactants.
- Dow™ Triton™ X100 at 0.1% is about 5 times its CMC and will be a good wetting solution with minimal detergency. But, Triton™ X100 at 0.5% is excessive at >25 times the CMC and will be difficult to dissolve without the 5% IPA, could be subject to excessive foam and the high concentration will require careful (aggressive) rinsing for complete removal such as the specified two rinses with DIW.
- The formula at its lowest concentration has an NVR of 1,380 ppm (mg/L) while the highest concentration has an NVR of 5,760 ppm (mg/L), so rinsing as the formulator specifies is necessary to ensure excessive residue is not left behind.

REMAINDER OF PAGE INTENTIONALLY BLACK

CHAPTER IX. DISCUSSION OF THE FINAL CLEANERS:

My recommendation is that a simple, single component nonionic surfactant at low concentration is considered the best chemistry for the manual cleaning, final clean step. The final clean step should be performed with a cleaner that has the following properties:

- ✓ Low surface tension to effectively perform the final clean step of removing thin soil films not removed by the pre-clean step or deposited by the pre-clean step, or remaining from prior chemistry, and removing small particulate; and
- ✓ Compatible with the pre-cleaning chemistry and any prior-chemistry (such as an anti-static spray) to be effective in removing any residue left by the pre-cleaner or prior chemistry without any adverse reaction; and
- ✓ Low enough concentration to be easily and effectively rinsed, and
- ✓ Nonionic so that any residue that may be left behind will not react with any other contaminants, and
- ✓ Safe – be non-flammable and be non-toxic in use, and be materially compatible (with limited exposure) with the vinyl record (see **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:** for further discussion of material compatibility).

IX.1 Dow™ Tergitol™ 15-S-9 nonionic surfactant meets all desired final cleaner criterion and is readily available at reasonable cost from Talas™ (<https://www.talasonline.com>). Laboratory grade with a certificate of analysis (COA) is also available at much higher cost. As a nonionic surfactant it will be compatible with residue left from a prior chemistry of either anionic or cationic surfactants. The product in its diluted form is neutral pH, safe and its very high performance to concentration ratio results in a very low concentration minimizing material compatibility issues with the vinyl record and risk of NVR from incomplete rinse. The Dow™ Tergitol™ 15-S-9 product is delivered concentrated at about 100% active ingredients. **Table VII** lists the performance properties of two Dow™ Tergitol™ nonionic surfactants, showing near equivalency of Dow™ Tergitol™ 15-S-9 to Dow™ Tergitol™ 15-S-7, and how they compare to the often-used for record cleaning Dow™ Triton™ X-100 nonionic surfactant. **Table VII** data (unless referenced otherwise) was obtained from Dow™ literature available on the web.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Table VII
Nonionic Surfactant Performance Properties

Property	Tergitol™ 15-S-7	Tergitol™ 15-S-9	Triton™ X-100
Chemistry (see Note 1)	Secondary Alcohol Ethoxylates	Secondary Alcohol Ethoxylates	Octylphenol Ethoxylates
CAS Number	84133-50-6	84133-50-6	9002-93-1
Cloud Point (°C/°F) – see Note 2	37 (99)	60 (140)	66 (151)
Hydrophilic-Lipophilic Balance (HLB) – (see Note 3)	12.1	13.3	13.5
Critical Micelle Concentration (CMC) ppm at 25°C/Surface Tension dynes/cm (see Note 4)	38/28	52/30	189/33
Surfactant Micelle Size nm/microns (see Note 5)	15/0.015	9/0.009	4.4/0.0044
Specific Density at 25°C	0.910	1.060	1.065
Environmental Hazard (diluted)	No	No	Yes

Notes	Table VII Nonionic Surfactant Performance Properties
1	The DOW™ material safety data sheets will show a small amount (<3 wt%) of “poly (ethylene oxide)” as an ingredient with a CAS No. 25322-68-3. This CAS No. translates to polyethylene glycol that is compatible with PVC, and MSDS’s from some chemical suppliers such as Sigma-Aldrich™ will list the ingredient as polyethylene glycol. Additionally, all ethoxylated nonionic surfactants have ethylene oxide molecules as part of the chemical structure often referred to as levels or moles of ethoxylation. For the Dow™ Tergitol™ 15-S family, the last digit is the levels/moles of ethoxylation, so Dow™ Tergitol™ 15-S-7 has 7 moles while Dow™ Tergitol™ 15-S-9 has 9 moles. However, ethylene oxide by itself is a gas that is not compatible with PVC, and some internet forums have incorrectly stated that Dow™ Tergitol™ is not compatible with PVC. See CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY: for additional discussion of material compatibility.
2	Cloud point is the temperature when the mixture starts to phase-separate, and two phases appear, thus becoming cloudy. The cloud point is the optimum temperature for detergency, but above the cloud point the surfactant comes out of solution and detergency drops. Cloud point is generally specified at 1% and will generally increase at lower concentrations as much as 75% (<i>Surfactant Parameter Effects on Cleaning Efficiency (32)</i>).
3	The hydrophilic-lipophilic balance of a surfactant is a measure of the degree to which it is hydrophilic (water loving) or lipophilic (oil loving), and is predictive of the surfactant properties. <ul style="list-style-type: none"> a. < 10: Lipid-soluble (water-insoluble) b. 10: Water-soluble (lipid/oil-insoluble) c. 1 to 3: Anti-foaming agent d. 3 to 6: Water in oil emulsifier e. 7 to 9: Wetting and spreading agent f. 13 to 16: Detergent g. 8 to 16: Oil in water emulsifier

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Notes	Table VII Nonionic Surfactant Performance Properties
4	The critical micelle concentration (CMC) is the concentration when the surfactant achieves its lowest surface tension and at greater than CMC micelles are formed. Adding additional surfactant will not lower the surface tension any further. But, for detergency, the concentration should be at least 5 to 10 times greater than the CMC to form an adequate number of micelles. However, excessive concentration will only impede solution preparation and rinsing. For reference, the surface tension of water is ~72 dynes/cm.
5	<i>Source: Impact of Surface Active Ionic Liquids on the Cloud Points of Nonionic Surfactants and the Formation of Aqueous Micellar Two Phase Systems 2017, and Temperature Dependence of Triton X-100 Micelle Size and Hydration 1994 (33)</i>

- IX.2 Reviewing **Table VII**, Dow™ Tergitol™ 15-S-9 is very similar to the Dow™ Tergitol™ 15-S-7 used by the *Library of Congress* to clean shellac records. The main difference in cloud point is inconsequential for the manual cleaning process addressed herein. However, the low cloud point of Dow™ Tergitol™ 15-S-7 could make it unsuitable for use with ultrasonic cleaning tanks because of the elevated temperatures. The higher HLB value for Dow™ Tergitol™ 15-S-9 predicts better detergency than Dow™ Tergitol™ 15-S-7. The slight difference in CMC/Surface Tension between Dow™ Tergitol™ 15-S-9 and Dow™ Tergitol™ 15-S-7 is insignificant to the performance or amount of surfactant used to prepare the NID cleaning solution.
- IX.3 Dow™ Tergitol™ 15-S-9 with a CMC of 52 ppm (equal to 0.0052 wt%) at 10-times the CMC for minimum optimum concentration would be 0.052 wt% (520 ppm) - same as 520 mg/L for a water solution. With Dow™ Tergitol™ 15-S-9 specific density equal to 1.06 (and very close to water at 1.0), the approximation that 1 ppm = 1 mg/L = 0.001 mL/L is used for solution preparation purposes. Dow™ Tergitol™ 15-S-9 at a 0.1% (1000 ppm) solution specified herein is ~20 times the CMC; if used at 0.25% (2000 ppm) it would be ~50 times the CMC.
- IX.4 Reviewing **Table VII**, and Dow™ literature, Tergitol™ 15-S-9 is intended as a safer and more efficient replacement to Dow™ Triton™ X-100.
- IX.4.a The cloud point and HLB are very similar, but Dow™ Tergitol™ 15-S-9 has 10% lower surface tension, and this is achieved at a CMC of 52 ppm versus 189 ppm for Dow™ Triton™ X-100. This means that two-thirds less Dow™ Tergitol™ 15-S-9 can be used to achieve the same performance of Dow™ Triton™ X-100. So, while Dow™ Triton™ X-100 is often used at 0.5% (~5000 ppm) solution, Dow™ Tergitol™ can be used at 0.1% (~1000 ppm) to 0.05% (~500 ppm).
- IX.4.b Additionally, Dow™ Tergitol™ 15-S-9 is reported to have a faster dissolution rate (time to dissolve), which combined with the reduced concentration makes the NID cleaning solution preparation easier and faster. Some users of Dow™ Triton™ X-100 report that they mix Dow™ Triton™ X-100 with IPA to improve dissolution which given that users are sometimes using a 1.0% (~10,000 ppm) solution should not be unexpected.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- IX.4.c However, Dow™ Triton™ X-100 is categorized as a nonylphenol ethoxylate (NPE) and NPE chemical compounds have aquatic toxicity and are being phased-out (ref: *EPA, Nonylphenol (NP) and Nonylphenol Ethoxylates (NPEs), 8/18/2010, Action Plan, RIN 2070-ZA09 (16)*).
- IX.5 **ILFORD-ILFOTOL™**: Referencing the discussion in **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS**;, substituting ILFORD-ILFOTOL™ as the final cleaner mixed 10 to 20 mL to one-liter should yield about a 0.05 to 0.1% nonionic detergent solution that is near equal of 0.05 to 0.1% Dow™ Tergitol™ 15-S-9. Neither Dow™ Tergitol™ 15-S-7 nor Tergitol™ 15-S-9 as a concentrate are sold in the EU/UK.
- IX.6 **BASF™ DEHYPON® LS 54**. This is a high performance, low foaming non-ionic surfactant manufactured by BASF™ that those in the UK can purchase [Dehypon – Conservation Resources \(UK\) Ltd \(conservation-resources.co.uk\)](http://www.conservation-resources.co.uk). This surfactant is a fatty alcohol C12 - C14 with approximately 5 moles ethylene oxide and 5 moles of propylene oxide (CAS # 68439-51-0). This product is used for cleaning textiles by conservationist as detailed in the paper “*Detergency evaluation of non-ionic surfactant BASF™ DEHYPON® LS54 for textile conservation wet cleaning, Moe Sato & Anita Quye, Journal of the Institute of Conservation, 29 Jan 2019*” (44). The product has been successfully used in ultrasonic cleaning machines such as the Degritter™ that require a low foaming cleaning agent (see **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES**:). The product details are as follows:
- IX.6.a The BASF™ reported CMC is 10 mg/L which would be 10 ppm or 0.001%. Given this very low CMC, for manual cleaning 0.01-0.02% would be recommended. For ultrasonic tanks with pumps that may cause foam, 0.0025 – 0.005% has shown effective – see **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES**:.
- IX.6.b Density is 0.933 - 0.938.
- IX.6.c Product is a concentrated liquid at room temperature.
- IX.6.d Cloud point is 30°C/86°F at 1%. As noted in **Table VII**, cloud point will increase at much lower concentrations.
- IX.6.e pH is neutral 6.5 - 7.5.
- IX.6.f Product is an aquatic environmental toxin.
- IX.7 **TERGIKLEEN™**: Commercial sold product with MSDS.
- IX.7.a A blend of two nonionic surfactants – Dow™ Tergitol™ 15-S-3 (not water soluble) and Tergitol™ 15-S-9 (water soluble). Tergitol™ 15-S-3 is a hydrocarbon emulsifier and in water can act as a defoaming agent. Not being soluble, Tergitol™ 15-S-3 has no CMC and does not act as wetting agent. Tergikleen™ which does not foam has found some acceptance

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

in the UK for use in ultrasonic tanks. The recommended use of 15-20 drops per gallon works out to about 1 mL and with 1-US gallon = 3786 mL the final overall concentration could be $1 \text{ mL}/3786 \text{ mL} = 0.00026 = 0.026\% =$ to about 260 ppm.

- IX.7.b Assuming a 50:50 mix, at 130 ppm concentration, the Dow™ Tergitol™ 15-S-9 critical micelle concentration should be achieved lowering the surface tension of the water to about 30 dyne/cm but very little detergent micelle reserve is provided. Some of the Tergitol™ 15-S-9 will be used to keep the Tergitol™ 15-S-3 in solution. If too much Tergikleen™ is added (quantity unknown) the Tergitol™ 15-S-3 which exists as an emulsion will likely come out of solution.
- IX.7.c If using Tergikleen™ as a single application with no water rinse used at 15-20 drops per gallon should not leave a significant residue behind by itself. At an equivalent of about 260 ppm = 260 mg/L, and if 1 to 2 mL of solution dries on the surface = 0.26 to 0.52 mg can be left behind; and what is left behind will essentially be an oil. However, what is left behind will also contain diluted contaminants from the record and therefore the final residue likely to be higher. There are reports by experienced listeners that the residue left behind is audible and is reported as a 'veil' over the high frequency music content. For further discussion see **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:** and **paragraph XIV.7.**
- IX.7.d Tergikleen™ is the same record cleaning composition specified in *The Care and Handling of Recorded Sound Materials, By Gilles St-Laurent Music Division National Library of Canada January 1996(20)*. "*The Canadian Conservation Institute (CCI) recommends the use of nonionic, ethylene oxide condensates surfactants to clean sound recordings. The CCI does not foresee long-term problems associated with the use of nonionic surfactants such as Tergitol. Tergitol 15-S-3 is an oil soluble surfactant and 15-S-9 is a water-soluble surfactant. Combined they remove a wide range of dirt and greases and can safely be used on sound recordings. Use 0.25 part of Tergitol 15-S-3 and 0.25 parts of Tergitol 15-S-9 per 100 parts of distilled water. The recording must then be rinsed thoroughly with distilled water to eliminate any trace of detergent residue.*". However, the CCI application concentration is very high; 0.25 parts of Tergitol 15-S-3 and 0.25 parts of Tergitol 15-S-9 per 100 parts of distilled water is the same as $0.25 \text{ mL}/100 \text{ mL} = 0.25\% = 2500 \text{ ppm}$ of each. Tergitol™ 15-S-9 at 2500 ppm is 50 times the CMC. It is unknown whether the *Library of Canada* is still using this formula. However, if in use, it would be in a manual cleaning process similar to that used by the *US Library of Congress* (34) that uses a lot of DIW for final rinse.

CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY:

The first priority of cleaning is to do no harm. To address this as it relates to the vinyl record requires a brief discussion of vinyl record composition and then a discussion of chemical compatibility testing.

X.1 **Record Composition:** There are a number of web site and forum discussions of vinyl record composition such as

- <https://audiokarma.org/forums/index.php?threads/record-cleaning-a-comprehensive-resource.884598/#post-13072519>
- https://www.vinylengine.com/turtable_forum/viewtopic.php?t=99579

These are consistent with what is (noting that actual formulations are highly protected) addressed by *RCA Engineer Magazine, 1976, Issue 02-03, Development of Compound for Quadradiscs, by G.A. Bogantz S.K. Khanna (61)*. The quadradisc composition was developed to provide low wear with the wide bandwidth record using the Shibata™ stylus profile as addressed **CHAPTER I. VINYL RECORD CLEANING CHALLENGES:**. The following summarizes *RCA Patent 3,960,790, June 1, 1976, DISC RECORD AND METHOD OF COMPOUNDING DISC RECORD COMPOSITION (55)*. Of interest, the RCA composition “...results in a surface that wears in a smooth manner and not in a porous granular manner as heretofore experienced.”. Also, it should be noted that RCA did state “It is a somewhat softer formulation than we had initially expected but with well-defined and controllable elastomeric properties.”.

X.1.1 **Resin:** A 60-70% of a copolymer of vinyl chloride-vinyl acetate resin suspension or solution containing 12-16% by weight of polyvinyl acetate + 26.2-36.2% of a suspension or solution type homo polymer of vinyl chloride. These two resin ingredients should total 96.2%. Note: “The acetate makes the resin softer and, therefore, acts as an internal plasticizer.” (source: *RCA Engineer Magazine, 1976 Issue 10-11, Polymer Science - New Materials for Phonograph Discs, by S.K. Khanna (60)*).

X.1.2 **Heat Stabilizer:** 1.6% of a sulfur-free organotin salt containing about 16% tin. All PVC compounds when exposed to heat release hydrogen chloride gas. This gas triggers a further autocatalytic degradation process, causing rapid discoloration and embrittlement of the PVC. Heat stabilizers increase the heat stability by various mechanisms, such as scavenging of released hydrogen chloride gas molecules. The type of heat stabilizer used depends on the application and required heat stability. Lead compounds were among the first stabilizers used by the PVC industry but due to health concerns, the record industry phased out lead compounds moving to mostly tin based compounds.

X.1.3 **Anti-static Agent** ~1.2%. RCA successfully developed an anti-static record process that was based on a quaternary ammonium salt (specifically, stearamidopropyldimethyl-2-hydroxyethylammonium nitrate) that coated the resin powder so it was uniformly distributed throughout the record. The details are documented in *RCA Engineer Magazine, 1976 Issue 10-11, Anti-static Phonograph Records by G. P. Humfeld (22)*. RCA as part of the

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

testing determined that carbon black could make the record 'conductive' to impart anti-static properties. But the quantities required then (~13%) had too many deleterious effects to be practical.

- X.1.3.a Today there are many types of anti-static additives classified as either applied externally as discussed **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS:** that are temporary or are internal additives that are longer lasting. Internal quaternary ammonium salt anti-static additives migrate to the record surface where they form a micro-layer of water making the vinyl record 'dissipative' (recall definition **CHAPTER VI. MAINTAINING CLEANLINESS:**). This function is sensitive to ambient humidity and can be removed with many types of cleaning eventually depleting the reservoir of anti-static additive. Do all records have dissipative internal anti-static additives – that is unknown. What is known is that some records play quieter than others and that could be a function of the record surface roughness factor discussed further in **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:**.
- X.1.3.b There are various conductive carbon black pigments now available that can achieve 'dissipation' at less than 5%, and emerging graphene additives that may in the future be able to reduce the record 'conductivity' to achieve permanent anti-static without deleterious effects (source: *Anti-static PVC-graphene Composite through Plasticizer-mediated Exfoliation of Graphite*, Wei, Z. B.; Zhao, Y.; Wang, C.; Kuga, S.; Huang, Y.; Wu M. *Chinese Journal Polymer Science*, June 2018 (68).)
- X.1.4 **Plasticizer:** 1% of a soybean oil epoxide (ESO) provides a lower melt viscosity of the mixture, which reduces the internal friction of the mixture when it is pressed into a record and thereby improves the moldability by filling the groove with less compression force. More than 1% over-saturates the resin thereby producing oily splotches on the surface of the record, and the splotches result in noise on playback. Some of the many forum discussions on removing mold release may be actually be associated with excess plasticizer/modifier. For information, ESO is a yellowish color. So clear records if they use a plasticizer may use something different from ESO.
- X.1.5 **Lubricant:** 0.4% of an esterified montan wax. The wax also acts as a mold release. When the record is removed from the press without the lubricating effect of the montan wax ester in the compound, the grooves of the record are sometimes fractured, torn, and deformed by the removal. These faults in the groove produce noise on playback. Montan wax ester at the stated percentage is compatible with the resins and is homogenized into the surface of the record at the normal pressing temperature. If more than the stated amount of the montan wax ester is used, the excess amount is not absorbed into the surface of the record. Its presence results in non-uniformity in the surface of the record, particularly as related to the friction between the stylus and the groove. This non-uniformity produces noise when the record is played. Some of the many forum discussions on removing mold release may actually be associated with excess lubricant.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- X.1.6 **Pigment:** Carbon black 0.2% as a coloring pigment to get black record. For information the natural color of PVC and PVCa is clear. For translucent or colored records, the carbon back is omitted and the percent colorant/pigment adjusted as necessary for the customer. Carbon black is known as an inorganic pigment, and there are organic pigments that may be used.
- X.1.7 **Fluorescence:** Viewing records under UV light can show variations in the composition and maybe pressing quality with materials fluorescing different colors; see - <https://aiccm.org.au/national-news/summary-ultra-violet-fluorescent-materials-relevant-conservation>. Different pigments will view differently under UV light as indicated in **Figure 35**. Depending on the exact black pigment used, records under UV light can lightly fluoresce with a bluish or brownish type color or appear as just black where the UV light is absorbed. The three records in **Figure 35** vary left to right circa 2000, circa 1980's and circa late 1950's. Recent records appear to now be using black pigments that absorb UV light. The carnauba and paraffin waxes used as "Lubricant" and the ESO-Modifier if excessive may fluoresce with long-wave (365 nm) UV lights, and this may be the source of some of the fluorescence noted in records illustrated **CHAPTER IV. RECORD INSPECTION:**




Figure 35 – Records Inspected UV Light – Pigment Variations

- X.2 **Material Compatibility Testing.** There are many PVC material compatibility tables available on the internet. However, most are for rigid-PVC associated with PVC pipe, fittings, and components, and there are often no clear time limits for exposure, and there may be limited applicability to a thin relatively flexible vinyl record. Additionally, some of the PVC material compatibility tables are conflicting especially for alcohols. However, for PVC, there

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

is non-rigid-PVC which by *ASTM-D2287* can contain 10% copolymer/plasticizer, and there is plasticized-PVC (such as vinyl curtains and vinyl-tubing) that can contain 35% and more plasticizer. The following is a summary of quantitative material compatibility testing obtained from the web with cleaning agents performed for non-rigid and plasticized PVC.

- X.2.a *NAVSEA Report on Aqueous Oxygen Cleaning Products and Processes, 1994 (50)* tested rigid PVC per *ASTM-D1784* and non-rigid-PVC per *ASTM-D2287* (that contains 10% copolymer or plasticizer) to a variety of cleaning agents for up to 24-hours. In general, hot demineralized water and hot inorganic alkaline solutions (pH 12.5, max) and warm neutral pH aqueous cleaners (including one that contained 2-butoxyethanol – a glycol-ether water soluble solvent) did not extract any material and only a small weight gain (<2%) occurred. However, for non-rigid PVC, one hot alkaline detergent solution diluted to 10% showed a weight-loss (1.27%) after 24-hours exposure. The hot alkaline detergent was a concentrated industrial alkaline detergent (Brulin™ 815GD) that contains 5% to 10% nonylphenol ethoxylate nonionic surfactant (CAS 9016-45-9 similar to Dow™ Tergitol™ NP) and 1% to 5% anionic surfactant. Additionally, one near-neutral detergent solution containing 2-butoxyethanol showed an excessive weight gain (>2%). As a cautionary note, 2-butoxyethanol is a respiratory hazard with an allowable exposure limit of 25 ppm, and while used in many past cleaners, is no longer a common ingredient.
- X.2.b The study *A Model Approach for Finding Cleaning Solutions for Plasticized Poly(Vinyl Chloride) Surfaces of Collections Objects by Morales Muñoz, Clara & Egsgaard, Helge & Sanz-Landaluze, Jon & Dietz, Christian, 2014 (45)* focused on conservation of PVC-plastic artworks. The study tested thin (2 mm) PVC with 35% plasticizer to exposure times up to 150-seconds at ambient temperature with six (6) different solutions; water, solvents (heptane, ethanol and 1-propanol), two aqueous cleaners (5% BASF™ DEHYPON® LS45 a ethoxylated propoxylated nonionic surfactant (CAS 68439-51-0) with CMC 569 ppm and 5% Hostapon™-T described as an anionic surfactant composed of fatty acid methyl tauride with sodium salt) and a 1-mole(M) potassium hydroxide (KOH) alkaline solution. The solvents at 100% all showed plasticizer extraction, while 50% ethanol-water showed only minimal extraction after 100-seconds exposure. The 5% Hostapon T and 1M KOH aqueous solution showed no extraction and similar to the NAVSEA results, showed only a small weight gain. However, the 5% BASF™ DEHYPON® LS45 aqueous solution showed plasticizer extraction after only 50-seconds exposure and it was noted that the 5% concentration was very difficult to rinse. The paper indicates that the exact plasticizer in the sample was unknown, but that prior analysis showed 96% diisononyl phthalate (DINP), and 4% di-2-ethylhexyl adipate (DEHA).
- X.2.c The pamphlet *Hallstar™ Plasticizers for PVC (16)* tested 40% plasticized-PVC with an unspecified 1% soapy water solution. However, the Hallstar™ results for 1% soapy water, 7-days at 90°C (194°F), consistently showed weight loss for all plasticizers. These results are consistent with the testing that was performed by the study *A Comparison of Plasticizers for Use in Flexible Vinyl Medical Products, April 2001 by Richard C. Adams (38)*; that tested

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

very thin (thickness 0.5-1.0 mm) 40% plasticized-PVC using an unspecified 1% soapy water solution with exposure times 24-hours and 72-hours at temperatures of 50°C, 60°C & 90°C (122°F, 140°F & 194°F). The study explanation for the weight loss by the 1% soapy water solution was that surfactant micelles can remove plasticizer that is located on the material surface. However, these studies do not specify the constituents in the 1% soapy solution which if a common household detergent can contain many ingredients including alcohol, anionic surfactants; nonionic surfactants, glycerine, colorants, perfumes, etc..

X.2.d The paper *Kinetics Study of the Migration of Bio-Based Plasticizers in Flexible PVC*, Ching-Feng Mao and De-Bin Chan, *2012 International Conference on Life Science and Engineering IPCBEE vol.45 (2012)* tested the migration of five different plasticizers (at concentrations about 30%) from very thin flexible PVC of 1 mm under contact with polystyrene sheets at 190°C for 10 min. The plasticizers tested were acetyl tributyl citrate (ATBC), di (2-ethylhexyl) phthalate (DEHP), di (2-ethylhexyl), adipate (DEHA), and epoxidized soybean oil (ESO). The PVC/ESO showed no weight loss, while the PVC/DEHP was about 2%, PVC/ATBC was about 7% weight loss and PVC/DEHA was about 12% weight loss. The stability of the ESO plasticizer, the same used in the RCA™ record composition, is noteworthy.

X.3 **Data Analysis:** Its important understand that the record composition of PVCa, PVC and pigment form a polymer while any added plasticizer acts as a solvent. How each of these can be attacked by a cleaning agent should yield different, but predictable results. When the results are contrary to what is predicted, there is reason to challenge the test data.

X.3.a Plasticizers can migrate from polymers based on three general mechanisms 1) evaporation to the ambient – same as off-gassing; 2) extracted by being soluble with liquids in contact; and 3) transfer from one surface of another. So, extracting a plasticizer is noted by weight loss.

X.3.b Solvent dissolution of polymers follow a well documented path. The paper *A review of polymer dissolution*, Beth A. Miller-Chou, Jack L. Koenig, *Prog. Polym. Sci. 28 (2003) 1223-1270* states: “First, the solvent begins its aggression by pushing the swollen polymer substance into the solvent, and, as time progresses, a more dilute upper layer is pushed in the direction of the solvent stream. Further penetration of the solvent into the solid polymer increases the swollen surface layer until, at the end of the swelling time, a quasistationary state is reached where the transport of the macromolecules from the surface into the solution prevents a further increase of the layer.”. So, for a polymer, evidence of swell and maybe weight gain are the first evidence of attack.

X.3.c Some polymers such as Nylon are hydroscopic and will gain weight in contact with water, but over time will release the absorbed moisture and recover. PVC is not hydroscopic, so weight gain after exposure to water or an aqueous surfactant solution is unlikely associated with swell. The weight gain associated with aqueous surfactants noted in the NAVSEA

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

testing is likely the result of surfactant residue. High concentration surfactant solutions – those at many times the CMC, are known to be difficult to rinse and so weight gain can be a consequence. Also, the water loving head of the surfactant is hydroscopic, and if left behind will want to absorb moisture. Nonionic surfactants are known to be weak anti-static agents. In some cases such as anti-static cationic surfactants, it's intended that a surfactant film be deposited that absorbs moisture from the air since this is how the anti-static functions.

- X.3.d The weight loss and plasticizer extraction test results with solvents, Brulin™ 815GD and 5% BASF™ DEHYPON® LS45 a nonionic surfactant can be explained. Common plasticizers used in non-rigid PVC are phthalates and the plasticizer DINP is mainly from C9 – branched alcohol isomers. So the ability of alcohols and 5% BASF™ DEHYPON® LS45 a C12-C14 ethoxylated alcohol non-ionic detergent to extract this plasticizer should not be unexpected. As a side note, the plasticizer DINP is part of a family of phthalate plasticizers that along with bisphenol A (BPA) have received wide attention for their toxicity concerns in plastic bottles and the ability to be extracted. Overall, it is very unlikely that record compositions include any phthalate plasticizers.
- X.3.e The ability of 1% soap solutions to extract a plasticizer from flexible PVC containing upwards of 40% plasticizer should not be unexpected. The testing was performed at high temperatures and durations with an indeterminate cleaner composition that may have contained any number of ingredients including ethanol, IPA, and likely an alcohol derived nonionic surfactant. As a side note, Hallstar™ does not manufacture ESO plasticizer, so the 1% soap solution testing does not include the ESO plasticizer used by the RCA™ patent.
- X.3.f However, none of the quantitative testing for non-rigid/flexible PVC has any real correlation to the PVCa/PVC record composition detailed in the RCA™ patent. The plasticizer in the RCA™ record composition is only 1% or less and the ESO plasticizer is not commonly used in flexible PVC because of poor mechanical properties, but is a very stable plasticizer in PVC unlikely to be extracted by any aqueous solution. Additionally, the vinyl record PVCa/PVC composition is predominantly a copolymer + homopolymer and is unlikely to be attacked by any aqueous surfactant solution. Additionally, because plasticizers migrate, if the record contained any appreciable amount, it would never last as long as it does.
- X.4 **Aqueous Surfactant Cleaner Summary:** There is no data that supports that an aqueous surfactant cleaner (less any solvent such as alcohol) of near neutral pH is going to harm a modern (1970's and later) PVCa/PVC record used at any application temperature that would not otherwise harm the record. The greatest harm from surfactant-based cleaners is failure to rinse leaving residue that can then lead to other consequences. However, recalling **CHAPTER IV. RECORD INSPECTION:** and **paragraph VIII.9.3.c**, there is variability in the record composition especially with re-pressed (recycled) records or very early records (1950's to 1960's) that may have used lead based heat stabilizer. Therefore, to be conservative, using the smallest chemical concentration is always prudent. From this perspective, there is no

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

evidence that the Alconox™ Liquinox™ pre-cleaner at 1% concentration or the Dow™ Tergitol™ 15-S-9 final cleaner at 0.1% concentration for short exposure times at temperatures up to about 40°C (104°F) will have material compatibility issues with PVCa/PVC vinyl records, substantiated as follows.

- X.4.a The manual cleaning process specified herein (and vacuum RCM) exposes the vinyl record to the cleaning solutions at room temperature for an accumulated time of only a few minutes – 5 minutes at most. Even if used in heated ultrasonic tanks for longer durations up to about 15 minutes, the exposure time is still very short.
- X.4.b The concentrations recommended herein are all very low in comparison to those tested. The 0.1% Tergitol 15-S-9 recommended herein is 50 times less than the 5% BASF™ DEHYPON® LS45, and 10 times less than the 10% alkaline detergent (Brulin™ 815GD) that when diluted would contain 0.5% to 1% nonionic surfactant. and 0.1% to 0.5% anionic surfactant.
- X.4.c The Alconox™ Liquinox™ concentrate contains two anionic surfactants combined for 12.5% to 35% and two nonionic surfactants - one an amine at 1% to 2%, the other an ethoxylated nonionic surfactant similar (by CAS No.) to Dow™ Tergitol™ 15-S-9 at 2.5% to 10%. Diluted to 0.5% to 1% as specified herein, in use the Alconox™ Liquinox™ pre-cleaner contains only a maximum of 0.1% ethoxylated nonionic detergent; a concentration no different from that specified herein for use of Dow™ Tergitol™ 15-S-9. While the sodium alkylbenzene sulfonate anionic surfactant in Alconox™ Liquinox™ is more aggressive than the mild anionic surfactant used in Hostapon™-T; diluted to 1%, in use the Alconox™ Liquinox™ anionic surfactant concentration is only 0.35% which is 14 times less than the tested 5% Hostapon™-T.
- X.4.d The paper *Corrosion of Lead and its Alloys*, Stuart Lyon, December 2010 (63) indicates that the solubility of lead is greater in distilled water than in anionic solutions stating that “*In distilled water free from dissolved gases, corrosion is slight though significant however, the rate of corrosion is increased by the presence of oxygen.*”; and “*Lead is not generally attacked rapidly by solutions that contain anions where the lead salt is sparingly soluble and, hence, where lead can passivate by the formation of a salt film.*”. The detrimental effects noted by *Record Contamination: Causes and Cure* by Percy Wilson, 1965 (52) in **paragraph VIII.9.3.c** may have been from residue left behind versus a short exposure followed by DIW rinse. Additionally, cationic surfactants have been used for anti-static record ingredients and coatings since 1960 per *Anti-Static Phonograph Records* G. P. Humfeld, *RCA Engineer Magazine Vol. 6, No.3. October-November, 1960 (21)*. However, as previously addressed **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS**; anionic surfactants are generally not compatible/soluble with cationic surfactants, so this may have been the root cause for the observation.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

X.4.e The use of cleaning agents in ultrasonic cleaning machines (UCM) heated to the point that the record no longer has the same stiffness as room temperature should be approached with Caution especially if using a cleaning agent other than just purified water. Chemical reaction rates are proportional to temperature. The Dow™ Tergitol™ 15-S-9 final cleaner at less than 0.1% concentration and the Alconox™ Liquinox™ pre-cleaner at less than 1% concentration should be UCM compatible with vinyl records, but time and temperature need to be considered and further details and recommendations are addressed **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES:**. But, use of other aqueous cleaning agents without knowing detailed constituents could present a risk and using the least amount for the shortest time prudent.

X.5 **Solvent Compatibility with Records:** Solvents can dissolve polymers, and solvents can span a wide variety of chemistries. One of the constant debates at many forums is the use of ethanol and isopropanol (IPA) alcohol solvents and their material compatibility with records. There are no definitive test results. There are some tests exposing a few records with visual observation and subsequent playback to determine change in sound. One test did analyze the alcohol for evidence of extracted components, and none were found which is predictable. But these do not duplicate the 'gold-standard' testing that RCA™ did, and are unlikely to determine the actual effect which is more likely associated with swell and causing accelerated wear of the record. In an attempt (*as futile as it may be*), to potentially bound the issue, a basic Hansen Solubility Parameter Analysis was performed.

X.5.a *Charles M. Hansen (Ph.D)* in 1967 developed a method to predict if one material will dissolve in another. The method is based on one of the foundations of chemistry that "**like dissolves like**". Hansen expanded upon the *Hildebrand* solubility parameter to establish three parameters that would characterize the forces that hold the molecule together.

$$\sqrt{(\partial d^2 + \partial p^2 + \partial h^2)} = \partial t$$

Where: ∂d = the energy from dispersion forces between molecules

∂p = the energy from dipolar intermolecular force between molecules

∂h = the energy from hydrogen bonds between molecules.

∂t = the total and is the *Hildebrand* solubility parameter that is the sum of the squares of the three *Hansen* parameters

X.5.b For polymers, the three parameters are used to calculate a sphere with radius-R. The smaller the radius-R, generally, the smaller the number of solvents that can attack/swell/dissolve the polymer. For solvents, the three parameters are used to calculate their distance from the center of the polymer sphere D(S-P) as follows where 's' designates the applicable solvent parameter and 'p' designates the applicable polymer parameter.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

$$D_{(S-P)} = [4(\partial_{dS} - \partial_{dP})^2 + (\partial_{pS} - \partial_{pP})^2 + (\partial_{hS} - \partial_{hP})^2]^{0.5}$$

- X.5.c $D(S-P)-R$ = distance of the solvent from the center of the polymer solubility sphere.
- $D(S-P)-R < 1$; If less than the radius of interaction for the polymer, the polymer will likely be partially or completely soluble in the solvent.
 - $D(S-P)-R = 1$; If equal to the radius of interaction for the polymer, the polymer is likely to swell and may partially dissolve in the solvent.
 - $D(S-P)-R > 1$; If greater than the radius of interaction for the polymer, the polymer will not dissolve but depending on how close to the radius of interaction for the polymer, the solvent may cause the polymer to swell.
- X.5.d The “*HANSEN SOLUBILITY PARAMETERS, A User’s Handbook, Second Edition, Charles M. Hansen, CRC Press, 2007 (11)*” details the solubility parameters for many polymers and solvents. Using available data and doing only a simple stepped proportional analysis of the three polymer ingredients from the RCA™ patent (PVCa, PVC and pigment), the least (most PVCa, least PVC and carbon-black pigment) and most sensitive (least PVCa, most PVC and carbon-black pigment) record composition was determined to potentially bound the uncertainty in the record composition. Tables **Table VIII** & **Table IX** show the analysis results. Remember the analysis is only a prediction, but it compares against known data, and this assumes room temperature. Heated applications such as ultrasonic tank cleaning accelerate chemical reaction rates and the results could be worse. The term “weight gain” may only apply to the side wall ridge peaks and only measurable in micro-grams (μg).
- X.5.e The first take-away is that the record PVCa/PVC composition is not that much different than PVC. But, it’s important to do a stepped proportional analysis where PVCa at the allowable variation is first determined. Otherwise, doing just an analysis of the total PVC + PVA will yield solubility spheres much larger than those calculated herein making the record appear less compatible than it likely is.
- X.5.f For a quick summary, use of ethanol and IPA at 20% or less are unlikely to cause any material compatibility issues used at any temperature that will not damage/wrap the record, flammability and explosion hazard notwithstanding. At higher concentrations, there is uncertainty and results will be dependent on the specific record composition; application temperature; polymer weight to solvent volume and the exposure time. However, high concentrations at higher temperatures, fire and explosion risk should preclude use. Is someone using 70% to 100% alcohol to wipe a record for a few minutes using just a few milliliters going to cause harm? It is very unlikely.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

X.5.g Soaking a record with high concentrations of alcohol solvents at room temperature for extended periods could be harmful. We do not know how reversible is any swell, and we do not know the exact record composition. If reversible such as Nylon, and adequate time between cleaning and play, then little harm will occur. If not, and the record properties are altered – likely softened or possibly hardened, in either case accelerated record wear would be expected and the high frequency side wall ridges/peaks that are the thinnest portion of the record should be the most susceptible. If they soften, the stylus will permanently bend/smear the peak and high frequency data (signal amplitude/strength) will be attenuated/lost.

**Table VIII
Hansen Solubility Parameter Record Polymers & Solvents**

Material	Total δ_t	Dispersion δ_d	Polar δ_p	Hydrogen δ_h	Radius R
POLYMERS					
Polyvinyl Chloride (PVC)	21.36	18.20	7.50	8.30	3.50
Polyvinyl Acetate (PVA)	25.66	20.93	11.27	9.66	13.71
Polyvinyl Chloride-Acetate 60% PVCa - calculated (44% PVC/16% PVA)	13.83	11.36	5.10	6.03	4.08
Polyvinyl Chloride-Acetate 70% PVCa calculated (58% PVC/12% PVA)	15.46	13.07	5.70	5.97	4.22
Inorganic Carbon Black (CB) Pigment 250 nm	26.91	21.10	12.30	11.30	16.60
Organic Pigments (OP) Black or Red	13.00	9.80	7.70	5.00	5.20
RECORD COMPOSITIONS Per the RCA Patent (calculated parameters)					
Record 60% PVCa + 36.2%- PVC + 0.2%-CB	16.05	13.42	5.79	6.63	3.73
Record 70% PVCa + 26.2%- PVC + 0.2%-CB	16.47	13.96	5.98	6.38	3.91
SOLVENTS - Listed Total (δ_t) Increasing					
Epoxidized Soybean Oil (ESO) plasticizer	17.34	16.50	1.60	5.10	NA
100% Toluene	18.20	18.00	1.40	2.00	NA
100% Methyl Ethyl Ketone	19.00	16.00	9.00	5.10	NA
100% Acetone	20.00	15.50	10.40	7.00	NA
100% Acetic Acid	21.37	14.50	8.00	13.50	NA
100% IPA	23.50	15.80	6.10	16.40	NA
91% IPA/Water	25.47	15.78	6.99	18.73	NA
100% Ethanol	26.50	15.80	8.80	19.40	NA

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Material	Total δ_t	Dispersion δ_d	Polar δ_p	Hydrogen δ_h	Radius R
95% Ethanol + 5% Methanol (denatured)	26.67	15.77	8.98	19.55	NA
100% Propylene Glycol	29.52	16.80	9.40	23.30	NA
70% IPA/Water	30.24	15.74	9.07	24.17	NA
30% Acetic Acid/Water (Vinegar)	39.38	15.27	13.60	33.66	NA
20% IPA/Water	42.65	15.64	14.02	37.12	NA
Water	47.80	15.60	16.00	42.30	NA

Table IX

Hansen Solubility Parameter Record & Solvents Analysis

Combination	Solvent Distance from Polymer Center D(S-P)	Polymer Radius R	D(S-P)-R	Data/Risks
PVC & Solvent - Documented Baseline Data for Comparison Tested 0.5 gm polymer in 5 mL solvent				
PVC % 100% Methyl Ethyl Ketone	3.90	3.50	0.40	Testing showed strongly swollen & slightly soluble
PVC & 100% Toluene	4.98	3.50	1.48	Testing showed swelling
PVC % 100% Acetone	5.91	3.50	2.41	Testing showed swelling
PVC & 100% Propylene Glycol	6.44	3.50	2.94	Testing showed compatible
PVC & 100% Ethanol	6.85	3.50	3.35	Testing showed compatible
PVC & 100% Acetic Acid	8.09	3.50	4.59	Testing showed compatible
LEAST SENSITIVE RECORD FORMULATION Record 60% PVCa + 36.2%-PVC + 0.2%-CB				
Record & 100% Acetone	6.23	3.75	2.48	Likely to result in swelling
Record & 100% IPA	6.46	3.75	2.71	May result in swelling
Record & 91% IPA	6.89	3.75	3.14	Likely compatible
Record & 100% Ethanol	7.53	3.75	3.78	Likely compatible
Record & Denatured Ethanol	7.58	3.75	3.83	Very likely compatible
Record & 70% IPA	8.17	3.75	4.42	Compatible
Record & 30% Acetic Acid (Vinegar)	11.32	3.75	7.57	Compatible

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Combination	Solvent Distance from Polymer Center D(S-P)	Polymer Radius R	D(S-P)-R	Data/Risks
Record & 20% IPA	12.16	3.75	8.41	Compatible
Record & Water	13.92	3.75	10.17	Compatible
MOST SENSITIVE RECORD FORMULATION Record 70% PVCa + 26.2%-PVC + 0.2%-CB				
Record & 100% Acetone	5.50	3.91	1.60	Likely to cause swelling
Record & 100% IPA	5.80	3.91	1.89	Likely to cause swelling
Record & 91% IPA	6.25	3.91	2.34	May cause swelling
Record & 100% Ethanol	6.90	3.91	2.99	Likely compatible
Record & Denatured Ethanol	6.95	3.91	3.05	Likely compatible
Record & 70% IPA	7.60	3.91	3.70	Very likely compatible
Record & 30% Acetic Acid (Vinegar)	10.93	3.91	7.02	Compatible
Record & 20% IPA	11.72	3.91	7.82	Compatible
Record & Water	13.53	3.91	9.62	Compatible

X.6 **Closing thoughts:** Off-gas testing may be an easy, low-cost qualitative test for solvent absorption (polymer swell). IPA is not expected to extract anything; any attack should be swell. Soak a record sample in IPA for X-hrs. Once removed from the IPA, allow the wet IPA to dry/evaporate for ~15 minutes. Check for odor; IPA has a very low odor threshold ~22 ppm. If there was odor, this is the first evidence that the record absorbed 'some' IPA. If odor-free (more likely) place the sample in a sealed glass container and heat in a water bath at 95°F to 100°F for 2-4 hours and then check the container air for odor. If it smells of IPA, the record likely experienced some swell; and even a small amount can have an impact. Industry advances this off-gas test by placing samples in an oven filled with oil-free nitrogen and then samples with a GC/MS to get quantitative results with sensitivity to 1 ppb. But off-gas testing using just our noses can be very sensitive for what we are concerned with and eliminates the many variables associated with trying to measure and analyze weight change. Additional details may be captured in the 3rd edition of this document.

CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:

When cleaning any item, there is the very first question - "What is clean?", and for a record the next question should be "When is a vinyl record clean?" **CHAPTER I. VINYL RECORD CLEANING CHALLENGES:** indicated we have no practical quantitative verification method. This Chapter *attempts* to answer these questions by establishing quantitative criteria and to show that the process detailed **CHAPTER V. MANUAL CLEANING PROCESS:** can achieve a *clean vinyl record*.

XI.1 The concluding statements from **CHAPTER I. VINYL RECORD CLEANING CHALLENGES:** are that for vinyl records, a robust precision cleaning process is required to achieve desired cleanliness. In the precision cleaning industry, there are visual and quantitative cleanliness levels. The following are the visual cleanliness levels commonly used by *MIL-STD-1330D (42)*, *MIL-STD-1622B (43)* and NASA adjusted for a vinyl record.

XI.1.a **Generally Clean (GC):** Freedom from manufacturing residue, dirt, oil, grease, etc. The generally clean level is specified for hardware that is not sensitive to contamination and is easily cleaned or recleaned. A vinyl record that passes GC can have particles greater than 50 microns and organic contamination greater than 50 mg/ft² present. This level of cleanliness is insufficient for a vinyl record. The user will experience annoying noises, possible collection of 'gunk' on the stylus and the playback fidelity will likely be compromised.

XI.1.b **Visibly Clean (VC):** Free of all particulate and nonparticulate matter visible to the normal unaided eye or corrected vision eye with bright white light. This level is for hardware that requires removal of surface particulate and nonparticulate for operation; or hardware for which recleaning would be difficult and/or time consuming. A vinyl record that passes VC can have many particles less than ~50 microns and have organic contamination as high as 50 mg/ft² depending on the contaminant. This level of cleanliness is achieved with simple wet brushes but based on groove dimensions and geometry is insufficient to prevent annoying noises or an accumulation of 'gunk' on the stylus, and maximum fidelity from a vinyl record is unlikely.

XI.1.c **Visibly Clean + Ultraviolet (VS+UV):** Visually clean and inspected with ultraviolet light. This level is usually specified for hardware that cannot tolerate buildup of hydrocarbons between uses or operations, and is more sensitive to particulate, but is limited to only those contaminants that are visible and fluoresce. A vinyl record that passes VS+UV can have many particles less than ~25 microns and have organic contamination of 25 to 50 mg/ft² depending on the contaminant. Lightweight mineral oils that do not fluoresce can be non-detectable with VS at levels of 50 mg mg/ft². Cleanliness level VS+UV based on groove dimensions and geometry is insufficient to prevent annoying noises and to obtain maximum fidelity from a vinyl record. However, once cleanliness is established by a precision wet cleaning process, VS+UV should be suitable for maintenance of cleanliness. This concept is fundamental to *MIL-STD-1330D (42)* and *MIL-STD-1622B (43)*.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XI.2 *MIL-STD-1246C, Product Cleanliness Levels and Contamination Control Program (41)* (now superseded by commercial specification IEST-STD-1246) has been a source for defining quantitative product cleanliness levels in terms of allowable particulate and allowable non-volatile residue (NVR) for decades. Other agencies such as NASA specify similar cleanliness levels. Some of the various cleanliness levels are defined in **Table X**. Achieving a cleanliness level of 50A in a residential setting is a challenge - but doable (as will be discussed); aided by vinyl records having the advantage of being a fairly robust, reasonably hard material that is not porous and has no inaccessible areas. The following are a few notes to **Table X**.
- XI.2.a When specifying cleanliness requirements, the particulate level and non-volatile residue (NVR) level are specified separately, so for example a cleanliness level of 100A can be specified.
- XI.2.b Because of how particle counts are measured, *MIL-STD-1246C (41)* can show fractional counts. For the purposes of this document, and similar to how other activities specify particulate cleanliness levels, all counts are simply bounded and all counts are rounded-up. For each cleanliness level, particles smaller than the smallest specified have an allowable count that is unlimited (but silting is not allowed).
- XI.2.c The pre-clean, rinse, final clean, rinse process detailed in *MIL-STD-1330D (42)* and similar type precision processes can routinely achieve cleanliness Level 50A. While *MIL-STD-1330D (42)* uses a parts washer or ultrasonic tank for final cleaning, the use is for complex geometries, process efficiency (many parts at-once) and for cleanliness verification. The final clean step of **CHAPTER V. MANUAL CLEANING PROCESS**: is as effective for cleaning and this will be shown in **Table XI**.
- XI.2.d A particulate Level 25 (and less) can generally only be achieved in a controlled cleanroom or equally controlled environment such as provided by a vertical air flow (laminar) bench or hood with HEPA air filters, that are readily available from a number of vendors, but at costs starting at about \$3K. However, as addressed in **CHAPTER V. MANUAL CLEANING PROCESS**; use of lower cost, portable room or desk-top HEPA air filter should establish a temporary area of very low levels of airborne particulate for those so inclined.
- XI.2.e The flat surface area of each 12-inch record (minus label area) side calculates to about 0.6-ft². However, the grooves and side wall ridges add surface area. Using the nominal groove dimensions from **CHAPTER I. VINYL RECORD CLEANING CHALLENGES**; the groove side wall (triangle hypotenuse) is about 0.0016-inches so that each groove that is about 0.0022-inch wide at the top has about 0.0032-inches linear length and 0.0032"/0.0022" = 1.46 correction to the 0.6-ft² calculated flat surface area. Adding 10% for the side wall ridges, the actual record surface area = (0.6-ft² flat surface area) x (1.46 groove correction) x (1.1 side wall correction) = 0.96-ft². Rounding up, a 12-inch record has an

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

actual surface area of about 1.0-ft². The 1-ft² area makes its very simple to convert NVR mg/ft² to film thickness.

- XI.2.f The NVR nominal film thickness (*Contamination Control Engineering Design Guidelines for the Aerospace Community, NASA Contractor Report 4740, May 1996*) (46) shown in **Table X** assumes the contaminant is uniformly applied and has a density of 1-g/cm³ = 62.43 lbs/ft³ (same as freshwater); and while a 1-micron film calculates to about 9.1 mg/ft², for ease of use 10 mg/ft² equals 1-micron thickness is applied. Most water-soluble nonionic surfactants have a density very close to water, but lower density contaminants such as oil will develop larger film thickness while denser contaminants such as hard water spots develop thinner thickness as noted for **Table V**.

Table X
MIL-STD-1246C Particulate and NVR Cleanliness Levels

Particulate			Non-Volatile Reside		
Level	Particle Size microns	Allowable Count/ft ²	Level	Limit	Nominal Film Thickness
25	≥2 <5	53	A/2	0.5 mg/ft ²	0.05 micron
	≥5 <15	23			
	≥15 <25	4	A	1.0 mg/ft ²	0.10 micron
	≥25	1			
50	≥5 <15	166	B	2.0 mg/ft ²	0.20 micron
	≥15 <25	25			
	≥25 < 50	8	E	5.0 mg/ft ²	0.50 micron
	≥50	1			
100	≥5 <15	1785	G	10.0 mg/ft ²	1.00 micron
	≥15 <25	265			
	≥25 <50	78	J	25.0 mg/ft ²	2.50 micron
	≥50 <100	11			
	≥100	1			

- XI.3 **Figure 36** and **Table XI** are a process analysis of the estimated NVR remaining from the pre-clean and final clean steps specified by the process detailed in **CHAPTER V. MANUAL CLEANING PROCESS**. **Table XI** is intended to show how the overall cleaning process can achieve an NVR cleanliness Level A of less than or equal to 1.0 mg/ft². **Table XI** also shows that cleaning agents have more NVR than the NVR being removed, and shows why using tap-water for the pre-rinse, and rinsing after each cleaning agent application is acceptable. **Table XI** has been formatted to allow easy conversion to a spreadsheet allowing users to adjust initial record NVR and chemistry to see results. **Table XI** was developed as follows:

- XI.3.a An initial heavy soil load of 25 milligrams (that would include particulate) is used and should not be considered unrealistic for a dirty record.
- XI.3.b For the purposes of water, equivalent TDS-ppm converted to milligrams from **Table IV** was used for NVR, while the cleaner concentration in ppm converted to milligrams was used for

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

NVR. For ease of analysis, all ppm is assumed equal to mg/L, so TDS of 200 ppm = 200 mg/L. All solutions are then corrected for the amount of solution applied or allowed to dry = (solution mL/1000).

- XI.3.c There are some assumptions since the cleaner will release and contain contaminants removed from the record surface. The amount of cleaning solution on the record is about 25 mL based on a simple test that measured the amount applied to a record. The NVR removed from the record is equally distributed in the 25 mL of cleaning solution. Each cleaning step is assumed to be 90% efficient for how it is applied. The final-cleaner would not be 90% efficient in removing an initial heavy soil load because of the small amount (about 25 mL) of cleaner and type of cleaner used. **Table XI** should show that the high concentration pre-cleaner is doing the heavy-lifting, removing the bulk of the soil, while the lower concentration final cleaner does the final polish. However, it is important to note that because of the limited amount of cleaning solution used (~25 mL), exceptionally dirty records can exhaust the chemistry which is why **CHAPTER V. MANUAL CLEANING PROCESS:** recommends using two (2) pre-clean steps for these records.
- XI.3.d The effectiveness of the rinse under essentially unlimited, flowing tap-water may achieve better than specified, but to be conservative is assumed at 95% for this analysis and is shown in the Item 8 calculation.
- XI.3.e The lower efficiency of 85% for the final spray rinse is intended to account for the limited amount of DIW used and application inefficiency and is shown in the Item 10 calculation.
- XI.3.f To determine the NVR contamination level (mg/ft²), the assumption (by simple measured test) is that 5-mL of post rinse water-solution dries on the surface, and the resulting NVR in milligrams is distributed across the record that was previously calculated to be about 1.0 ft² minus the label. This is calculated in Items 8 and 10.
- XI.3.g The final NVR on the record after each cleaning step is the sum of NVR not removed plus the NVR left from the cleaner/rinse and this shown in Item 12. However, the worst case is that the NVR is only in the groove so Item 14 shows that equivalent recalling that the groove is about 40% of the total record surface.
- XI.3.h Items 13 & 15 converts Items 12 & 14 to the film thickness.
- XI.3.i Pursuant to **Table XI** and **Figure 36**, the NVR cleanliness goal of **Table X** Level A (1.0 mg/ft²) should be achievable.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Figure 36 – Record NVR Following Precision Aqueous Cleaning Process

**Table XI
Remaining NVR Analysis After Pre-Cleaning & Final Cleaning**

Item	Solution	Pre-Clean Step	Final Clean Step
1	Initial record NVR (For Final Clean NVR is from Pre-Clean item 11)	25 mg	2.5 mg
2	5-mL water on record NVR after Pre-Rinse with tap-water [(assumes 200 ppm TDS) x (0.005)]	1 mg	NA
3	Record NVR left from cleaning (For Final Clean NVR from Pre-Clean item 8)	NA	1.1 mg
4	Cleaner NVR from 25 mL application [(cleaner ppm/40)]	125 mg	25.0 mg
5	Estimated NVR removed from record at 90% cleaner efficiency [(item 1) x (0.90)]	22.5 mg	2.3 mg
6	Total cleaner solution NVR before rinse (sum of items 2:5)	148.5 mg	28.4 mg
7	Tap-water rinse NVR (unlimited volume) (assumes 200 ppm TDS)	200.0 mg	200.0 mg
8	5-mL water on record NVR after 95% effective rinse with flowing tap-water [(item 6) x (0.05) +(item 7)] x (0.005)	1.1 mg	1.0 mg
9	Purified water rinse NVR (2.5 ppm from Table IV)	NA	2.5 mg
10	5-mL water on record NVR after 85% effective rinse with spray purified water [(item 8) x (0.15) +(item 9)] x (0.005)	NA	0.02 mg
11	Record NVR still remaining after cleaning [(item 1) x (0.05)]	2.5 mg	0.32 mg
12	Best-case Equivalent total surface NVR contamination level (pre-clean = sum of items 8 + 11) (final-clean = sum of items 10 + 11)	3.6 mg/ft²	0.34 mg/ft²
13	Best-case: Equivalent film thickness from Item 12 (Item 12) x (1 mg/ft ² /0.01 micron)	0.4 microns	0.03 microns
14	Worst-case: Equivalent surface contamination level assuming Item 12 is only in the groove that is 40% of the record total surface. (Item 12/0.4)	9.0 mg/ft²	0.85 mg/ft²
15	Worst-case: Equivalent film thickness assuming Item 12 is only in the groove (Item 13) x (1 mg/ft ² /0.01 micron)	0.9 microns	0.09 microns

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

XI.4 Having discussed what is clean, and what a reasonable cleaning process can achieve, the existential question remains – is what can be achieved using reasonable chemistry and methods good enough for a record? Audio forum reports from users using ultrasonic cleaning machines (UCM) without rinsing, indicate that by analysis of the bath cleaning concentration, cleaner (surfactant) residue equal to much greater than 150 mg/L (150 ppm) can be left behind and many report stylus residues, and those with critical listening skills hear distortion noted as “veiling of the music”. This begs the question; how large do imperfections need to be before they are audible?

XI.4.1 While **CHAPTER I. VINYL RECORD CLEANING CHALLENGES:** summarized the groove dimensions and geometry, very little detail was provided. The details of the groove geometry and the dynamic relationship of the stylus to that geometry can be affected by the record cleanliness. The lateral and vertical displacement defines the signal amplitude/output. The record spinning at ~33.333 revolutions per minute (rpm) = 0.56 revolutions per second (rps); the linear (tangential) velocity will vary from 51 cm/sec (20 inches/sec) at the outer-most groove to 20 cm/sec (7.9 inches/sec) at the inner-most groove. **Figure 37** shows simplistically the groove modulation wavelength (ridge to ridge distance) to reproduce various frequencies between the outer and inner-most grooves for 12-inch, 33.333 rpm and 45 rpm records. At the highest frequency the values can be as small as 10 microns for a 33.333 rpm record at the inner groove.




Figure 37 – Record Groove Wavelength to Produce Hz

XI.4.2 The stylus as it moves laterally and vertically is displaced, and displacement over time equals velocity and from velocity comes acceleration and all of this is combined to be the

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

modulation amplitude – the stylus motion that produces an audible signal. Fundamentally, during a silent, unmodulated groove, the stylus is not moving in relation to the record that is moving underneath it. The modulations cause the stylus to move up and down (vertically) and side to side (laterally). The recording industry uses groove-stylus velocity as a measure of signal output. Groove-stylus velocity, acceleration and amplitude can be calculated as follows (equation source: *Disc Phonograph Records by Dr. A. M. Max, RCA Engineer Magazine 1966-08-09 (1)*).

$$V = A2\pi f$$

$$a = \frac{A4\pi^2 f^2}{g}$$

$$A = \frac{V}{2\pi f}$$

Where: V = Velocity (cm/sec)
 a = Acceleration (g's)
 A = Amplitude (cm)
 f = Frequency (Hz)
 g = Acceleration constant = 981 cm/sec/sec

XI.4.3 There are three limiting factors when recording records, the stylus velocity, stylus acceleration and stylus radius. The amplitude equation above is usable for frequencies greater than 1000 Hz since at lower frequencies the amplitudes would be unreasonably large and because of this, the *Recording Industry Association of America® (RIAA)* recording curve attenuates the lower frequencies. Acceleration becomes limiting as the frequency increases as shown **Figure 38** and to correct recording engineers will often adjust the recording signal to limit acceleration to about 2000-g's (depending on the cutting head limitations) along with the RIAA® recording curve that amplifies high frequencies.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 38 – Stylus Acceleration

XI.4.4 **Figure 39** shows the RIAA™ recording curve, the peak groove-stylus velocity at a maximum recording amplitude of 0.005 cm/50 microns at the inner and outer grooves (per the equations in **paragraph XI.4.2**) and examples of the effect of stylus tip radius limiting the groove velocity. A radius of 0.0004 cm/4- μ m would be similar to a Shibata type stylus shape while the 0.0007 cm/7- μ m radius would be similar to an elliptical type stylus.




Figure 39 – Record Groove Velocity

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XI.4.5 Graphs presenting groove velocity, amplitude and stylus radii can also be found in *STEREOPHILE Chart File No. 8 Record Groove Parameters*, J. Gordon Holt, *The Stereophile Magazine Vol.1 No. 8, August 1964 (30)* and “*Disc cutting in theory*, Hugh Finimore, *Studio Sound and Broadcast Engineering, July 1975” (27)*. The following is provided to better understand **Figure 39**.
- XI.4.5.a The maximum amplitude is generally associated with how wide the groove can be before cutting into the groove next to it. Recalling **Figure 37**, as the frequency increases and as the stylus tracks closer to the inner groove, the stylus has less time to travel from rest to the modulation peak amplitude and therefore higher (peak) velocities occur. The practical limit of peak velocity occurs when the peak velocity of the modulation equals the linear (tangential) velocity of the groove (the speed at which the record passes the stylus). Exceed peak velocity and the “...groove swings become so sharp that the stylus tends to ride up over them instead of traveling around them. (30)”
- XI.4.5.b Groove modulations produce sine-waves and these have curves with a radius defined by the square of the linear (tangential) velocity divided by the stylus acceleration (**paragraph XI.4.2**) The (tip) radius of the stylus is tracing these curves. At higher frequencies, the radius of the sine-wave curve decrease. If the radius of the sine-wave curves becomes less than the stylus tip radius, the stylus will be unable to trace the modulations and “...the stylus loses its ability to follow the modulations accurately and tends to “gloss over them (30)” leading to loss of signal output and distortion. A conical stylus that can have a tip radius of 0.0018-cm (not shown **Figure 39**) has difficulty in tracking high frequency peak velocities and amplitudes.
- XI.4.6 Why are we concerned with these groove and stylus details? While the recording industry is often focused on the maximum peak velocity that can be recorded, from a precision clean perspective the opposite is of interest; and understanding the very small modulations and large accelerations involved provides insight to how small amounts of contamination can have an impact. The higher frequencies appear to be the most sensitive. Reviewing **Figure 38**, in order to limit stylus acceleration, the amplitude at the higher frequencies may be very small on the order of 1 micron with values as small as 0.1 micron reported (*An LP Primer*, Robert Harley *The Absolute Sound June/July 2007 (58)*). Reviewing **Figure 39**, technically, the area under the peak velocity lines can have recorded music, but the lowest groove velocities may only be used for records with a large dynamic range. Shure™ did a survey of the groove velocity of records that was reported in the paper *Design Considerations of the VI5 Type IV Phonograph Cartridge*, L. R. Happ (35) delivered at a 1978 technical seminar on phonograph cartridges. The majority of records were recorded at 6 dB (2 cm/sec) and greater.
- XI.4.7 **Table XII** analyzes the lower expected groove velocities where the amplitudes can be very small and then calculates the corresponding amplitudes. The 0.1 cm/sec (-20 db) is listed as a reference for a silent, unmodulated groove. Some observations from **Table XII** include

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

that thin soil films can especially at the higher frequencies contribute to the reported “veiling of the music” and small particulate can deflect the stylus sufficient to cause an audible response as follows:

- XI.4.7.a Any particle on the record has kinetic energy = 1/2 its mass times the record linear velocity squared. The stylus is essentially stationary, so when the particle ‘crashes’ into the stylus, some of energy may breakup/move the particle but some energy is transferred to the stylus displacing the stylus. This analysis is the same as a car hitting a stationary object. So, the same weight particle in the outer groove will have $[(51 \text{ cm/sec}) / (20 \text{ cm/sec})]^2 = 6.5X$ more kinetic energy than the same particle in the inner groove.
- XI.4.7.b For a simple example, a particle in the outer groove crashing into the stylus causes the stylus to displace 2.5 microns. If the system sees this as a low frequency signal (<1kHz) then the RIAA playback equalization is going to amplify the signal and a large audible response occurs. Assuming all things being equal, the same particle in the inner groove may only cause the stylus to displace $(2.5/6.5) = 0.4$ microns; and if the systems see this as a high frequency (>1kHz) then the RIAA playback equalization is going to attenuate the signal and a small audible response may occur. So, the location of the particle can be a significant factor.

Table XII
Record Groove Velocity vs Frequency & Amplitude

Frequency Hz	Amplitude in Microns at Groove Velocity					
	0.1 cm/sec -20 dB	0.5 cm/sec -6 dB	1.0 cm/sec 0.0 dB	2.0 cm/sec 6 dB	3.0 cm/sec 9.5 dB	4.0 cm/sec 12 dB
1250	0.127	0.637	1.273	2.546	3.820	5.093
1600	0.099	0.497	0.995	1.989	2.984	3.979
2000	0.080	0.398	0.796	1.592	2.387	3.183
2500	0.064	0.318	0.637	1.273	1.910	2.546
3150	0.051	0.253	0.505	1.011	1.516	2.021
4000	0.040	0.199	0.398	0.796	1.194	1.592
5000	0.032	0.159	0.318	0.637	0.955	1.273
6300	0.025	0.126	0.253	0.505	0.758	1.011
8000	0.020	0.099	0.199	0.398	0.597	0.796
10000	0.016	0.080	0.159	0.318	0.477	0.637
12500	0.013	0.064	0.127	0.255	0.382	0.509
16000	0.010	0.050	0.099	0.199	0.298	0.398
20000	0.008	0.040	0.080	0.159	0.239	0.318

XI.5 **Figure 40** graphs **Table XII** (except 0.1 cm/sec) and adds 8-cm/sec (18 dB) and 16 cm/sec (24 dB) groove velocity. It shows while anything below 25 microns will not be visible, gross contamination of 50 and 100 mg/ft² that develops a 5.0-to-10-micron film thickness is enough to fill-in most of the high frequency (>1000 Hz) side wall ridges (amplitude) and partially fill the groove. The 5.0 to 10 microns film thickness is an extreme amount of NVR

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

that may be associated with an “exceptionally dirty” record. Smaller film thicknesses especially if associated with hard mineral residue from tap-water is unlikely to be uniform so should be audible as transient noise (clicks, pops, etc.,) and can cause accelerated wear of the record and the stylus. Softer residue such as surfactants can be uniform and can be displaced into the side wall ridges and effect or reduce the recorded surface amplitude which is alluded to in the paper *Record Contamination: Causes and Cure by Percy Wilson, 1965 (52)* when it discusses in generalities loss of high-notes by some contaminants that can also foul the stylus.




Figure 40 – Groove Velocity vs Amplitude vs Gross Contamination

XI.6 **Figure 41** focuses the data to show the overall cleaning process of **Table XI** with groove velocity data from **Table XII** into the zone of precision cleaning where the amplitude is less than 2.5 microns and where there can still be a lot of music. This is likely the area that experienced listeners report ability to hear loss of high frequency detail; the detail that allows the listener to hear into the instrument and into the soundstage. A surfactant film thicknesses (from NVR) less than 0.5 microns (left as a result of no-rinse or insufficient rinse) can still cover a wide range of frequencies.

XI.6.1 From **paragraph XI.4.7.a** there is an objective rationale for how “small” particulate effects the sound. But, how does residue – NVR - effect the sound? There are a number of possibilities. First, what we do know is that thick residue will cause debris/residue to form

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

on the stylus as the record drags the stylus through the debris/residue, and records subsequently cleaned often are audibly improved indicating that the stylus will not clean a record of residue; record and stylus wear notwithstanding. We should agree that any residue that alters the natural surface finish of the record, that alters the friction factor, that increases the mass of the stylus, that alters the interface between stylus and the record may affect how and what the stylus traces. The residue can be viscous (liquid-like) or non-viscous (dry flakes/powder) and each can affect the surface differently.

- XI.6.1.a Given the high accelerations that the stylus experiences, residue (mass) that collects on the stylus will cause a resultant force (force = mass x acceleration) that can affect the stylus ability to trace the groove. A viscous residue on the record groove may damp the stylus reducing the modulation reducing the signal output. It may cause vibrations if the stylus experiences variable-drag or causes the liquid to cavitate under the extreme pressure of the stylus which in either case, the background noise floor may increase obscuring high frequency detail.
- XI.6.1.b If the residue coats only the side-wall ridge valley, then the stylus may not deflect/trace the full peak-to valley height and high frequency detail can be attenuated/lost. Recalling the DIY cleaners from **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS**; some are over 1000 mg/L (1 mg/ml) and if 3 mL was allowed to dry, the resultant NVR could be 3 mg/ft² with a resultant film thickness greater than 0.3 microns which by **Table XII & Figure 41** should be audible.
- XI.6.1.c A non-viscous residue may increase the surface roughness noting that the silent groove if at -20db (**Table XII**) is very near the record baseline surface roughness (0.01 micron) causing the background noise floor to increase potentially obscuring high frequency detail, record and stylus wear notwithstanding.
- XI.6.2 **Figure 41** shows that Level A = 1 mg/ft² should not interfere with most if any music; except for high frequency 0.5 cm/sec (-6 db) and therefore should be an acceptable NVR criterion for general record cleanliness. However, the preceding discussion of the NVR film has assumed it is uniform on the record. Instead, a more variable distribution is possible. Applying a simple Gaussian (normal) distribution for a nominal NVR of 1 mg/ft² = 0.1-microns, the actual film thickness could realistically vary from as low as 0.04-microns to as thick as 0.2-microns. So, depending on the individual record dynamic range, even Level A = 1 mg/ft² may be insufficient for very experienced listeners.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 41 – Groove Velocity vs Amplitude vs Contamination Levels

CONCLUSION

Based on the vinyl record groove dimensions, geometry, and velocities and what is achievable, that for overall good playback fidelity, a MIL-STD-1246C cleanliness Level 50A should be the **minimum** goal. If Level 50A is achieved it should provide margin for uncertainty and the natural degradation that will occur during use but mitigated if reasonable practices to maintain cleanliness are used.

XI.7 **Concluding Thoughts:** Will cleanliness better than Level 50A improve playback fidelity? As previously stated, depending on the record dynamic range, even Level A = 1 mg/ft² (=0.1-micron) may be insufficient if the soil is not uniformly distributed on the record. However, the best-case NVR from **Table XI** showed 0.34 mg/ft² (=0.34-microns) as being achievable.

XI.7.a My own recent experience implies that achieving the lowest level of any residue may be beneficial. I have noted improved playback quality – better detail – less distortion during the 2020-2021 winter. Similar improvement was not noted with my digital sources. The only quantifiable variable was ambient relative humidity had decreased from the mid-50’s to the lower 30’s/upper 20’s percent (humidifier not used). Per **CHAPTER VI. MAINTAINING**

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CLEANLINESS:, my platter and mat are grounded as specified, and I had no static issues even with carpet and socks. The lower humidity will by **Table VI** result in a thinner moisture film, but the film theoretically is less than the record surface roughness as shown **Figure 42**. But the moisture film may only be enough to fill-in the surface roughness.

- XI.7.b Recent discussion on some audio forums with subjective (listening) tests of various surfactant concentrations for ultrasonic cleaning without rinsing (details in **paragraph XIV.7**) imply that >0.03-micron cleaner residue 'may' be the threshold for audible effects. **Table XIII** evaluates at various cleaner concentrations the film thickness if a given volume is allowed to dry without rinsing. Note that the residue thickness is assumed to be uniform across the record which may or may not be the case. **Red** blocked data all exceeds the Level A NVR cleanliness criteria. **Yellow** and **orange** data could be the threshold of being audible by experienced listeners.

Table XIII
Residue Thickness from Cleaner Residue

Cleaner Concentration		Residue Thickness microns after X mL of Cleaner Allowed to Dry on a Record (1 mg/ft ² = 0.1 micron)				
%	mg/L	0.25 mL	0.50 mL	1.00 mL	2.00 mL	3.00 mL
0.005%	50	0.001	0.003	0.005	0.010	0.015
0.01%	100	0.003	0.005	0.010	0.020	0.030
0.02%	200	0.005	0.010	0.020	0.040	0.060
0.03%	300	0.008	0.015	0.030	0.060	0.090
0.04%	400	0.010	0.020	0.040	0.080	0.120
0.08%	800	0.020	0.040	0.080	0.160	0.240
0.120	1200	0.030	0.060	0.120	0.240	0.360
0.240	2400	0.060	0.120	0.240	0.480	0.720
0.480	4800	0.120	0.240	0.480	0.960	1.440

- XI.7.c There are audio enthusiasts with very high-resolution systems in acoustically engineered rooms that can reveal details not otherwise achievable. For these individuals, the best achievable cleanliness level may yield acoustic benefits, the complexity and cost notwithstanding. Completing the full pre-clean/final clean procedure detailed **CHAPTER V. MANUAL CLEANING PROCESS:** (or its equivalent with a vacuum-RCM) followed by ultrasonic cleaning with a demineralized and filtered pure water bath, with drying under a HEPA air hood (or temporary area of near equivalence) should repeatably obtain a cleanliness level better than Level 50A. There are audio enthusiasts already using something similar to this process (minus the HEPA air filtering) investing many thousands of dollars and reporting exceptional results.
- XI.7.d **Figure 42** shows the best possible cleanliness that can be achieved with certain limits as boundaries. The lowest is the water film at about 0.003 microns that forms from the air at 55°F dewpoint from **Table VI**. The best level of cleanliness is the inherent background noise of the vinyl record material that is a function of the material surface roughness which

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

by the paper "Disc cutting in theory, Hugh Finimore, Studio Sound and Broadcast Engineering, July 1975" (27) has an equivalent amplitude of 0.01 micron (this is better than a #8 Super Mirror Finish/Non-Directional Mirror Finish used to produce/polish stainless steel mirror). Achieving a Level-A/2 NVR cleanliness of 0.5 mg/ft² (0.05-micron layer equivalent) 'should' have some benefit in lowering the background noise floor for the silent track, but noting the very limited audio frequencies that may be affected at 0.5 cm/sec (-6 dB) and above. But, if a simple Gaussian (normal) distribution is applied to a nominal NVR of 0.5 mg/ft² = 0.05-microns, the actual film thickness could realistically vary from as low as 0.003-microns to as high as 0.11-microns. There is a cleanliness Level-A/5 (0.2 mg/ft² = 0.02 microns), but much lower and you are now approaching the surface roughness of the record and mostly below any recorded frequency/amplitude except for the silent track. It is possible to get the record too clean. Some very small amount of benign residue 'may' actually be beneficial since it may fill-in the surface roughness yielding a lower background noise floor.




Figure 42 – Groove Velocity vs Amplitude vs Best Possible Cleanliness

XI.7.e Caveat: The audio community is not bound to any predetermined cleanliness criteria such as Level A, A/2 or A/5. These are being used only as industry benchmarks. The audio community can adopt any cleanliness criteria it wishes. But, as the final concluding thought for justifying precision cleaning and achieving a high level of cleanliness I refer back to what was written in the **FORWARD**, "...it is my observation, that to effectively clean a vinyl record a precision cleaning process is required, and what lies within the grooves of a vinyl record may as yet be fully realized."

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER XII. DISCUSSION OF THE CLEANING PROCESS:

Disclaimer: There has been no microscopic analysis to verify the following discussion. The cleaning process detailed in **CHAPTER V. MANUAL CLEANING PROCESS:** and its applicable chemistry have its roots in verified precision cleaning processes such as *MIL-STD-1330D (42)*. However, actual use of the cleaning process specified herein with new and older/used contaminated/noisy records has yielded excellent results.

- Records cleaned by the process show no evidence of appreciable stylus debris viewed with white & UV light. An occasional fiber dropping from the atmosphere has been noted but easily removed. Records that were graded “generally clean” (including new records), still benefited from the pre-clean step yielding reduced surface (and overall background) noise that also yielded improved fidelity. The often-used comparison is the clarity of a glass window. The pre-clean/final-clean left the glass free of any film/haze as if the glass was removed.
- However, some records still had surface noise following the cleaning process. For some new records, the noise abated after a few plays which is not uncommon – initial plays effectively burnish the record surface removing microscopic burrs left from pressing. However, residual noise that remains can be groove damage caused by wear or poor pressing quality; neither repairable. Residual noise and overall poor playback can also be caused by poor quality vinyl. Recalling **CHAPTER IV. RECORD INSPECTION;** my experience is that records manufactured from poor quality, recycled vinyl generally have playback qualities deficient to records manufactured from virgin vinyl, regardless of record weight. It is possible that residual noise could be caused by deeply embedded debris that ‘may’ be removed with a heated ultrasonic cleaning machine discussed **CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES:**

XII.1 The U.S. Navy, NASA and many others developed in the early 1990’s as a result of eliminating ozone depleting chlorofluorocarbon (CFC) solvents, precision aqueous cleaning procedures that were all based on the foundation of pre-clean, rinse, final-clean, rinse, dry. This process is the basis of the component cleaning process specified *MIL-STD-1330D* and *MIL-STD-1622B* (source: *NAVSEA Report on Aqueous Oxygen Cleaning Products and Processes, 1994*) (50). The pre-clean step is intended to degrease, followed by a rinse, while the final-clean is intended to remove mostly invisible very fine films (including those that may be left by the pre-cleaner) and particulate, followed by a final rinse. The concept of pre-clean, final clean and final rinse is the essence of some record cleaning systems such as the Mobile Fidelity™ trio of cleaning products – Super Record Wash™, One Cleaning Solution™ and Pure Record Rinse™. However, one caveat is that the vinyl record is a fairly robust material that is applicable to a pre-clean/final clean process. Delicate materials such as a lacquer records or conservation art must be approached with Caution otherwise item damage can occur.

XII.2 The VinylStack™ Vinyl ‘1’ Stack record label protector (or the similar Groovemaster™ record label protector shown used by the *Library of Congress (34)*) allows the record to be exposed

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

to flowing water without concern for damaging the record label. The handle design of VinylStack™ Vinyl '1' Stack Record Label Protector provides ease of use, prevents handling the record surface, and the optional VinylStack™ Drying Stand with a simple modification shown **Figure 11** allow its use as an assembly stand for additional ease of use and process efficiency.

- XII.3 The U.S. Navy determined during the development of its *MIL-STD-1330D*, Aqueous Oxygen Cleaning Process in the early 1990's (*source: NAVSEA Report on Aqueous Oxygen Cleaning Products and Processes, 1994*) (50) that fluid agitation was critical to any water-based cleaning process, and that for pipe cleaning a minimum fluid velocity of 3 feet per second with goal of 6 feet per second was required. Additionally, for optimum performance, flushing forwards and backwards was also required for systems that had any irregular geometries. Fluid motion past a sharp irregularity would mostly bypass the backward side. The U.S. Navy also determined that the Reynolds number for turbulent flow was not the deciding factor; it was the shear force developed by the fluid velocity on the surface being cleaned. The use of water dropping from a faucet and flowing across the record surface for the first rinse to remove loose debris, the second rinse to remove the pre-cleaner and its debris and the third rinse to remove the final cleaner and its debris should approximate a near equivalent shear force. This will allow the rinse water assisted with the Record Doctor™ Clean Sweep Brush to penetrate the record grooves to remove/flush-away the cleaning solutions, debris released by the cleaning solutions, and finally any remaining very small loosened particulate.
- XII.4 The Record Doctor™ Clean Sweep Brush with clusters of 0.05 milli-meter (0.002") wide Nylon bristles (260,000 bristles total) or the OSAGE™ Nylon record brush with 0.004" wide Nylon bristles should not deeply penetrate the record groove. Additionally, Nylon absorbs water and softens during use (but returns to original properties once dry). Furthermore, the bristle width is near equal to the top width of the record groove and when combined with the low surface tension of both the Alconox™ Liquinox™ and Dow™ Tergitol™ cleaning solutions should form a hydraulic wedge to force the cleaner deep into the groove. The back-and-forth brushing action should then develop the fluid agitation (a combination of shear force & cavitation) necessary to deeply scrub/clean/flush the groove. But, since a new Record Doctor™ Clean Sweep Brush (or OSAGE™ brush) does not deeply penetrate the groove, there should be very little risk of record harm. Additionally, use of the Nylon brush 'wet' mitigates developing static that could occur if used 'dry' because of the strong triboelectric effect (recall **Figure 25**) that would occur between the positively charged Nylon and the negatively charged record. Note that a brush that has been used 'dry' may over time develop Nylon bristles with a chiseled or elliptical tip that could deeply penetrate the groove.
- XII.5 The two-step final rinse that first uses tap water to remove the Dow™ Tergitol™ NID cleaning solution and then uses Purified (distilled/demineralized) water to remove the tap-water mimics the steps used for many precision aqueous cleaning processes. Following final cleaning with chemistry, a two-step cascading (filtered & demineralized) two-tank rinse is generally used. The first final rinse (often an ultrasonic tank) uses Purified-water to remove

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

residual final cleaner, while a second final rinse (cascading into the first rinse) is performed with Pure-water to remove the Purified-water and any contaminants and achieve final cleanliness free of residue. So, depending on the required cleanliness level, the first final rinse is generally one step less quality than the second final rinse.

- XII.6 Rinsing is crucial and so is not physically handling the item being cleaned. Absent the record label protector/handle and the three rinse steps in **CHAPTER V. MANUAL CLEANING PROCESS;**, the probability of achieving particulate cleanliness Level 50 is low. The paper *Rudimentary Cleaning Compared to Level 300A Christina Y. Piña Arpin, Joel Stoltzfus, 2012 (12)* showed how a very simple cleaning process (less rigorous than **CHAPTER V. MANUAL CLEANING PROCESS:**) was able to achieve NVR cleanliness Level A. However, cleaning that required the operator to handle the item being cleaned (including a 6" x 6" x 0.25" thick aluminum disc) could barely achieve NASA particulate cleanliness Level 300 (0 particles > 300 microns; 3 particles from 250 to 300 microns; 93 particles from 100 to 250 microns; and no limit on particles < 100 microns; no silting allowed). The take-away is that removing organic contamination is easy, removing particles is the challenge. Some items to consider.
- XII.6.a As previously indicated **paragraph VI.11** there is an entire science on the removal of particles from surfaces. Summarizing; the smaller the particle the more difficult it is to remove from the surface, and consequently attempting to achieve particle cleanliness of Level 50 is not simple. The paper *Adhesion and Removal of Fine Particles on Surfaces, Aerosol Science and Technology, M. B. Ranade, 1987 (38)* shows for aluminum oxide particles, the force (acceleration) required to remove a 10-micron particle is 4.5×10^4 g's, a 1-micron particle is 4.5×10^6 g's and a 0.1-micron particle is 4.5×10^8 g's. A simple brush or wipe is not going to get the smallest particles/debris that can 'hide' in the valleys between the groove side wall ridges. As fluid flows past a surface, a boundary layer is developed and depending on its thickness (upwards of 5 microns) it will essentially shield any particles within it. So, agitation as previously addressed is critical in reducing the boundary layer to expose the surface with its particles to the cleaning fluid and the fluid velocity (shear force) that can remove them.
- XII.6.b The NVR of the cleaner will likely be greater than the NVR being removed from the record, so rinsing away the cleaner is critical. Surfactants (lipophilic tail) essentially bond to the surface of the vinyl record, so absent an effective water rinse, some surfactant (invisible to the naked eye) will likely be left behind as noted **Table XIII** and will be discussed **paragraph XII.7**. The common water-break test that was discussed **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS:** is not applicable to a record because the record critical surface tension as shown **Figure 30** is less than water. A thin film of surfactant with oil-loving tail-down and water-loving head-up can cause sheeting/wetting. So, for a record, the final spray DIW rinse should show water beading-up as indicated **Figure 19**, but this may only indicate the record surface and not what is in the groove. If an excessive quantity of NVR is left behind, as addressed **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:** it

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

may be noted as dulling of sound from the record, or a build-up of 'gunk' on the cartridge needle/stylus.

XII.7 To emphasize the ability of surfactants to bond to surfaces, the following examples are provided. The lessons learned is avoid excessive concentrations of cleaning agents – using too much will do more harm than not using enough.

XII.7.1 During the implementation of *MIL-STD-1330D*, a manufacturer was experiencing frequent failure of the final clean step. Final cleaning was with a clear, alkaline, non-foaming solution filtered to 0.5 micron (absolute) that as part of cleanliness verification a sample was taken and checked for foam. If the final cleaner foamed, it indicated that the rinse step after pre-cleaning was not successful, and pre-cleaner was being carried over to the final clean step – contaminating the final cleaner. The final clean step was intended to only remove very fine particulate and thin non-foaming mineral-based films. The pre-clean step was using a commercial cleaning agent diluted per the vendor application notes to 10% (10:1) followed by a Purified-water ultrasonic rinse. To pass through the final clean step without it foaming, the pre-cleaner dilution had to be changed to 2% (50:1).

XII.7.2 In the presentation BASF™ *Compatibility of Nonionic Surfactants with Membrane Materials and their Cleaning Performance*, Dr. Arend J. Kingma, Sepawa Nordic 2014, various non-ionic surfactants were used to clean small silicon wafers or glass plates coated with polyethersulfone and polyamide-12 (Nylon) to test for residue. Each wafer was dipped for 10 minutes in a 0.025% (250 ppm) surfactant solution, rinsed with water and dried. Although not specified, the fragility of the wafers could have prevented an aggressive rinse step. The testing was to show that membrane filters could be cleaned with nonionic surfactants without leaving excessive residue.

XII.7.2.a Most nonionic surfactants such as Dow™ Triton™ X100 left a uniform residue of about 0.1 mg/ft². BASF™ DEHYPON® LS 54 was tested with Nylon, and the residue thickness was 0.15 mg/ft². But, some low-foaming nonionic surfactants (none as recommended for use in this document) that are not very soluble with water showed residues levels 5X higher that would equal 0.5 mg/ft² (0.05-micron thickness). The concern here being formulations using anti-foaming agents such as insoluble Dow™ Tergitol™ 15-S-3 that are likely to leave residue that may be audible.

XII.7.2.b One item to note is that polyethersulfone and polyamide-12 are hydrophilic and will absorb water; so, some baseline weight could have been associated with moisture. Additionally, when rinsing, the 0.025% concentration would have benefited those surfactants with higher CMCs such as Dow™ Triton™ X100 which with a CMC of 189-ppm would have been used at <2X the CMC while BASF™ DEHYPON® LS 54 with a 10 ppm CMC would have been used at 25X the CMC.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XII.8 The drying process with first using the lint-free PVA sponge and then the very fine/soft Kinetronics™ anti-static microfiber cloth is intended to mostly wick the moisture from the surface. Like the rinse process it's a 2-step process first removing the bulk moisture with the lint-free PVA high absorbency sponge then near completely dry with a thin mostly lint-free, anti-static cloth. Leaving a very thin moisture film on the record prevents developing any static charge. Overall, this improves the drying time to just a few minutes, and since it is performed with very little pressure, the drying material should not penetrate the groove minimizing depositing small particulate or any chance for record harm.
- XII.9 The final few minutes of drying in a still air environment minimizes fine lint/particulate or ambient volatile organics depositing on the record. Use of forced air drying without HEPA filtration risks contaminating the record surface/grooves with airborne lint and particulate.
- XII.10 **Reality Check:** A review of *MIL-HDBK-407 (40)* would indicate that the level of background contamination in a commercial or residual environment and that produced by the human (*the Peanuts™ character Pig-Pen™ is not too far off*) can be smaller than the record groove detailed in **CHAPTER I. VINYL RECORD CLEANING CHALLENGES:**. Attempting to achieve a **Table X** particulate cleanliness Level 50 even in the most basic Class 100,000 cleanroom (100,000 particles >0.5 microns/ft³ of air, and 700 particles >5 microns/ft³) can be a challenge, let alone in a mostly uncontrolled commercial or residential environment.
- XII.11 However, the cleaning process in **CHAPTER V. MANUAL CLEANING PROCESS:** is performed mostly wet with liberal use of flowing water. During this wet-time, the record is essentially protected from the ambient environment. It is only during the final drying process that the record is at risk and the record mostly aligned vertically during the limited drying time minimizes the risk from airborne contaminants. Additionally, if the local area where the record is being clean is cleaned of visible particulate to a visual cleanliness level of VS+UV (white light & blacklight) then a temporary clean area can be established. Adding a room or desk-top HEPA air filter as addressed **CHAPTER V. MANUAL CLEANING PROCESS:** should maintain the background airborne contamination low. Combine these elements with the cleaning process likely being performed in a residential kitchen that is manufactured of mostly hard, non-shedding surfaces, and the goal of achieving a **Table X** initial cleanliness Level 50A should be possible. There will be some degradation during subsequent play, but this should be minimal and acceptable with maintenance of cleanliness as specified **CHAPTER VI. MAINTAINING CLEANLINESS:**.
- XII.12 The manual cleaning process detailed herein has a very low life cycle cost, with cost of cleaner solutions and distilled water less than \$0.05 per record. Very little cleaner is used per record. One quart of Alconox™ Liquinox™ will prepare about 100 liters of solution and using only about 50 mL per record can clean 2,000 records. One pint of Dow™ Tergitol™ 15-S-9 will prepare about 500 liters of solution, and using only about 50 mL per record, can clean 10,000 records. Very little distilled water is used per record. The PVA sponge and drying cloths are only used to remove distilled water so there should be no need to wash. The sponge is just

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

squeezed-out and stored wet, and the cloth(s) are just hang-to-dry and shake before use. Additionally, the equipment is not subject to any appreciable wear. If using disposable nitrile gloves that can cost about \$0.20/each, these will be the highest cost item. If you buy the next larger size, they can be reused a number of times.

XII.13 The final chapters of this document will discuss machine assisted cleaning methods: vacuum record cleaning machines (RCM) and ultrasonic cleaning machines (UCM). It's important to consider that machines are generally developed for two primary reasons – reduce labor and improve process efficiency. Process efficiency can mean faster (higher throughput) and/or higher probability of achieving quality or achieving a quality that manual labor cannot produce. Manual cleaning in the appropriate environment with appropriate controls can achieve impressive levels of cleanliness, but the labor, skill, time and probability of success generally make it impractical for manufacturing environments. But for the home audio enthusiast; depending on your attention to details, adopting machine assisted cleaning may or may not yield a cleaner record. However, the ease of use and convenience provided by machines can be very enticing and cannot be denied.

REMAINDER OF PAGE INTENTIONALLY BLANK

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

CHAPTER XIII. DISCUSSION OF VACUUM RECORD CLEANING MACHINES:

One machine-assisted vinyl record cleaning process that has been in use for decades is the vacuum record cleaning machine (RCM). There are a variety of vacuum-RCMs available from many vendors such as Record Doctor™, VPI™ (see **Figure 43**), Clearaudio™, Nessie Vinylmaster®, Nitty Gritty™ and Keith-Monks™ (see **Figure 44**) and Loricraft™ with costs that vary from as little as \$200 to over \$4,000 with a wide range of construction and features. **Table XIV** presents some major design features than can be found with vacuum-RCMs with the cost proportional to the features provided.

Table XIV
Vacuum-RCM Features

Feature	Variations	Notes
Vacuum Location	Bottom	Nitty Gritty™ & Record Doctor™ are examples of this design. They tend to be physically compact less than the dimensions of the record and inherently simple. Cleaning solution and rinse water cannot be sequentially applied while vacuuming. Some Nitty Gritty™ users report cleaning the record off the unit and then using it to dry the record.
	Top	Clearaudio™, VPI™, Keith Monks™ & Loricraft™ are examples of this design. Their dimensions are similar to that of the record. They have the benefit that cleaning solution and rinse water can be manually applied sequentially while vacuuming.
	Top & Bottom	Clearaudio™ Double Matrix Professional Sonic is an example of this type design where vacuum is applied both top and bottom.
Air Vacuum Source	Blower	Clearaudio™, Nitty Gritty™, Record Doctor™ & the VPI™ MW-1 Cyclone shown Figure 43 are examples. Blower designs will vacuum across the entire radius of the record. This design uses lots of air flow with very little vacuum (a few inches of water). The use of a blower is the most common and are the noisiest. Some units such as the VPI™ are legendary for their service life with many exceeding 20-years.
	Pump	Keith Monks™ & Loricraft™ are examples of this design shown Figure 44 . A groove point-nozzle is used with a vacuum pump. The vacuum pump draws much less air than a blower but draws a relatively low vacuum of about 20" Hg. These designs are therefore much quieter and generally more expensive than blower designs.
Method of Rotation	Manual	Nitty Gritty™ & Record Doctor™ are examples of this design. This design is the least expensive.
	Motorized	Clearaudio™, VPI™, Keith Monks™ & Loricraft™ are all examples of this design. A motor is used to rotate the record and higher cost units will have a reversible function to improve cleaning example shown Figure 43 . The Keith Monks™ & Loricraft™ units with the point-source vacuum nozzle spin at a faster speed than those with the

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Feature	Variations	Notes
		blower vacuum source and users report they cannot soak a record without fluid flinging off the record.
Cleaning	Manual	Clearaudio™, Nitty Gritty™, Record Doctor™ & VPI™ are examples. The user applies cleaner and rinse water manually.
	Semi-Auto	Clearaudio™, Keith Monks™ & Loricraft™ are examples. The unit has a semi-auto cleaner dispensing system. Depending on platter speed, the user may or may not have much opportunity to manually work the fluid while it is rotating.
	Fully Auto	Clearaudio™ Double Matrix Professional Sonic is an example of this type. The user mounts the record and the unit will clean and dry automatically without any further user interaction.



Figure 43 – VPI™ MW-1 Cyclone Vacuum-RCM
(image by permission of VPI™)

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021



Figure 44 – Keith Monks™ Vacuum-RCM
(image by permission of The Vinyl Press™)

Disclaimer: I do not own a vacuum RCM, and therefore no performance comparison has been made between the manual cleaning process of **CHAPTER V. MANUAL CLEANING PROCESS:** and vacuum-RCM. However, since the first edition of this paper, I have assisted a number of people using vacuum-RCMs with the successful use of Alconox™ Liquinox™ as the pre-cleaner and Dow™ Tergitol™ 15-S-9 or ILFORD™ ILFOTO™ as the final cleaner; and the lessons learned are discussed herein.



Be advised that some vacuum-RCM manufacturers may void the warranty if not used with their approved chemistry and this should be made clear in their literature. The formulas addressed in this chapter should not be harmful with vacuum RCMs and have been used with Loricraft™ and VPI™ units. However, some specialized units may be very sensitive to any foam, in which case, use the manufacturers supplied cleaning agent.

XIII.1 A key difference between the manual cleaning procedure of **CHAPTER V. MANUAL CLEANING PROCESS:** and vacuum-RCM, is the difference in cleaner concentration/ volume and rinse water volume that can be used. The manual clean procedure of **CHAPTER V. MANUAL CLEANING PROCESS:** has almost no limits. Any excess cleaner just drips off into a sink and there is a near infinite source of tap-water for initial rinsing. In comparison, vacuum-RCM have inherent design limits to the amount of cleaning agent and rinse water that can be applied otherwise the unit can be flooded and damaged. Additionally, because of limits with

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

the amount of rinse water that can be applied, lower cleaner concentrations are preferred to control foam and get better rinse efficiency.

- XIII.2 There are many vacuum-RCM cleaning products advertised as essentially pre-cleaners, and there are reports of excellent results with vacuum-RCM. I make no assessment and refer readers to the manufacturers and various audio forums for best practices and recommendations. Vacuum-RCMs that provide forward and reverse rotation will provide the best performance for similar reasons addressed **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:** for forward/backward flushing. The use of enzymes as pre-cleaners is offered by some manufacturers and these have the benefit of being able to essentially dissolve applicable contaminants by simple soaking using little volume – whereas surfactants perform best when very wet and assisted with agitation.
- XIII.3 If using vacuum-RCM for a pre-clean step, and if using the same brush for pre and final clean, rinse the record brush separately before any follow-on step to ensure pre-cleaner is not on the brush. In this instance first rinsing with tap water to remove the cleaner and then a quick spray with DIW or dip in a bowl filled with DIW can work.
- XIII.4 The following pre-clean/rinse/final clean/rinse/dry process using the Alconox™ Liquinox™, Dow™ Tergitol™ 15-S-9 and ILFORD™ ILFOTOL™ chemistry has been successfully used by persons with vacuum-RCMs such as the VPI™ models and the Loricraft™ PRC-4. For records that are not exceptionally dirty, the pre-clean process can be deleted. The process mimics the process in **CHAPTER V. MANUAL CLEANING PROCESS:** except it substitutes a vacuum-RCM and reduces the CLEANER and NID concentration to minimize foam and improve rinse efficiency.
- XIII.4.a Pre-clean exceptionally dirty records with Alconox™ Liquinox™ at 0.5% (5 mL/L) - vacuum but do not fully dry. Depending on the record condition, two pre-clean steps may be required. Although the Alconox™ Liquinox™ will foam, most of the foam is collected in the brush as noted **Figure 15**.
- XIII.4.b Rinse pre-cleaner with DIW - vacuum, but do not fully dry.
- XIII.4.c Final clean with Dow™ Tergitol 15-S-9 at 0.05% (0.5 mL/L) or ILFORD™ ILFOTOL™ at 1% (10 mL/L) - vacuum and do not fully dry. There will be some foam as noted **Figure 17**, but most of the foam will be in the brush.
- XIII.4.d Rinse final cleaner with DIW - vacuum and fully dry. When drying be careful of drying too long that can cause static to form.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIII.5 A possible concept for vacuum RCM is to design a record label protector such as the VinylStack™ or Groovemaster™ that could couple to the vacuum-RCM with a magnetic coupling (and a hexagonal shaft to avoid rotational slip) to allow moving the record from the manual cleaning procedure specified **CHAPTER V. MANUAL CLEANING PROCESS**: directly to the vacuum RCM for drying.
- XIII.6 A final thought on the subject of vacuum-RCM is drying. As previously addressed **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA**;, the normal residential environment contains thousands of invisible small particles per cubic-foot of air. The UV blacklight specified **Table I** if purchased would show an amazing amount of particulate on all surfaces. The high velocity air used by blower designs as part of the drying process draws unfiltered air across the record surface. The vacuum-RCM wet-brushes/pads should collect a lot of the airborne particles. But, if the cleaner(s) have not been fully rinsed and the invisible particles are collected by the surfactant residue – essentially a sludge will form. As a concept for those vacuum-RCMs with lids such as the VPI™ models (example **Figure 43**), modify the lid to add a replaceable fine particulate air filter such as the 3M® Filtrete™ Healthy Living Air Filters (MERV ratings 12 to 14) that have dimensions as small as 12"x12". The large filter area would minimize pressure drop, and this could allow quick drying (with lid closed) with filtered air to prevent drawing-in and depositing airborne lint and particulate. Air filters that rated in Minimum Efficiency Reporting Values (MERVs) will have performance as specified **Table XV** that was obtained from the Environmental Protection Agency (EPA) (15).

Table XV
Air Filter Ratings

MERV Rating	Average Particle Size Microns	Filter Efficiency
1-4	3.0 - 10.0	Less than 20%
6	3.0 - 10.0	49.9%
8	3.0 - 10.0	84.9%
10	1.0 - 3.0 3.0 - 10.0	50% to 64.9% 85% or greater
12	1.0 - 3.0 3.0 - 10.0	80% to 89.9% 90% or greater
14	0.3 - 1.0 1.0 - 3.0	75% to 84% 90% or greater
16	0.3 - 1.0	75% or greater

NOTE: High efficiency particulate air [filter] - HEPA; is a type of pleated mechanical air filter. As officially defined by the U.S. Dept. of Energy, this type of air filter can theoretically remove at least 99.97% of dust, pollen, mold, bacteria, and any airborne particles with a size of 0.3 microns (µm).

CHAPTER XIV. DISCUSSION OF ULTRASONIC CLEANING MACHINES:

One power-assisted vinyl record cleaning process that is gaining wider acceptance and is the source of many audio forum discussions is ultrasonic cleaning machines (UCM). A UCM can be assembled by the user as a DIY or semi-automated and fully automated products are now available from a variety of vendors.

Disclaimer: I do not own a UCM, and therefore no performance comparison can be made between the manual cleaning process of **CHAPTER V. MANUAL CLEANING PROCESS:** and UCM. The following discussion is provided based on my experience with UCMs used for industrial precision aqueous cleaning, and since the first edition of this paper, I have assisted a number of people using UCMs with the successful use of Dow™ Tergitol™ 15-S-9 and other final cleaners; as well as UCM bath recycling, and the lessons learned are discussed in this chapter.

XIV.1 Ultrasonic cleaning has been used for decades. The precision cleaning processes detailed by *MIL-STD-1330D* and *MIL-STD-1622B* address UCMs cleaning. However, recalling **CHAPTER I. VINYL RECORD CLEANING CHALLENGES:** and **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:**, the particle cleanliness level for a vinyl record needs to address less than 5 microns. This presents a unique challenge since UCM operating frequency will influence cleaning effectiveness. The book *Particle Adhesion and Removal 2015* (53), has a large section on nothing but ultrasonic cleaning. The following is a quick summary of ultrasonic cleaning:

XIV.1.a The basic principle is that ultrasonic sound waves can produce bubbles that will grow until they collapse and the associated event is termed 'cavitation' as illustrated **Figure 45**. The energy associated with cavitation is known by any motor boat owner who has experienced propeller pitting/wear from cavitation, and the same phenomenon can be experienced with centrifugal pumps. For ultrasonics there is a minimum power (wattage) necessary to produce cavitation. The higher the frequency, the more power is required. The minimum power required at 40 kHz is reported between 0.3 and 0.5 W/cm² (per transducer radiating surface). As the UCM tank volume increases, less power, measured as W/gal or W/cm³ is required to maintain cavitation throughout the tank. A very small 0.5-gal/1.9-L 40-kHz tank may require 125 W/gal while a 12.75-L/3.4-gal 40-kHz tank may only require 80 W/gal; noting that as the ultrasonic kHz increases so does the power required. There is a limit to increasing power above which no additional benefit is obtained.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 45 – Fundamentals of Ultrasonic Cavitation

(Image from NASA)

XIV.1.b The lower the ultrasonic frequency, the larger the bubble that is created. A 40 kHz UCM will produce bubbles about 75 microns diameter. These are not going to get into the record groove. A 120 kHz UCM will produce bubbles about 20 microns and these can get into the groove. But the larger bubble can produce more energy when it collapses/implodes (cavitation) so there is fluid agitation around the collapsing event that can provide cleaning. How violently the bubble collapse is determined by the amount of power provided by the ultrasonic transducers. A low power 40 kHz unit may be safe for soft metal such as jewelry, while a 40 kHz high power unit may not. The smaller bubble by its size is limited to how violent it can collapse. A high powered 120 kHz unit has less potential for damage than a high powered 40 kHz. As the frequency increases well above 250 kHz, cavitation pretty much disappears replaced by 'acoustic streaming'. The fluid velocity produced by the acoustic streaming is what then does the cleaning; and the target velocities are not much different than those developed for pipe/tube flushing addressed **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:**

XIV.1.c Further complicating the effectiveness of ultrasonics is the fluid boundary layer. The fluid flow at the record (or any) surface develops a static layer that is separate from the bulk fluid that is moving. The boundary layer thickness is dependent on the ultrasonic frequency (high kHz = thinner boundary layer), acoustic energy, and fluid properties (viscosity & density). To get the most effective cleaning, the cleaning process has to penetrate the boundary layer to remove the soil and particles that are contained within it. This concept is also applicable to pipe flushing and was addressed **CHAPTER XI. DISCUSSION OF CLEANLINESS CRITERIA:** At 40-kHz, the boundary layer can be as thick as 5 microns, while at 120-kHz, the boundary layer can be as thick as 2 microns.

XIV.1.d So, fundamentally, following the logic, lower frequency units (40 kHz) are good for larger soil surfaces and particles while higher frequency units (80-132 kHz) are better at removing smaller particles as illustrated **Figure 46**. There are UCMs that provide dual

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

frequencies. The Elma™ (<https://www.elma-ultrasonic.com/en/>, Elmasonic P-series laboratory grade, tabletop, ultrasonic units have a micro-processor controlled dual frequency that can produce 37-kHz or 80-kHz. Zenith™ (www.zenith-ultrasonics.com) manufacturers industrial ultrasonic systems including benchtop units with a patented dual frequency design (called Crossfire™) that uses separate transducers to simultaneously produce 40-kHz and 80-kHz.




Figure 46 - UT Tank Frequency Cleaning Guide

(Image courtesy of Blackstone-Ney Ultrasonics™)

XIV.1.e Many ultrasonic tanks advertise they have a “sweep frequency” function. The “sweep frequency” function modulates the main ultrasonic frequency about +/- 1 to 2 kHz. This ensures the ultrasonic energy is more evenly distributed throughout the tank by preventing standing waves from a fixed frequency that can lead to low energy zones in the tank.

XIV.2 Beyond the mechanics of ultrasonics, the fluid being sonicated has a profound effect on the cavitation energy and the overall cleaning efficiency. From the book *Particle Adhesion and Removal 2015* (53), and the paper *Parametric Study for High-Frequency, High-Intensity Ultrasonics in Removal of Sub-Micron Particles*, Vetrimurugan, J. Michael Goodson, and Terry Lim, *International Journal of Chemical Engineering and Applications*, Vol. 6, No. 1, February 2015 (67), the following are some of the variables with the fluid.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIV.2.a **Temperature:** For water, beyond about 40°C/104°F, the cavitation intensity can decrease. But, for lower kHz (60-kHz) cleaning efficiency can increase by about 10% up to about 60°C/140°F. However, for higher frequency (132- kHz) units, cleaning efficiency peaks at 40°C/104°F and then decreases rapidly.
- XIV.2.b **Flow Rate:** For recirculated/filtered tanks operated during ultrasonic cleaning, the optimum flow rate is about 25% of the tank volume. A flow rate equal to 50% of the tank volume is acceptable, but any greater and the cavitation intensity can decrease quickly.
- XIV.2.c **Surface Tension & Vapor Pressure:** As the fluid surface tension drops less power is required to develop cavitation, and more cavitation bubbles are developed, but with less cavitation intensity, but cleaning efficiency increases. As vapor pressure (boiling point) drops, such as when using a solvent, the cavitation intensity can drop if the fluid density decreases. The density of the fluid affects the cavitation intensity. A denser fluid (such as water) is essentially stiffer and allows a higher pressure to develop in the cavitation bubble which upon implosion releases more energy. So, there is a trade-off with the chemistry of the fluid. But chemistry can bring a host of other problems if not careful, such as fire and explosion hazards if using flammable solvents (i.e., alcohol), and residue if using high concentrations of surfactants
- XIV.3 The following is some guidance that has been used for ultrasonic cleaning beyond the basics such as degassing and were sourced from *MIL-STD-1330D (42)*, *NASA LPR 1740.5F, Procedures for Cleaning of Systems and Equipment for Oxygen Service, 2015 (48)* and *Ultrasonic cleaning: an historical perspective Mason, T.J. 2016 (37)*.
- XIV.3.a *(MIL-STD-1330D) Generator power per radiated surface of at least 3 watts/in². The power per radiated surface area can be determined by dividing the total generator power by the surface area of tank bottom or side where the generator transducers are located.*
- XIV.3.b *(MIL-STD-1330D) When cleaning non-metallic/elastomeric parts limit duration to 10 minutes; but not less than 5-minutes.* The general industry guidance for all materials is 2-10 minutes. A maximum time of 20 minutes is addressed, but generally as indicating that the process has a weakness in one of the parameters such as the cleaning agent, ultrasonic power or ultrasonic frequency.
- XIV.3.c *(NASA) The sum of the parts cross-sectional area should not exceed 75% of the tank cross-sectional area.* The tank cross-sectional area is associated with the surface where the transducers are mounted. For bottom mounted transducers, the cross-sectional area is the tank length x width, and the record shows only its width x thickness (12" x ~0.1"). For side mounted transducers, the cross-sectional area is the tank height x length and the record shows its width x height (about 0.67 ft²/record) for a much larger cross-section. This suggests why stacks of multiple records "can" be cleaned with a UCM with bottom mounted transducers, but with some loss of efficiency.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIV.3.d *(NASA) For most effective cleaning, total parts weight should not exceed 0.351 kg/Kw of generator power, even though a slightly higher weigh to Kw ratio can be accommodated. If an ultrasonic tank has only 200 W power, then by this direction the total weight should not exceed 70 grams which would be only about 40% of a 180-gram record which is not much more than one record in an ultrasonic tank. The implication is that when cleaning a stack of multiple records there is likely some compromise.*
- XIV.3.e *(NASA) Parts positioning, important in most cleaning operations, is doubly important in ultrasonic cleaning. If possible, critical areas to be cleaned should face the transducer(s). This is intuitive except consider that Industry often cleans complex shapes with inaccessible areas; whereas the record in comparison is a relatively simple shape with no inaccessible surfaces.*
- XIV.3.f *(NASA) Non-rigid plastics absorb ultrasonic energy and can produce a shadowing effect. This can be an issue when cleaning many records at once such as the stacked capability of the VinylStack™ Ultra Sonic Spin (Figure 47), and other similar commercially sold units. Shadowing will depend on where the ultrasonic transducers are located. Vinyl records whose low-density material is about 22 g/in³ (compared to 127 g/in³ for stainless steel) will absorb ultrasonic energy. The current record spacing guidance appears based on various qualitative observations. There are ways to evaluate UCM performance based on testing for cavitation. There is the qualitative aluminum-foil test for cavitation, but it has limitations and the reader is directed to <https://techblog.ctgclean.com/> search “aluminum foil” for information. There is the SonoCheck™ [Healthmark Industries - Cleaning Verification - SonoCheck](#) that is used to qualitatively verify cavitation intensity (*suitability for stacked record cleaning unknown*). There are quantitative ultrasonic cavitation meters such as <https://sonicmeter.com/>. However, the cost of ultrasonic cavitation meters makes purchase by an individual for one time use impractical.*



- XIV.3.g UCMs should not be used with any flammable liquids unless explosion proof in accordance NFPA 70 NEC, and recall from **Figure 31** that IPA at about 10% is considered flammable by the NFPA, and at about 7% can still produce explosive vapors. Any use of IPA in a UCM should not exceed 2.5% to avoid any fire and explosion hazard noting that some UCM users are operating as high as 45°C/113°F.
- XIV.4 Readers are directed to *Ultrasonic Cleaning Fundamental Theory and Application*, F. John Fuchs, Blackstone Ultrasonics, 1995 (31) and the book *Particle Adhesion and Removal 2015* (53) for additional information on ultrasonic cleaning fundamentals. For information, John Fuchs (who sadly passed away Jan-2021) had a blog at <https://techblog.ctgclean.com/>, that has extensive information on ultrasonic cleaning. The study of cavitation energy is on-going, as is its relationship to the fluid being sonicated and the item geometry and particle soil

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

tenacity (for want of a better term). As addressed **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY;** one of the foundations of chemistry is that “**Like dissolves Like**”. Unfortunately, as addressed in the **FOREWORD**, a single safe high-density solvent to handle the wide variety of soils does not exist, so experiments with different chemistry, fluid parameters and UCM designs continue. Additionally, as addressed **CHAPTER XII. DISCUSSION OF THE CLEANING PROCESS:** there is an entire science on just particle removal. Otherwise, testing has shown that for vinyl record cleaning with UCM, a balance of process, equipment and cleaning solution are required to get the best results.

- XIV.5 **Record rotation speed.** The record needs to be in contact with the fluid and ultrasonics long enough to be cleaned. Accumulated time may not be the same as continuous contact time. Contact time is necessary to clean some soils that are essentially removed layer-by-layer and this will depend on the bath chemistry. The UCM is going to heat up during use if by nothing more than the heating caused by the ultrasonic power. Because of the heat, if using a relatively high cleaner concentration time may have to be limited so that no part of the vinyl record is in continuous contact with the cleaner for greater than about 5-10 minutes because of material compatibility (ref: **CHAPTER X. DISCUSSION OF MATERIAL COMPATIBILITY;**). If using only DIW, then extended contact time is generally required for the process to be effective. The following are some options for rotating speed.
- XIV.5.1 If using a low-residue bath (low concentration cleaner with low NVR), where there is no concern for cleaning solution drying in-place, a very slow rotation speed is an option. Targeting that the record will have a continuous exposure time of about 2-3 minutes, and with only about 33% of the record exposed at any time, a single rotation time of about 6-9 minutes (0.17 to 0.11 rpm) could be an option as could doubling the time 12-18 minutes to ensure equal exposure.
- XIV.5.2 If using a high-residue bath (high concentration cleaner with high NVR), where there will be a post-rinse, the rotation speed can be faster since there is more chemistry, but it also needs to be faster to prevent cleaner drying in-place. In this circumstance, the record will have an intermittent exposure and the rotation time should be adjusted to obtain an equal number of rotations (i.e., no fractions) but at an accumulated time of 5-10 minutes. Calculate the time = (number of rotations)/(rpm) so for examples (5 rotations)/(0.6 rpm) = 8.333 = 8 min 20-sec; while (4 rotations)/(0.4 rpm) = 10 min.
- XIV.5.3 Record rotating speed can be too fast. Recalling **paragraph XIV.2.b**, if the rotating speed develops a flow rate equal to 1/2 the tank volume per minute, cavitation intensity will decrease and maximum benefit of ultrasonics will not be obtained. What is the rpm threshold? That would depend on the number of records (the stack) being cleaned simultaneously and the tank volume. However, a very simplified analysis shows that as a record moves 1-rpm through the fluid it moves about 1.0-liter of fluid with it. The calculation is as follows:

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

XIV.5.3.a Assume 0.333% of the record is in contact with the fluid and recalling (**paragraph XI.2.e**) the record (minus label) per side is 1-ft², so at any time 0.67-ft² are in contact with the fluid.

XIV.5.3.b Assume that as the record rotates, it will agitate a film of fluid 0.25-inch thick on each side. Therefore, as the record rotates, the volume of water that is agitated = (0.67-ft²)(144-in²/ft²)(0.5-in) = 48.25-in³ = 0.8 mL.

XIV.5.3.c However, the faster the rotation, the more fluid is moved because of drag, so a 25% factor is applied for uncertainty to yield a simple thumb-rule that the rotating record is agitating/moving 1 liter of fluid; and a rotating speed of 1-rpm = 1-lpm.

XIV.5.3.d Example: The Kuzma™ RD Kit is often used with the Elmasonic™ P 120-H ultrasonic tank that has a volume of 12.75 liters. If cleaning 10 records at a time, and using the thumb-rule 1 rpm = 1 lpm, the maximum speed for 50% tank flow is (12.75L)(0.5)/(10 records)(1 lpm/rpm) = 0.64 rpm which is right at the maximum speed (0.6 rpm) of the Kuzma™ RD Kit. So, the derivation and use of the thumb-rule 1 rpm = 1 lpm appears valid for this application noting the Elmasonic™ P 120-H is a very well manufactured unit with a lot of power about 100 watts/gallon.

XIV.5.3.e However, if the ultrasonic tank is being filtered, then the flow rate of the pump has to be added to the flow generated by the record rotating and the final equation is as follows:

$$Rrpm = \frac{(V)(0.5 - Q/V)}{(N)(K)}$$

Where: Q = pump flow rate (gpm or lpm)
K = thumb-rule 1 lpm/rpm
N = number of records
Rrpm = maximum record rpm
V = tank volume (gals or L)

Example: Single record in a 6.5-L tank, with 2.8 lpm pumped filtration. (6.5-L)(0.5-2.8/6.5)/(1 record)(1 lpm/rpm) = 0.5 rpm

XIV.5.3.f In cases where the pump should not be operated, then there are two options to operate the filter between record cleaning cycles. One option is to install a large recirculating pump to reduce the tank 1/2-life (see **paragraph XIV.15.1**) or install a holding tank to do batch filtration (see **paragraph XIV.15.3**). Batch filtration is 100% efficient and much faster.

XIV.5.4 For information, the VinylStack™ Ultra Sonic Spin – Record Cleaning Kit can clean up to 4 records at a time with a convenient magnetic clamp design, and provides a rotation speed

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

variable from 0.14 to 0.67 rpm. Note: The ultrasonic tank in **Figure 47** is for representation only (it is a USA manufactured Sharpertek™ unit <https://www.sharpertek.com/tale7to24.html>). VinylStack™ does not sell ultrasonic tanks, and I makes no assertion as to the correct spacing of the records in **Figure 47**. Another source for a high-quality record stack/spinner is the Kuzma™ RD Kit that can clean up to 10 records at a time and rotates at 0.4-0.6 rpm - [RD Ultrasonic Record Cleaning kit - Kuzma Professional Turntables, Tonearms and Accessories](#).



Figure 47 - VinylStack™ Ultra Sonic Spin
(by permission VinylStack™)



Be advised that record specific UCM manufacturers may void the warranty if not used with approved chemistry and this should be made clear in their literature. The formulas addressed in this chapter should not be harmful with these units except for those sensitive to foam which is addressed. However, if in doubt, use the manufacturers supplied cleaning agent.



IPA can cause stress cracking of some plastics such as Acrylic at high concentrations. When preparing IPA solutions add IPA to water.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIV.6 If cleaning only new or relatively clean records - i.e., mostly particulate, there should be no need for a lot of chemistry. The amount of chemistry is based on whether a final rinse will be used. If using only a single UCM for final clean without separate rinse, such as the Degritter™ [Record cleaning machine that is easy to use - Degritter](#) or the Audio Desk Systeme™ Vinyl Cleaner PRO then there is compromise between convenience and ease of use and cleaning efficiency and minimizing cleaner residue. Recall that **Table XIII** shows the cleaner residue film thickness that can remain on the record and subjectively >0.03 microns 'may' be the threshold for hearing the effects. If not using the manufacturer's supplied cleaning agent, the DIY goal is to get the lowest surface tension (such as Dow™ Tergitol™ 15-S-9 at 0.01%) and maybe some detergency (2-3 times the CMC) if foam is not excessive plus a little IPA (2.5%) to help with soil-swell/roll-up recalling **Figure 34** but still be within safe guidelines for flammability. Otherwise, the following are some additional considerations when using a single UCM for cleaning:
- XIV.6.a The large cleaner volume to record surface ratio avoids the chemistry being quickly exhausted by the record NVR (recalling how surfactants work from **CHAPTER VIII. DISCUSSION OF PRE-CLEANERS:**) and by drag-out. But the low concentration may not provide much bath life, and aside from observing sheeting on the record or maybe a 'shake test' to test for surfactant foam there is no easy quantitative method to measure the nonionic solution concentration.
- XIV.6.b Anytime multiple record batches are exposed to the same bath, there is the question of whether the last item (record) is cleaned as well as the first. Using a single bath-charge for cleaning many records will present challenges as oil and particulate build-up in the tank and chemistry is depleted. Also; if use extends for many weeks, bacteria may form. For those with large record collections or those who process a lot of records, purchasing a demineralizer can significantly improve access to and reduce the cost of purified-water as discussed **CHAPTER VII. DISCUSSION OF WATER QUALITY:** If there is a source of readily available cheap purified water, then the bath can be dumped more frequently and the need to add filters/pumps etc. to recycle and extend the UCM bath life can be eliminated. Otherwise, for the DIY's pumped filter systems are addressed later in this chapter.
- XIV.6.c The use of a dual frequency UCM that can produce about 40-kHz followed by about 80-kHz such as the Elma™ Elmasonic P-series or the Zenith™ Crossfire may get the best cleaning from a single-UCM. An article by *John Fuchs* <https://techblog.ctgclean.com/2014/04/ultrasonics-applying-multiple-frequencies-for-maximum-benefit/>, discusses not only the benefits of multiple frequencies but also the possible need for multiple cycles of multiple frequencies.
- XIV.7 **Degritter™ UCM:** The following summarizes some results of various chemistries with the Degritter™ UCM that were addressed at the Steve Hoffman Forum™ [Degritter Users | Steve Hoffman Music Forums](#). The Degritter™ because of how it pumps-down the tank for drying; pumps-down the reservoir for cleaning; and primes on start-up is sensitive to pump

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

cavitation and producing foam so nonionic surfactants that can foam are used at very low concentrations mostly just for 'wetting'. As a general note, the manufacturer supplied cleaning agent is low foam, and users report that for dirty records' multiple cleaning cycles – as many as 3 had improved results.

- XIV.7.a Tergikleen™ at a solution concentration of about 260 ppm (1 mL/1-US-gal) left a residue that was audible and noted as a “veiling” of the music. However, the product produced no foam as expected because of the Dow™ Tergitol™ 15-S-3 which is also a defoaming agent (see **paragraph IX.7** for further details).
- XIV.7.b ILFORD™ ILFOTOL™ at a solution concentration of 0.125% (actual non-ionic surfactant concentration about 62 ppm) with 2.5% IPA. This solution did not leave an audible residue but was problematic because of excessive foam after the first cycle.
- XIV.7.c BASF™ DEHYPON® LS 54 at a solution concentration of about 50 ppm (0.0050%) did not leave an audible residue and did not produce excessive foam. Note that BASF™ DEHYPON® LS 54 at 0.0150% with 2.5% IPA did foam excessively. The 2.5% IPA does lower the solution boiling point/increasing the solution vapor pressure that would increase the risk of pump cavitation.
- XIV.7.d Dow™ Tergitol™ 15-S-9 at a solution concentration of about 150 ppm (0.0150%) and 2.5% IPA did not initially produce foam, but after successive cleaning cycles began producing foam. Reducing the Dow™ Tergitol™ 15-S-9 to a concentration of about 80 ppm (0.008%) and 2.5% IPA significantly reduced foaming and still showed excellent wetting.
- XIV.7.e The Degritter™ tank volume is only about 1400 mL. The surfactant concentrations previously stated were being obtained by 'drops' of surfactant whose volume can be variable. When working with very small concentrations in small volumes such as this, it is better to prepare a diluted concentration of say 1% (10 mL/L) and then proportion from that. The equation shown **paragraph VIII.8.7** is useable. As an example, to obtain 0.008% Dow™ Tergitol™ 15-S-9 using a 1% solution; add = $(0.00008/0.010) \times (1400 \text{ mL}) = 11 \text{ mL}$. Additionally, the sequence of adding nonionic surfactant +IPA to water makes a difference. If you take a small glass container (150-200 mL) and just fill with tap-water, and do the following experiment the following will be observed:
- If IPA (2.5% equivalent) is added first and then add the non-ionic surfactant the surfactant does not immediately break-up, it sinks as a solid drop(s). It will go into solution but it needs to be agitated. As it's agitated, the drop of surfactant break-ups and 'slowly' goes into solution.
 - If 1-drop of non-ionic surfactant is added first, the drop immediately breaks-up and with some agitation quickly goes into solution.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- If adding chemicals individually to the Degritter™ tank that could be a problem. At the very least, add the surfactant as a pre-diluted solution. Otherwise, prepare a gallon of prepared cleaning solution and then fill the tank from that.

XIV.8 But, if the record is exceptionally dirty, such as trying to resurrect a Goodwill® or flea market find, attempting to use a single ultrasonic tank to clean presents a number of challenges because of the variety and concentration of contaminants. Lower UCM frequency and/or more aggressive chemistry is preferred. The record must first be degreased to remove any oil/grease film, otherwise, the underlying or trapped particulate may not be removed. The user has a number of options, but as previously discussed, standard industrial guidance used by nearly every precision aqueous cleaning procedure is pre-clean (degrease/remove visible contaminants), rinse, final-clean (polish), rinse, dry. Additionally, if the goal is extending the bath life of a unit like the Degritter™ or to achieve the best cleanliness, there are a number of options to use UCM as part of a pre-clean/final clean process and these are addressed in the following paragraphs. In all cases, a separate UCM will be used for the final clean step.

XIV.9 **Step 1: Pre-Clean:** A variety of pre-clean methods are listed **Table XVI**. Any number of methods can be combined. Methods 1 and 3 have the benefit that the cleaner is removed/rinsed after use minimizing carry-over to the final clean step. A number of people indicate that they use Method 3 vacuum-RCM for the first pre-clean, albeit many of these people first owned a vacuum-RCM before adding a UCM. Some people whose goal is the cleanest possible record and who have the space and financial resources may use Method 3 vacuum-RCM for the first pre-clean and then use Method 4 UCM as the second pre-clean or rinse.

Table XVI
Pre-Clean Methods

Method	Chemistry	Effectiveness	Labor	Cost	Life Cycle \$	Safety
1. Manual Brush	Alcohol solvent	Dependent on chemistry, brush & operator technique	High	Low	Solvent	Fire
2. Manual Brush	Aqueous		High	Low	Cleaner & Water	Safe
3. Vacuum-RCM	Aqueous		Medium	Medium to High	Cleaner, Water, & Parts; some can last 20 yrs	Noise
4. UCM	Aqueous	Dependent on chemistry & equipment design	Low	Medium to High	Cleaner, Water, Filters, Parts. Low-cost units can fail in <2-yrs	Noise

XIV.9.1 Pre-clean method 1 using IPA and brush is a common addressed item on the many audio forums; and a popular brush is the one that comes with the Audio Technica™ AT-6012 kit. The IPA is applied to the brush bristles or to the record directly.

XIV.9.2 Pre-clean method 2 can be any of the many manual aqueous methods available such as:

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIV.9.2.a One of the many record cleaning brushes and aqueous cleaner kits such as the Audio Technica™ AT-6012 kit or the Discwasher™ Vinyl Record Cleaning System. However, cleaner NVR will likely be carried-over to the final clean step reducing the final clean UCM bath life and the actual performance of these brushes and associated cleaners are debatable as previously discussed paragraphs VI.1 and VI.2.
- XIV.9.2.b Many people pre-clean with the Spin-Clean® record washer [Spin-Clean Record Washers - Shop the Official Spin-Clean Store](#) (or equivalent). These manual spin type bath units have the benefit of not using a large bath so its economical to frequently replace the bath. Using a second unit for rinsing only is an option.
- XIV.9.2.c Or, pre-clean/rinse step from **CHAPTER V. MANUAL CLEANING PROCESS:** which will minimize cleaner carry-over.
- XIV.9.3 Pre-clean method 3 would be similar to **CHAPTER XIII. DISCUSSION OF VACUUM RECORD CLEANING MACHINES:**
- XIV.9.4 Pre-clean method 4. The assumption is that a UCM used for pre-clean will be without post rinsing. This requires balancing the cleaner concentration to minimize the carry-over/drag-out to the final clean UCM. Otherwise, the bath life of the final clean UCM will be shortened, and there are not many cost-effective options to remove excess surfactant with filters. The UCM for pre-cleaning should be a lower frequency 35-40 kHz unit to remove tenacious soil films and large particles. Be advised, that the lower cost 35-40 kHz units can be very noisy and hearing protection may be warranted. The following are some options for chemistry. For those with IPA, the information in **paragraph XIV.7.e** applies.
- Alconox Liquinox at 0.25 to 0.50%
 - Tergitol 15-S-9 at 0.05 to 0.1%
 - Tergitol 15-S-9 at 0.05 to 0.1%% + 2.5% IPA
 - ILFORD ILFOTOL at 0.25 to 0.50%
 - ILFORD ILFOTOL at 0.25 to 0.50% + 2.5% IPA
 - BASF™ DEHYPON® LS 54 at 0.025 to 0.01%
 - BASF™ DEHYPON® LS 54 at 0.025 to 0.01% + 2.5% IPA
- XIV.10 **Step 2 - Final Clean:** Assuming no rinse after final clean with a DIY UCM, similar chemistry discussed for the Degritter™ can be used, but since there should be less risk of foam, slightly higher concentrations can be used. Exposure time should be similar to the pre-clean-UCM so that no part of the vinyl record is in contact with the final-cleaner for greater than 5 minutes. Assuming an exposure time of 2-3 minutes, with only 33% of the record exposed at any time, a total rotation time of about 6-9 minutes would be recommended subject to record rotation previously discussed **paragraph XIV.5** . The following are a couple of options for DIY-UCM chemistry. In all cases the goal is to obtain the best wetting and maybe some micelle formation but not more than about 5X the CMC to minimize the cleaner MVR.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

If using a Degritter™, or equivalent, use the chemistry previously addressed **paragraph XIV.6**; and those with IPA the information in **paragraph XIV.7.e** applies.

- DIW only
- DIW + 2.5% IPA
- Tergitol 15-S-9 at 0.01 to 0.015%
- Tergitol 15-S-9 at 0.01 to 0.015% + 2.5% IPA
- ILFORD ILFOTOL at 0.125 to 0.25%
- ILFORD ILFOTOL at 0.125 to 0.25%+ 2.5% IPA. (Note: This solution is similar to that used by [tima's DIY RCM | What's Best Audio and Video Forum. The Best High End Audio Forum on the planet! \(whatsbestforum.com\)](http://timsdiyrcm.com))
- BASF™ DEHYPON® LS 54 at 0.0025 to 0.005%
- BASF™ DEHYPON® LS 54 at 0.0025 to 0.005% + 2.5% IPA.

XIV.11 **Step 3 - Rinse:** None. However, if using surfactant chemistry, if possible, lightly rinse the record(s) with spray or wash bottle filled with purified water – effluent can just drain into the UCM tank or a separate tray before drying.

XIV.12 **Step 4 - Dry:** There are a number of methods/options for drying discussed as follows, and this assumes a Degritter™ or similar UCM that has a drying feature is not used.

XIV.12.1 If cleaning stacks of records as shown **Figure 47**, most people are leaving the stack assembled and allowed to air-dry in or on a rack.

XIV.12.2 If using Method 3, vacuum-RCM as the pre-clean step, the record can be dried with the vacuum-RCM.

XIV.12.3 If using fans to dry, unless very fine air filters (see **CHAPTER VII. DISCUSSION OF WATER QUALITY: Table VII**) are installed there is risk of depositing very fine, invisible ambient particulate on the record. Simple expandable air filter socks can be of value. But, if using very fine air filters, small 120VAC/60Hz axial fans that are restricted to about 3600 rpm may not develop enough fan static pressure to overcome the resistance of a small fine air filter. However, small high speed 24VDC axial fans are available that can produce as much as 5X the fan static pressure of a 120VAC/60Hz axial fan, the higher noise notwithstanding. These 24VDC fans often are variable using a 0-10VDC signal for speed control.

XIV.12.4 A design option for drying could be a heated/warm, high speed spin-dry. If the UCM bath water was to drain to a reservoir, and a variable speed motor similar to a variable speed hand-drill was used for rotation (with twist-style chuck to secure record stack), and a vented cover lowered for protection, auxiliary UCM heaters could be used to safely perform a quick heated (~35°C/95°F) spin dry. This type of drying process should avoid the need for air filters and minimize the time needed to dry, and 'may' be able to eliminate

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

any post clean rinse. Low wattage (i.e., 25W) silicone heat pads could be used for the air-drying process. Energizing immersion heaters installed for fluid temperature control without water in the tank can cause UCM damage.

- XIV.13 UCM cleaning does present the opportunity to implement a form of cleanliness verification as part of the final-clean step **paragraph XIV.10**.
- XIV.13.a The final cleaner chemistry **paragraph XIV.10** is nonionic; including the IPA. Bath ionic purity – TDS, can be easily monitored. TDS meters such as Extech™ Model EC410 (www.extech.com) with calibration kit can at the lowest range measure with a 0.1 ppm resolution recalling from **Table IV** that new purified water should measure <2.5 ppm TDS. However, in-use, allowing the TDS to increase to 10 ppm; same as Navy Grade B water specified in **Table IV**, should yield acceptable results as implied **Table V**.
- XIV.13.b To check for particulate, obtain about 50 mL sample of the UCM bath water in a clean glass container, and place a piece of white and then black paper behind the container and inspect for visible particulate or turbidity. There should not be any visible particulate and unless very turbid (and this will take some experience), at this point the process has done all it can do. If the sample is very turbid, refresh the tank (or allow time to filter) and reclean. Alternatively, compare the sample to known sample of unused cleaning solution.
- XIV.13.c If using only DIW or DIW + 2.5% IPA, obtain about a 50-100 mL sample of the UCM bath water in a clean clear container. Cap, shake and verify no stable foam - this will verify that there is no foaming pre-cleaner that may have carried-over from the pre-clean step. If final-clean is using any of the surfactants, some foam will develop and this 'shake-test' is not applicable.
- XIV.13.d Note - if you are constantly having to reclean, the pre-clean step needs to be adjusted. It may be the chemistry, the chemistry concentration, the bath life, exposure time, record loading, or the tank Hz and watts. But an occasional (not frequent) reclean generally indicates an efficient process. If you never have to reclean, chances are you doing more than 'required', but that is not necessarily bad.
- XIV.14 **Filtration Systems:** For any UCM there is the option to extend bath life by installing a pumped filtration system. Depending on the bath chemistry there are three basic types of filters that can be used – particulate (commonly called sediment), activated carbon and ion-exchange (demineralizer). If the UCM will use only purified water or Purified water + IPA, all three filter-types are usable. Activated carbon and ion-exchange have limitations with surfactants. If a low concentration of Dow™ Tergitol™ 15-S-9 (0.01 to 0.05%) nonionic surfactant is used to reduce surface tension then only a sediment filter is recommended. To control biologics, instead of chemistry, absolute sediment filters <0.3 micron are effective as discussed **paragraph XIV.19.2** as is compact UV sterilization that is discussed

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

paragraph XIV.22. The following paragraphs discuss some design considerations associated with pumped filtration systems.

- XIV.15 **Pumped Filtration:** Pumped filtration is performed either by single tank recirculation or tank-to-tank batch processing. There are advantages and disadvantages to each. **Table XVII** shows a comparison between the two-types of filtration systems assuming a UCM of 2-gallons capacity. Generally, recirculation is simpler and cheaper; while batch is faster, more efficient, but more complicated and expensive. Items to note:

Table XVII
Batch vs Recirculation Filtration

Parameter	Batch Filtration	Recirculation Filtration
UCM Tank capacity	2-gal	2-gal
Batch Tank Capacity	2.5-gal	Not applicable
Pump Capacity	1.0 gpm	0.5 gpm
Valves	Yes	None required
UCM Drain (pump) Down Time	2 minutes	Not applicable
Filtration Efficiency	100%	97% (five half-lives)
UCM Refill Time	2 minutes	Not applicable
Total Filtration Time	~5 minutes	14 minutes
Cost & Complexity	\$\$\$/##	\$\$/#
Risk of Foam	Moderate depending on pump	Low

- XIV.15.1 Recirculated pump-filtration systems follow an efficiency model that defines the time it takes to filter 50% of the tank, and is calculated as follows:

$$t^{1/2} = \frac{0.693 \times V}{Q}$$

Where: $t^{1/2}$ = time to filter 50% of the tank
0.693 = half-life exponential decay constant
V = UCM tank capacity (gal or liters)
Q = pump flow rate (gpm or lpm)

Example: A 2-gallon tank with 0.5 gpm recirculation pump would take 2.77 minutes to filter 50% of the tank. Five half-lives $(1.0 - 0.5^5)(100)$ will filter 96.875 percent of the total UCM tank. So, it will take about 14 minutes for 97% of the tank fluid to be filtered.

- XIV.15.2 As previously stated **paragraph XIV.2.b**, excessive fluid agitation can diminish the cavitation/cleaning effect of a UCM. If a high flow rate recirculation pump is used, consider energizing only between cleaning cycles to recycle the UCM bath as previously stated **paragraph XIV.5.3.f**.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIV.15.3 Batch filtration is 100% efficient but requires a second tank. The Degritter™ uses batch filtration. Batch filtration can use any size pump. However, pump selection can affect risk of foaming. During pump-down from the ultrasonic tank to the holding tank, or during pump-down of the holding tank to the ultrasonic tank, at the end of the evolution the pump suction will be very low causing centrifugal pumps to cavitate causing foam. On start-up as the centrifugal pump primes again cavitation and foam may develop. Positive displacement pumps are generally more forgiving and some can run dry without damage and self-prime.
- XIV.15.3.a For DIY using a 2-gallon ultrasonic tank, the 'holding' tank could be a 2.5 Gallon Natural Molded Polyethylene Tank with Lid & 1/2" FNPT Fitting - 12" L x 8" W x 10" H; <https://www.usplastic.com/>).
- XIV.15.3.b Use of two 3-way valves as illustrated in **Figure 48** and **Figure 49** could allow one pump to be used to transfer water from the UCM to the batch tank and then transfer water from the batch tank back to the UCM. The water can be filtered to or from the batch tank depending on how it is plumbed – **Figure 49** shows the arrangement for filtering from the holding tank.



Improper alignment of valves can lead to dead-heading a pump. Positive displacement pumps can develop pressures high enough to fail a plastic filter housing and clamp-fittings, and should be ordered with a high-pressure shutoff or provided with an over pressure relief valve.




Figure 48 - Batch Processing - UCM to Holding Tank - Unfiltered

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 49 – Batch Processing – Holding Tank to UCM – Filtered

XIV.16 **Pumps:** The challenge with a recirculation pump will be finding a low flow pump with enough pump head to over-come the pressure drop caused by the filter as it loads with soil. As a general note, the filtration media is located at the pump discharge where the pump discharge head is greatest to overcome the differential pressure that the filter will develop as it loads with particulate. Placing a fine, micron-rated filter at the pump suction will result in excessive pressure drop and the pump will lose suction causing it to cavitate; the technical term is loss of net positive suction head (NPSH). For pump protection all that is required is a simple strainer and these are readily available such as Shurflo™ Model 255-313 strainer.

XIV.16.1 **Centrifugal Pumps:** The most common design is the centrifugal pump, and low-cost units with mechanical seals are readily available. Mechanical seals can leak when operated with a low surface tension fluid such as a water + Dow™ Tergitol™ 15-S-9 mix. Alternant centrifugal pumps with magnetic couplings to the motor (also known as magnetic drive) can eliminate the shaft seal to prevent leakage. Centrifugal pumps follow a pump curve vs flow rate that generally drops significantly as pump discharge head increases; and this is complicated by small 120VAC centrifugal pumps being speed limited to 3600 rpm. For example, a common centrifugal pump used by DIY UCM is the 120VAC Little Giant™ 1-AA-OM Series. This pump is rated 2 gpm at 1-ft (0.43 psi) head, and 0-gpm at 7-ft (3.01 psi). This pump is not really suitable for filtration since it will “dead-head” at 0 gpm long before any micron rated filter is actually loaded with soil. In comparison, the small centrifugal pump BLDC Pump Model DC40-1250 is 12VDC so it can operate at higher rpm, and this pump is rated 2.2 gpm at 1-ft (0.43 psi) head, and 0-gpm at 17-ft (7.4 psi). The representative pump curves for these two pumps are shown in **Figure 50**.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 50 – Centrifugal Pump Curves

XIV.16.2 **Positive Displacement Pumps:** There are low flow, high head positive displacement diaphragm pumps well suited for UCM filtration systems, two readily available examples from SHURflo™ ([Shurflo | Brands | Pentair](#)) are listed below and the representative pump curves are shown **Figure 51**. Positive displacement pump flow rate generally varies very little with pump discharge head. Diaphragm pumps are perfect for batch filtration since they can run dry and with good suction lift do not require priming providing easy installation and use. However, as previously stated, diaphragm pumps can develop pressures high enough to require over pressure protection and these are provided as a ‘demand switch’.

XIV.16.2.a SHURflo Model 8020-513-236 is 115VAC supplied with 3-prong grounded plug and is rated 1.27 gpm at 10 psi head and 1.05 gpm at 30 psi head and comes with a 60-psi overpressure shutoff (demand switch). This pump is self-priming to 10-ft and has 3/8"-18 NPT Female ports. A grounded outlet with ON/OFF switch (and some with integrated circuit breaker) such as [Philips Accessories Philips Grounded Outlet with Integrated Circuit Breaker, ON/OFF switch, Gray, SPP1129GR/37, 1 Pack, Grey - - Amazon.com](#) is a convenient way to add a switch for the pump.

XIV.16.2.b SHURflo™ Model SLV10-AA48 is 12VDC rated at 0.73 gpm at 10 psi head and 0.49 gpm at 30 psi head(max) and comes with a 40-psi overpressure shutoff (demand switch); manual on/off switch and a 2-pin connector. The Model SLV10-AA40 is the same pump without a 2-pin connector. This pump is self-priming to 2.5-ft and is supplied with 3/8-inch barb connectors. This pump will require a separate desktop style 120VAC/12VDC power source rated at not less than 40 watts such as the Mean Well™ Model GST40A12 or GST60A12. This pump’s low flow makes its suitable for smaller volume tanks.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021




Figure 51 – Positive Displacement Pump Curves

- XIV.16.3 All centrifugal pumps will likely need to be located level with the base or beneath the UCM to ensure adequate pump suction head also known as net positive suction head (NPSH). Positive displacement pumps that have much higher suction lift can be mounted above the tank – the height depending on the pump suction lift rating. However, when the pump is turned-off; make sure the tank has enough volume to collect the fluid drain-back without overflowing.
- XIV.17 **Filter Housings:** Common point-of-use filter housing are those designed for 2.5-inch diameter x ~10-inch-long filter cartridges. There are many vendor/models available, however very few low-cost plastic housings have a built-in differential pressure gauge (or equivalent) that can monitor filter soil loading. There is a Pentek™ 3G 10" standard housing (part # 150574) with 3/4" inlet/outlet, with an integral bracket and meter mount cap that is used with part #143549 that is a differential pressure indicator that mounts to the filter cap and monitors filter soil loading/fouling. Otherwise, operating a UCM until the bath solution is cloudy can leave excessive NVR on the record unless some form of additional final rinse is added. Items to note:
- XIV.17.1 Opaque filter housings will have a higher-pressure rating than clear housings and are less prone to cracking.
- XIV.17.2 There are 5-inch filter housings, but these small housings have very limited filter cartridge options.
- XIV.17.3 Filter housing have a specific cartridge end cap design –the commonly used Pentek™ filter housing generally specify “double open ended” – DOE.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- XIV.18 **Filter Cartridges:** Filters are rated absolute or nominal. Absolute rated filters will generally remove not less than 99.5% of all particles greater than the rating. Industry standard nominally rated filters will generally remove about 80% of all particles greater than the rating, and generally have a 95% efficiency for particles about 5X the nominal rating. But some nominal rated filters can have nominal efficiency as low as 30% and the 95% efficiency can be as much as 50X the nominal rating. For absolute and nominal rated filters, the vendor should provide a filter efficiency chart that shows the filter performance.
- XIV.19 **Sediment Filters:** In general, thermally bonded polypropylene particulate/sediment depth filters are preferred for their overall compatibility, superior soil holding and low pressure drop performance, and are generally rated to at least 120°F (49°C) operation. For the precision cleaning of vinyl records, a 1-micron nominal rated filter is the largest recommended; a 0.2-micron absolute filter optimum. When ordering filters make sure the end-caps are compatible with the filter housing. The Pentek™ 3G filter housing specified **paragraph** XIV.17 uses double-open-ended (DOE) cartridges.
- XIV.19.1 A suitable 1-micron nominal example is the Hydronix® Model SDC-25-1010 (or equal) that DOE and at 1-micron is 80% efficient and at 5-microns is about 96.5% efficient. The 2.5" x 9-7/8" filter has a very low pressure drop of 0.6 psi at 5 gpm for a new 10-inch cartridge, has a maximum temperature rating of 145°F (63°C), has a recommended replacement at 21.75 psid and is generally available for less than \$10 from many sources. This filter does come in a 2.5" x 4-7/8" size.
- XIV.19.2 A much finer filter that is readily available is the Flow-Max™ FPP-0.2-975-DOE that is a pleated polypropylene 2.5" x 9-3/4" filter rated 0.2 micron absolute. The initial pressure drop is about 1.5 psi at 1.5 gpm for a new 10-inch cartridge; has a maximum temperature rating of 175°F (70°C); collapse pressure of 130 psid, and the recommended replacement pressure drop is 35 psid. As a general note, filters absolute rated less than 0.3 micron can remove bacteria.
- XIV.19.3 For information, high throughput processes will often install a pre-filter such as a 1-micron nominal to extend the life of expensive very fine (i.e., 0.2 micron absolute) filters. However, the added pre-filter does increase the water flow pressure drop that can impact the pump selection if a centrifugal design, but the positive displacement pumps listed **paragraph** XIV.16.2 would be able to accommodate. Note that at the time of this paper version, a readily available 10-inch 1-micron absolute filter cartridge could not be identified for easy purchase. There are models Hydronix® and Flow-Max™ listed, but none are readily available for consumer purchase.
- XIV.20 **Activated Carbon:** There are 10-inch activated carbon block cartridges such as Pentek™ CBC that are rated 1-micron absolute and flow rated 3.7 psi pressure drop at 1 gpm. These filters could be an alternative to polypropylene particulate filters for water only since they can remove some surfactants. But these type carbon filters have limited soil holding.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

Particulate and debris can foul the carbon block and the high-pressure drop at low flow may make pump selection difficult and expensive making them mostly impractical.

- XIV.21 **Demineralizers:** Purified water left exposed to the ambient (such as a UCM tank) will absorb air and carbon dioxide and form carbonic acid leading to a mild acidification with a pH of about 5-6. Additionally, contaminants from the record may be ionic further degrading the water purity increasing the TDS and risk of NVR.
- XIV.21.1 There are 10-inch mixed-bed ion exchange demineralizer cartridges such as Crystal Quest part #CQE-RC-04011 but these are generally rated for only about 0.5-gpm, and most will have particulate rating near 5-microns nominal, requiring a separate particulate filter be installed downstream.
- XIV.21.2 Most ion exchange demineralizers are limited to 100°F (38°C) operation. This limits continuous operation to unheated UCM cleaning. For heated UCM cleaning, batch filtration or recirculated filtration between heated UCM cleaning cycles could be used. Like carbon filters, these are for water only since they can remove or be fouled by surfactants.
- XIV.22 **UV Sterilization:** If operating tank baths for many weeks/month, biologic control of algae and bacteria, small ultraviolet disinfection units such as Polaris Scientific UV [Residential Archives - Polaris \(polarisuv.com\)](#) UAV-1C and VIQUA™ [VIQUA Home Page - VIQUA](#) UV-1 could be an option and would avoid any need for chemical micro-biological inhibitors. These would be plumbed downstream of the sediment filter, and are very low power 10-14W. Operationally they are rated for 9000 hours, but indicate limited to 104°F (40°C). Note that these units are rated for sterilization which is more demanding than disinfection. UV disinfection is commonly used for large (i.e., 100-gal) aquarium tanks, but these appear designed for lower operating pressures. If installed, energize w/o ultrasonics and just operate periodically (try once/week and adjust as necessary) with pumping only for enough time to disinfect/filter >95% of tank and then secure. No reason to operate when cleaning records which would extend UV bulb life, but having not used these devices, experience may show otherwise.

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

APPENDIX A - LIST OF REFERENCES

The following documents and sources are referenced in this document and are available in the Public Domain or for purchase at the noted internet addresses. Hyperlinks are provided only to secure sites (https://).

- (1) Dr. A. M. Max, *Disc Phonograph Records*, Max, RCA Engineer Magazine 1966-08-09, [1966-08-09.pdf \(worldradiohistory.com\)](#)
- (2) Dr. Arend J. Kingma, *BASF™ Compatibility of Nonionic Surfactants with Membrane Materials and their Cleaning Performance*, Sepawa Nordic 2014 [Title ARIAL bold 30pt \(semanticsscholar.org\)](#)
- (3) Anna L. Fricker, David S. McPhail, Brenda Keneghan and Boris Pretzel, *Investigating the impact of cleaning treatments on polystyrene using SEM, AFM and ToF-SIMS*, *Heritage Sci* (2017) 5:28 [Investigating the impact of cleaning treatments on polystyrene using SEM, AFM and ToF-SIMS \(springeropen.com\)](#)
- (4) ARSC Guide to Audio Preservation, 2015, Library of Congress (<https://www.clir.org/wp-content/uploads/sites/6/pub164.pdf>)
- (5) Astbury, G.R. & Bugand-Bugandet, J. & Grollet, E. & Stell, K.M.. (2005), *Flash Points of Aqueous Solutions of Flammable Solvents*. Institution of Chemical Engineers Symposium Series. 505-522 (<https://engage.aiche.org/HigherLogic/System/DownloadDocumentFile.ashx?DocumentFileKey=a48c5d29-842d-4382-88d8-4ecd176164fa&ssopc=1> ,)
- (6) ASTM D1193, *Standard Specification for Reagent Water* (<https://www.astm.org>;)
- (7) B.D. Flockhart, *The Vapor Pressures of Ethanol-Water Solutions of Detergents* 1960, [The vapor pressures of ethanol-water solutions of detergents - ScienceDirect](#)
- (8) Beth A. Miller-Chou, Jack L. Koenig, *A review of polymer dissolution*, *Prog. Polym. Sci.* 28, 2003 [A review of polymer dissolution - ScienceDirect](#)
- (9) Bill W. Lee, David E. Orr, *The Triboelectric Series*, , ©2009 by AlphaLab, Inc. (<https://www.alphalabinc.com/triboelectric-series;>)
- (10) CDC Guideline for Disinfection and Sterilization in Healthcare Facilities, 2008 Update: May 2019 [Guideline for Disinfection and Sterilization in Healthcare Facilities, 2008 \(cdc.gov\)](#)
- (11) Charles M. Hansen, *HANSEN SOLUBILITY PARAMETERS, A User's Handbook, Second Edition*, CRC Press, 2007
- (12) Christina Y. Piña Arpin, Joel Stoltzfus, *Rudimentary Cleaning Compared to Level 300A*, *Journal of ASTM International*, September, 2012, (<https://ntrs.nasa.gov/archive/nasa/casi.ntrs.nasa.gov/20120003024.pdf> ,)
- (13) *Discwasher™ U.S. Patent 3,951,84 Phonograph Record Cleaning Composition*, 1976.
- (14) EPA 2018 Edition of the Drinking Water Standards and Health Advisories Tables (<https://www.epa.gov/sites/production/files/2018-03/documents/dwtable2018.pdf> ,)
- (15) EPA, *Indoor Air Quality MERV-Rating* (<https://www.epa.gov/indoor-air-quality-iaq/what-merv-rating-1>)
- (16) EPA, *Nonylphenol (NP) and Nonylphenol Ethoxylates (NPEs)*, 8/18/2010, *Action Plan*, RIN 2070-ZA09 https://www.epa.gov/sites/production/files/2015-09/documents/rin2070-za09_np-npes_action_plan_final_2010-08-09.pdf,

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- (17) Filipa A. Vicente, Inês S. Cardoso, Tânia E. Sintra, Jesus Lemus, Eduardo F. Marques, Sónia P. M. Ventura, & João A. P. Coutinho, *Impact of Surface Active Ionic Liquids on the Cloud Points of Nonionic Surfactants and the Formation of Aqueous Micellar TwoPhase Systems* *J. Phys. Chem. B.* 2017, https://www.researchgate.net/publication/319257876_The_Impact_of_Surface_Active_Ionic_Liquids_on_the_Cloud_Points_of_Nonionic_Surfactants_and_the_Formation_of_Aqueous_Micellar_Two-Phase_Systems,
- (18) GE-Osmonics™ Pure Water Handbook (https://www.bigbrandwater.com/GE-Osmonics-RO-Membranes_ep_61-1.html,)
- (19) Geiman, Justin & Fuss, P., (2013). *Investigation of cigarettes as an ignition source for Coleman fuel.* *Fire and Materials 2013 - 13th International Conference and Exhibition, Conference Proceedings.* 759-768 ([PDF](#)) [Investigation of cigarettes as an ignition source for Coleman fuel \(researchgate.net\)](#)
- (20) Gilles St-Laurent Music Division National Library of Canada, *The Care and Handling of Recorded Sound Materials*, January 1996 [The Care and Handling of Recorded Sound Materials \(culturalheritage.org\)](#)
- (21) G. P. Humfeld, *Anti-Static Phonograph Records*, *RCA Engineer Magazine* Vol. 6, No.3. October-November, 1960 [1960-10-11.pdf \(worldradiohistory.com\)](#)
- (22) G. P. Humfeld, *Anti-static Phonograph Records*, *RCA Engineer Magazine*, 1976 Issue 10-11, [1976-10-11.pdf \(worldradiohistory.com\)](#)
- (23) Gonzalo Vazquez, Estrella Alvarez, Jose M. Navaza, *Surface Tension of Alcohol + Water from 20 to 50°C*, *Journal of Chemical and Engineering Data.* 1 May 1995, <https://pubs.acs.org/doi/abs/10.1021/je00019a016>,
- (24) Gordon Brushes®, *Brush Material* <https://www.gordonbrush.com/brush-fill-materials.php>
- (25) Hallstar™ *Plasticizers for PVC* <https://www.hallstar.com/webfoo/wp-content/uploads/Plasticizers-for-PVC.pdf>
- (26) Harold D. Weiler, *THE WEAR AND CARE OF RECORDS AND STYLI*, 1954 (funded by Shure® Inc, now in the Public domain <https://vinylrecordcleaningsystem.com/wp-content/uploads/2019/09/weiler-wear-and-care-of-records.pdf>.)
- (27) Hugh Finnimore, *Disc cutting in theory*, *Studio Sound and Broadcast Engineering*, July 1975 [Studio-Sound-1975-07.pdf \(worldradiohistory.com\)](#)
- (28) James H. Kogen, *Phonograph Reproduction 1978*, *Audio Magazine* May 1978 [Audio-1978-05.pdf \(worldradiohistory.com\)](#)
- (29) J G. Woodward, *Record -Groove Wear*, *HiFi Stereo Review Magazine*, October 1968, [HiFi-Stereo-Review-1968-10.pdf \(worldradiohistory.com\)](#)
- (30) J. Gordon Holt, *STEREOPHILE Chart File No. 8 Record Groove Parameters*, *The Stereophile Magazine* Vol.1 No. 8, August 1964 [Stereophile-1964-08.pdf \(worldradiohistory.com\)](#)
- (31) John Fuchs, *Ultrasonic Cleaning Fundamental Theory and Application*, *Blackstone Ultrasonics*, 1995 <https://ntrs.nasa.gov/archive/nasa/casi.ntrs.nasa.gov/19950025362.pdf>.
- (32) Kenneth R. Monroe, Elizabeth A. Hill, *Surfactant Parameter Effects On Cleaning Efficiency*, Oct 1993, *International CFC Alternatives Conference* [Surfactant Parameter Effect on Cleaning Efficiency \(p2infohouse.org\)](#).

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- (33) Kiril Strelitzky & George D. J. Phillis, *Temperature Dependence of Triton X-100 Micelle Size and Hydration*, Department of Physics, Worcester Polytechnic Institute, September 19, 1994 https://sciences.csuohio.edu/sites/csuohio.edu.sciences/files/media/physics/documents/Lang_111995.pdf
- (34) Library of Congress Lacquer Record Cleaning Procedure <https://www.nedcc.org/audio-preservation/cleaning-discs>
- (35) L. R. Happ, *Design Considerations of the VI5 Type IV Phonograph Cartridge*, delivered at a 1978 technical seminar on phonograph cartridges ([high-fidelity-phonograph-cartridge-technical-seminar-faq.pdf](https://www.cloudfront.net/d24z4d3zypmncx/technical-seminar-faq.pdf) (d24z4d3zypmncx.cloudfront.net))
- (36) Manual of Naval Preventive Medicine, Chapter 6, Water Supply Afloat <https://www.med.navy.mil/directives/Pub/5010-6.pdf>
- (37) Mason, T.J., *Ultrasonic cleaning: an historical perspective* CURVE 2016 <https://curve.coventry.ac.uk/open/file/d066157d-49ca-4d32-a575-8b07fa144040/1/Ultrasonic%20cleaning.pdf>
- (38) M. B. Ranade (1987) *Adhesion and Removal of Fine Particles on Surfaces*, *Aerosol Science and Technology*, 7:2, 161-176, DOI: 10.1080/02786828708959155 [Adhesion and Removal of Fine Particles on Surfaces: Aerosol Science and Technology: Vol 7, No 2 \(tandfonline.com\)](https://www.tandfonline.com/doi/abs/10.1080/02786828708959155)
- (39) MIL-HDBK-263B *Electrostatic Discharge Control (ESD) Handbook for Protection of Electrical and Electronic Parts, Assemblies and Equipment* (<http://www.everyspec.com/>)
- (40) MIL-HDBK-407 *Precision Cleaning Methods and Procedures* (<http://www.everyspec.com/>)
- (41) MIL-STD-1246C, *Product Cleanliness Levels and Contamination Control Program* (<http://www.everyspec.com/>)
- (42) MIL-STD-1330D *Precision Cleaning and Testing of Shipboard Oxygen, Helium, Helium-Oxygen, Nitrogen, And Hydrogen Systems* (<http://www.everyspec.com/>)
- (43) MIL-STD-1622B *Standard Practice for Cleaning of Shipboard Compressed Air Systems* (<http://www.everyspec.com/>)
- (44) Moe Sato & Anita Quye, *Detergency evaluation of non-ionic surfactant BASF™ DEHYPON® LS54 for textile conservation wet cleaning*, *Journal of the Institute of Conservation*, 29 Jan 2019 [Detergency evaluation of non-ionic surfactant Dehypon® LS54 for textile conservation wet cleaning \(tandfonline.com\)](https://www.tandfonline.com/doi/abs/10.1080/00220166.2019.1603111)
- (45) Morales Muñoz, Clara & Egsgaard, Helge & Sanz-Landaluze, Jon & Dietz, Christian. (2014). *A Model Approach for Finding Cleaning Solutions For Plasticized Poly(Vinyl Chloride) Surfaces of Collections Objects*, *Journal of the American Institute for Conservation*, 53. 236-251. https://www.researchgate.net/publication/268448708_A_model_approach_for_finding_cleaning_solutions_for_plasticized_polyvinyl_chloride_surfaces_of_collections_objects
- (46) NASA Contractor Report 4740, *Contamination Control Engineering Design Guidelines for the Aerospace Community*, C. Tribble, B. Boyadjian, J. Davis, J. Half-net, and E. McCullough, Rockwell International Corporation, May 1996 (<https://ntrs.nasa.gov/archive/nasa/casi.ntrs.nasa.gov/19960044619.pdf>.)
- (47) NASA *Electrical Bonding: A Survey of Requirements, Methods, and Specifications*, NASA/CR-1998-207400, Mar 1998(<http://www.everyspec.com/>)
- (48) NASA LPR 1740.5F, *Procedures for Cleaning of Systems and Equipment for Oxygen Service*, 2015 (https://lmsc.larc.nasa.gov/admin/public_docs/LPR_1740.5_ExtensionMemo.pdf.)

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- (49) NASA/TM-2011-217231, *Evaluation of Brushing as a Lunar Dust Mitigation Strategy for Thermal Control Surfaces*
(<https://ntrs.nasa.gov/archive/nasa/casi.ntrs.nasa.gov/20120000070.pdf>.)
- (50) NAVSEA Report on Aqueous Oxygen Cleaning Products and Processes, 1994
(<https://p2infohouse.org/ref/14/13872.pdf>)
- (51) New York Mount Sinai Silekoff Centers for Occupation Health titled "Quaternary Ammonium Compounds in Cleaning Products: Health & Safety Information for Health Professionals, August 2015, (https://www.mountsinai.org/files/MSHealth/Assets/HS/Patient-Care/Service-Areas/Occupational-Medicine/QACsInfoforWorkers_18.pdf.)
- (52) Percy Wilson, *Record Contamination: Causes and Cure*, by Journal of The Audio Engineering Society April 1965, Volume 13, Number 2 [AES E-Library » Record Contamination: Cause and Cure](#)
- (53) *Particle Adhesion and Removal*, Editors K.L. Mittal and Ravi Ja, John Wiley & Sons, Inc, 2015
[Particle Adhesion and Removal | Wiley Online Books](#)
- (54) *Quantifying the triboelectric series*, 2015
<https://www.ncbi.nlm.nih.gov/pmc/articles/PMC6441076/>,
- (55) RCA Patent 3,960,790, June 1, 1976, DISC RECORD AND METHOD OF COMPOUNDING DISC RECORD COMPOSITION [1498409551006799538-03960790 \(storage.googleapis.com\)](#)
- (56) *Returned/Overpressed Recycle Records*, Tue Mar 10, 2020 2:12 pm
(<http://vpiforum.com/viewtopic.php?f=7&t=13498&start=40#p58611;>)
- (57) Richard C. Adams, *A Comparison of Plasticizers for Use in Flexible Vinyl Medical Products*, April 2001, Copyright ©2001 Medical Device & Diagnostic Industry,
<https://www.mddionline.com/comparison-plasticizers-use-flexible-vinyl-medical-products>,
- (58) Robert Harley, *An LP Primer, The Absolute Sound* June/July 2007 vinyl_tutorial
(harryshifi.com)
- (59) Robert Stockton, *Do Turntable Mats Work? You Bet!*, Audio Magazine June 1979 [Audio-1979-06.pdf \(worldradiohistory.com\)](#)
- (60) S.K. Khanna, *Polymer Science - New Materials for Phonograph Discs*, RCA Engineer Magazine, 1976 Issue Oct-Nov [1976-10-11.pdf \(worldradiohistory.com\)](#)
- (61) S.K. Khanna & G.A. Bogantz, *Development of Compound for Quadradsics*, RCA Engineer Magazine, 1976, Issue Feb-Mar [1976-02-03.pdf \(worldradiohistory.com\)](#)
- (62) Shang-Yi Shen • Jia-Chi Chen • Shang-Hao Liu, Ron-Hsin Chang, Horng-Jang Liaw, Chi-Min Shu, *Effects of upper explosion limit for isopropyl alcohol by steam, inerting at 1 atm and 150 °C by 20-L-apparatus*, J Therm Anal Calorim (2013) 113:1619–1624 ([PDF](#)) [Effects of upper explosion limit for isopropyl alcohol by steam inerting at 1 atm and 150 °C by 20-L-apparatus \(researchgate.net\)](#)
- (63) Stuart Lyon, *Corrosion of Lead and its Alloys*, December 2010 ([PDF](#)) [Corrosion of Lead and its Alloys \(researchgate.net\)](#)
- (64) Tadahihiro Ohmi, Seiji Sudoh, and Hiroyuki Mishima, *Static Charge Removal with IPA Solution*, IEEE Transactions on Semiconductor Manufacturing, Vol. I, No. 4. November 1994 [Static charge removal with IPA solution - IEEE Journals & Magazine](#)
- (65) Tom Green, *Why Three Monolayers of Moisture Are Important*, T.J. Green Associates, LLC, Bob Lowry, *Electronic Materials Consultant*, September 2016 ([Why Three Monolayers Of Moisture Are Important - Tj Green Associates LLC. \(tjgreenllc.com\)](#))

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

- (66) Tyler J Johnson Jason S Olfert, Ross Cabot, Conor Treacy, Caner U Yurteri, Colin Dickens, John McAughey, Jonathan P.R Symonds, *Transient Measurement of The Effective Particle Density Of Cigarette Smoke*, *Journal of Aerosol Science* 87(May 2015)63–74. [\(PDF\) Transient measurement of the effective particle density of cigarette smoke \(researchgate.net\)](#)
- (67) Vetrinurugan, J. Michael Goodson, and Terry Lim, *Parametric Study for High-Frequency, High-Intensity Ultrasonics in Removal of Sub-Micron Particles*, *International Journal of Chemical Engineering and Applications*, Vol. 6, No. 1, February 2015 (<http://ijcea.org/vol6/444-C1009.pdf>)
- (68) Wei, Z. B.; Zhao, Y.; Wang, C.; Kuga, S.; Huang, Y.; Wu, M *Anti-static PVC-graphene Composite through Plasticizer-mediated Exfoliation of Graphite*, *Chinese Journal Polymer Science*, June 2018 <https://doi.org/10.1007/s10118-018-2160-5>,
- (69) WHO *Nutrients in Drinking Water 2005*
https://www.who.int/water_sanitation_health/publications/nutrients-in-dw/en/,
- (70) Yeon Joo Kim, Jaejun Lee, Sangwon Park, Chanhoo Park, Cheolmin Park and Heon-Jin Cho, *Effect of the relative permittivity of oxides on the performance of triboelectric nanogenerator*, *RSC Adv.*, 2017, 7, 49368 [\(PDF\) Effect of the relative permittivity of oxides on the performance of triboelectric nanogenerators \(researchgate.net\)](#)

REMAINDER OF PAGE INTENTIONALLY BLANK

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

APPENDIX B - LIST OF ABBREVIATIONS & ACRONYMS

AEL	Allowable Exposure Limit
CAS	Chemical Abstract System
CCI	Canadian Conservation Institute
CMC	Critical Micelle Concentration
DIW	Distilled/Deionized Water
DOE	Double Open Ended (ref: filter cartridge)
EPA	Environmental Protection Agency
ESD	Electrostatic Discharge
ESO	Epoxide Soybean Oil
GPM	Gallons per Minute
HDPE	High Density Polyethylene
HEPA	High Efficiency Particulate Air
LDPE	Low Density Polyethylene
IPA	Isopropyl Alcohol
LPM	Liters per Minute
MSDS	Material Safety Data Sheet
NASA	National Aeronautics and Space Agency
NID	Non-Ionic Detergent
NPSH	Net Positive Suction Head
NTU	Nephelometric Turbidity Units
NVR	Non-Volatile Residue
PPE	Personal Protective Equipment
PVA	Polyvinyl Alcohol (ref: sponge)
PVC	Polyvinyl Chloride
PVCa	Polyvinyl Chloride-Acetate
QAC	Quaternary Ammonium Compound
RCM	Record Cleaning Machine (ref: vacuum type)
RIAA	Recording Industry Association of America®
SEM	Scanning Electron Microscope
TDS	Total Dissolved Solids
TSS	Total Suspended Solids
UCM	Ultrasonic Cleaning Machine
UV	Ultraviolet
VAC	Volts Alternating Current
VDC	Volts Direct Current
VTF	Vertical Tracking Force
WHO	World Health Organization

Precision Aqueous Cleaning of Vinyl Records

Version: Second Edition March 2021

APPENDIX C - RECORD OF CHANGES

Date	Edition	Change
2020-05-19	-	Initial paper for development and review with last date of changes. Each page has a version date that may be used to identify future revisions.
May 2020	Rev A	Official version advanced to Revision A designating that all comments and changes have been adjudicated and incorporated and paper is approved for public release by author and The Vinyl Press.
March 2021	2nd	Major revision. Instead of advancing to Rev B, decision is made to title as Second Edition. Change details addressed in paper Forward. Document available for free download at the https://thevinylpress.com/